


Projector Instructions For SharpNV4

Step One:

The Sharp NV4 should contain 2 basic cords. Make sure all the cords are in the bag.



Cord #1: Plugs into the projector and the wall. Input 1 = RGB1

Cord #2: The second cord plugs into the laptop and to the projector (RGB1= port 1).




Plug to Projector

Step Two:

Turn on the projector on first and then the laptop.

Step Three:

Projector should come show on the screen (imaging). The “input selection” button on the projects will help you choose RGB1, RGB2, or video. **You will generally choose RGB1 for PowerPoint presentations. RGB2 is for Blackboard. Video is for a movie.**





Step Four:

If the projector is not projecting an image from the laptop, please re-start the computer. Then the projector will be able to find the image.

Step Five:

If the projector is still not projecting an image, then you must hold two keys at the same time the projector will also find the image. These two keys are: Fn and F3 (Please hold these keys down together). You may have to hit these particular keys 3 different times until you get the projected image on your desktop and screen or wall. Sometimes the Projector buttons maybe an F4 rather than an F3. Please take note of the pictures on the next page.



Step Six:

If you are still having problems call [Marti at x5289](#), Lowell at x7679, Sue at x5189.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>