

Citrus Press Automatic citrus juicer with anti-drip spout

Instruction Booklet JE2700

Please read these instructions carefully and retain for future reference.



Contents

| Sunbeam's Safety Precautions | 1 |
|------------------------------|---|
| Features of your CitrusPress | 2 |
| Using your CitrusPress | 4 |
| Care and Cleaning | 4 |

Important instructions – retain for future use.

تأكد من تفهِّم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

كارى بكنيد كه احتياطهاي بالاحتما درك بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Download from Www.Somanuals.com. All Manuals Search And Download.

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR CITRUSPRESS.

 Handle the moving parts of the device with extreme care and caution.


Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Never leave an appliance unattended while in use.

- Switch power outlet off and unplug before cleaning.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
- Do not operate your CitrusPress for more than 5 minutes continuously.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or www.sunbeam.co.nz contact the Sunbeam Customer Service Line. Ensure the above safety precautions are understood.

Features of your Sunbeam CitrusPress



Features of your Sunbeam CitrusPress (continued)

Dust cover

For use when the CitrusPress is in storage and not in use.

Large Juicing Cone

Extracts juice from large citrus fruits, such as oranges and grapefruits.

Small Juicing Cone

Extracts juice from small citrus fruits, such as lemons and limes.

Automatic start/stop operation

To start the juicer simply push the fruit onto the juicing cone, it stops automatically when you release the pressure.

Auto reverse juicing action

Each time pressure is applied to the juicing cone, the direction of operation is reversed to extract the most juice from the fruit.

Stainless steel sieve

Separates the pulp and ensures you get fresh, smooth juice.

Cord Storage

Excess cord can be wound around the storage facility underneath the CitrusPress.

Anti-drip spout

The anti-drip spout, when flipped down, allows fresh juice to pour directly into your glass. To stop the flow or to place another glass, simply push the anti-drip spout upwards. This will stop the flow of juice without spilling a single drop.

Non-slip feet

Ensures the CitrusPress remains stable on the benchtop for your safety and convenience.

Using your Sunbeam CitrusPress

Before using your CitrusPress

Clean the juicing cones, stainless steel sieve and juice container in warm soapy water. Rinse and dry thoroughly. Alternatively you can place these parts in the upper section of your dishwasher.

Using your CitrusPress

- Position the stainless steel sieve onto the juicing container and place onto the motor base.
- 2. Place the small juicing cone onto the drive shaft. If you are juicing larger citrus fruits, position the larger juicing cone over the smaller juicing cone so the large cone is sitting on top of the smaller cone.
- 3. Plug the power cord of the CitrusPress into a 230-240V AC power outlet and switch the power on.
- 4. Place a glass under the anti-drip spout.
- To open the anti-drip spout, push it downwards to allow the juice to slow into the glass.

6. Cut the citrus segments in half, cutting across the segments.

Note: Before juicing we recommend that you roll the fruit on the bench whilst pressing down gently. This way you will obtain more juice.

- 7. Press a fruit half onto the juicing cone the CitrusPress starts automatically and stops when the fruit is removed.
- 8. Push the anti-drip spout upwards to stop the flow of juice, you can then remove or exchange the full glass with another this ensures that the anti-drip spout does not allow the juice to continue to flow.
- 9.When the CitrusPress is no longer needed, remove the power cord from the power outlet and clean the CitrusPress – see "Care and Cleaning" below.

Care and Cleaning

Note: Before cleaning always remove the power cord from the power outlet.

Remove the juicing cones, stainless steel sieve and juicing container from the motor part of the base of the CitrusPress.

Clean all parts with warm soapy water. Rinse and dry thoroughly.

Note: For thorough cleaning of the anti-drip spout, it can be removed from the juicing container. This ensures that any residue remaining from the juice is removed.

Alternatively you can place these parts in the upper section of your dishwasher.

Clean the motor base of the CitrusPress with a damp cloth. Never use harsh cleaning or scouring agents. Never immerse in water or other liquids.



12 Month Replacement Guarantee

In the unlikely event that this appliance develops any malfunction within 12 months of purchase (3 months commercial use) due to faulty materials or manufacture, we will replace it for you free of charge.

Should you experience any difficulties with your appliance, please phone our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand. Alternatively, you can send a written claim to Sunbeam at the address listed below. On receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the appliance is defective, advise you on how to obtain a replacement or refund.

Your Sunbeam 12 Month Replacement Guarantee naturally does not cover misuse or negligent handling and normal wear and tear

Similarly your 12 Month Replacement Guarantee does not cover freight or any other costs incurred in making a claim. Please retain your receipt as proof of purchase.

The benefits given to you by this guarantee are in addition to your other rights and remedies under any laws which relate to the appliance.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law and under the New Zealand Consumer Guarantees Act In Australia you are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Should your appliance require repair or service <u>after</u> the guarantee period, contact your nearest Sunbeam service centre.

For a complete list of Sunbeam's authorised service centres visit our website or call:

Australia

www.sunbeam.com.au

1300 881 861

Units 5 & 6, 13 Lord Street Botany NSW 2019 Australia

New Zealand

www.sunbeam.co.nz

0800 786 232

26 Vestey Drive, Mt Wellington Auckland, New Zealand



Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

In Australia

Visit www.sunbeam.com.au Or call 1300 881 861

In New Zealand

Visit www.sunbeam.co.nz Or call 0800 786 232



Sunbeam is a registered trademark.

Made in China.

Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2012.

ABN 45 000 006 771

Units 5 & 6, 13 Lord Street Botany NSW 2019 Australia

Unit 3, Building D

26 Vestey Drive

Mt Wellington Auckland

New Zealand

Sunbeam Corporation is a division of GUD Holdings Ltd.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com