


# REPAIR PARTS FOR 45-0458 SPIKE AERATOR



REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	26369	Shaft	6	4	1540-31	Washer, .78" x 1.25" x .062"
2	10	25429	Curved Spike Disk	7	2	44798	Flange Bearing
3	20	45148	Spike Disk Hub	8	2	714-0121	Cotter Pin 5/32" x 1"
4	9	44494	Spacer, .8" x 1" x 1.33"	1	1	40753-S	Owners Manual
5	2	23368	Spacer, .76" 1" x .75"				

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>