


GLOBALMARK[®] 2

INDUSTRIAL LABEL MAKER



User Guide

English



Copyright	i-iii
Disclaimer	i-iii
End User License Agreement for Microsoft Windows CE,,	i-iv
Brady Warranty	i-v
FCC Notice-US Only	i-vi
<i>Canada</i>	<i>i-vi</i>
<i>Europe</i>	<i>i-vi</i>
Specifications	i-vii
<i>Physical characteristics</i>	<i>i-vii</i>
<i>Environmental characteristics</i>	<i>i-vii</i>
<i>Electrical characteristics</i>	<i>i-vii</i>
International Power Cords	i-viii

CHAPTER 1 Welcome

About This Book	1-2
Features and Functions	1-2
<i>The three printer systems</i>	<i>1-3</i>
<i>Specialty applications</i>	<i>1-4</i>
Contacting Technical Support	1-5
<i>Americas</i>	<i>1-5</i>
<i>Europe</i>	<i>1-5</i>
<i>Pacific</i>	<i>1-6</i>

CHAPTER 2 Setting Up

Connecting Peripherals	2-2
Installing supplies	2-3
<i>Opening the printer</i>	<i>2-4</i>
<i>Installing a ribbon cartridge</i>	<i>2-5</i>
<i>Adjusting the ribbon cartridge</i>	<i>2-6</i>
<i>Installing a tape cartridge</i>	<i>2-7</i>
<i>Closing the printer cover</i>	<i>2-11</i>
Installing a compact flash memory card	2-13
Cleaning your system	2-14

CHAPTER 3 Starting Up

Launching Your System	3-2
<i>The Main Menu</i>	<i>3-2</i>
Keyboard Basics	3-4

<i>The standard keyboard</i> -----	3-5
<i>System function keys</i> -----	3-5
<i>Alphabetic and command keys</i> -----	3-9
<i>Arrow and navigation keypads</i> -----	3-11
<i>Numeric keypad</i> -----	3-14
<i>Shortcut keys</i> -----	3-16
Mouse Basics-----	3-16
<i>Using a mouse on labels</i> -----	3-17
Checking System Status-----	3-17
Accessing Online Help-----	3-18

CHAPTER 4 Basic Procedures

Working in the Editor window-----	4-2
<i>Inside the Editor window</i> -----	4-3
<i>Editing procedures</i> -----	4-7
Working in Entry Screens-----	4-9
<i>Navigating in entry screens</i> -----	4-9
<i>Entering information in entry screens</i> -----	4-11
<i>Choosing options</i> -----	4-12
<i>Exiting entry screens</i> -----	4-15

CHAPTER 5 Setting Preferences

Accessing System Setup-----	5-2
Setting Printing Tab Options-----	5-4
Setting Localization Tab Options-----	5-6
Setting Hardware Tab Options-----	5-8
<i>Naming supply colors</i> -----	5-9
Setting Other Tab Options-----	5-10
<i>Displaying the screen grid</i> -----	5-11
Setting Text Tab Options-----	5-12
Setting On Line Tab Options-----	5-15

CHAPTER 6 Working with Labels

Creating Custom Labels-----	6-2
Creating QuickText Labels-----	6-5
<i>QuickText toolbar functions</i> -----	6-7
<i>QuickText key functions</i> -----	6-9
Creating Template Labels-----	6-10



<i>Pipe Marker and Right-to-Know exceptions</i> -----	6-11
<i>Choosing a label application</i> -----	6-11
<i>Choosing a category</i> -----	6-12
<i>Selecting a template</i> -----	6-13
<i>Following prompt sequences</i> -----	6-16
Creating Sets of Labels -----	6-21
<i>Adding labels to a label set</i> -----	6-22
<i>Moving between labels in a label set</i> -----	6-23
<i>Editing labels in a label set</i> -----	6-23
<i>Clearing labels in a label set</i> -----	6-23
<i>Saving label sets</i> -----	6-24
Changing Labels -----	6-24
<i>Changing the size of template labels</i> -----	6-25
<i>Editing template labels</i> -----	6-26
<i>Changing Label Properties</i> -----	6-27
Setting Application Preferences -----	6-33

CHAPTER 7 Working with Objects

About Objects -----	7-2
Adding Objects -----	7-3
<i>Adding and formatting text objects</i> -----	7-4
<i>Adding variable text objects</i> -----	7-10
<i>Adding vertical text objects</i> -----	7-16
<i>Adding bar code objects</i> -----	7-17
<i>Adding graphics objects</i> -----	7-22
<i>Adding HotShapes</i> -----	7-24
Selecting Objects -----	7-25
<i>Selecting a layered object</i> -----	7-26
Moving Objects -----	7-26
Sizing Objects -----	7-27
<i>Using Increase Size and Decrease Size</i> -----	7-28
<i>Using the Scale function</i> -----	7-28
Copying and Pasting Objects -----	7-30
Changing Objects-----	7-31
<i>Opening and editing an object</i> -----	7-31
<i>Changing object properties</i> -----	7-32

CHAPTER 8 Applying Color

About Color -----	8-2
-------------------	-----

<i>Ribbon color</i>	8-2
<i>Tape color</i>	8-4
Applying Color to Objects	8-5
<i>About the Object Color screen</i>	8-5
<i>Choosing color on the Monocolor system</i>	8-6
<i>Choosing color on the Multicolor and Color & Cut systems</i>	8-7
Printing Color	8-9

CHAPTER 9 Working with Files

About Files and File Groups	9-2
Saving Labels as Files	9-3
Managing Files	9-7
<i>Opening saved label files</i>	9-7
<i>Editing files</i>	9-10
<i>Deleting files</i>	9-11
Printing Files	9-12
Transferring Files	9-12
Using My Templates	9-12
<i>Accessing template files</i>	9-13
<i>Changing My Template label size</i>	9-14

CHAPTER 10 Working with Cut-outs

About Cutting	10-2
Creating Cut Out Objects	10-3
<i>Adding cut out objects</i>	10-4
Cutting Around Objects	10-8
<i>Minimum cut size</i>	10-9
Cutting Around Label Frames	10-10
Calibrating the Cutter	10-11
<i>Setting cutter calibration values</i>	10-11
<i>Restoring default cutter calibration settings</i>	10-14

CHAPTER 11 Printing

Printing Labels	11-2
<i>About pages</i>	11-2
<i>Printing a single label</i>	11-4
<i>Printing multiple copies of a single label</i>	11-5
<i>Printing labels in a label set</i>	11-6



<i>Printing labels in a file group</i> -----	11-7
Checking Supplies -----	11-10
Checking Size -----	11-11
Checking Length -----	11-12
<i>Minimum length</i> -----	11-12
<i>Maximum length</i> -----	11-12
<i>Cut out label length</i> -----	11-15
Checking Color -----	11-15
<i>Ribbon and color choices</i> -----	11-15
<i>Ribbon color needed</i> -----	11-17
<i>Tape color needed</i> -----	11-18
<i>Checking for cut out labels</i> -----	11-19
Printing Tab Options-----	11-19
<i>Accessing the Printing tab options</i> -----	11-20
<i>Supply saver option</i> -----	11-21
<i>Overprint option</i> -----	11-23
Canceling a Print Job -----	11-24

CHAPTER 12 Connecting to a PC

Working with a PC -----	12-2
Setting Up Your System as a Hardware Device -----	12-3
Placing Your System Online-----	12-4
<i>Setting Online Options</i> -----	12-4
<i>Connecting your system and a PC</i> -----	12-5
Printing from a PC -----	12-7
Working with the File Management Utility -----	12-8
<i>Storage locations for exported files</i> -----	12-8
<i>Installing the File Management Utility</i> -----	12-10
<i>Launching the File Management Utility</i> -----	12-11
<i>Communication Status</i> -----	12-11
<i>File Management Utility Main Menu</i> -----	12-12
Upgrading the Operating System -----	12-15

Appendix A Special Characters

Appendix B Cutter Maintenance

About the Cutting Mechanism -----	B-2
Removing the Stylus Holder-----	B-3

Adjusting the Cut Depth-----	B-4
Replacing the Stylus Blade -----	B-7
Cleaning the Stylus -----	B-8

Appendix C Error Messages

Error Messages -----	C-2
----------------------	------------



Copyright

This manual is copyrighted with all rights reserved. No portion of this manual may be copied or reproduced by any means without the prior consent of Brady Worldwide, Inc.

While every precaution has been taken in preparation of this document, Brady assumes no liability to any party for any loss or damage caused by errors or omissions or by statements resulting from negligence, accident, or any other cause. Brady further assumes no liability arising out of the application or use of any product or system described, herein; nor any liability for incidental or consequential damages arising from the use of this document. Brady disclaims all warranties of merchantability or fitness for a particular purpose.

Brady reserves the right to make changes without further notice to any product or system herein to improve reliability, function, or design.

Reproduction of this material, in part or whole, is strictly prohibited without the written permission of Brady Worldwide, Inc. For more information, contact: Brady Worldwide, Inc. Signmark® Division, 2221 W. Camden Road, Milwaukee, WI 53209.

Disclaimer

Every effort has been made to make this guide as accurate and complete as possible. Brady Worldwide, Inc. is not responsible for labeling inaccuracies and omissions occurring during the use of this guide.

This manual is proprietary to Brady Worldwide, Inc. and may be revised from time to time without notice. Brady Worldwide, Inc. disclaims any understanding to provide you with revisions, if any.

Windows CE is a trademark of the Microsoft Corporation.

Adobe Illustrator is a trademark of the Adobe Corporation.

All brand or product names referenced in this manual are trademarks or registered trademarks of their respective companies or organizations.

MarkWare and GalaRio are registered trademarks of Brady Worldwide, Inc.

**© 2006 Brady Worldwide, Inc. All rights reserved.
www.bradycorp.com**

End User License Agreement for Microsoft Windows CE[©]

You have acquired a device that includes software licensed by Brady Worldwide, Inc. from Microsoft Licensing or its affiliates (“MS”). Those installed software products of Microsoft origin, as well as associated media, printed materials, and “online” or electronic documentation (“SOFTWARE”) are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT, DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT BRADY WORLDWIDE, INC. FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS END USER LICENSE AGREEMENT (OR RATIFICATION OF ANY PREVIOUS CONSENT).

GRANT OF SOFTWARE LICENSE: This End User License Agreement grants you the following license:

You may use the SOFTWARE only on the DEVICE.

NOT FAULT TOLERANT. THE SOFTWARE IS NOT FAULT TOLERANT. BRADY WORLDWIDE, INC. HAS INDEPENDENTLY DETERMINED HOW TO USE THE SOFTWARE IN THE DEVICE, AND MS HAS RELIED UPON BRADY WORLDWIDE, INC. TO CONDUCT SUFFICIENT TESTING TO DETERMINE THAT THE SOFTWARE IS SUITABLE FOR SUCH USE.

NO WARRANTIES FOR THE SOFTWARE. The SOFTWARE is provided “as is” and with all faults. THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY, AND EFFORT (INCLUDING LACK OF NEGLIGENCE) IS WITH YOU. ALSO, THERE IS NO WARRANTY AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE OR AGAINST INFRINGEMENT. IF YOU HAVE RECEIVED ANY WARRANTIES REGARDING THE DEVICE OR THE SOFTWARE, THOSE WARRANTIES DO NOT ORIGINATE FROM, AND ARE NOT BINDING ON, MS.

Note on Java support. The SOFTWARE may contain support for programs written in Java. Java technology is not fault tolerant and is not designed, manufactured, or intended for use or resale as online control equipment in hazardous environments requiring fail-safe performances, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of Java technology could lead directly to death, personal injury, or severe physical or environmental damage. Sun Microsystems, Inc. has contractually obligated MS to make this disclaimer.

No Liability for Certain Damages. EXCEPT AS PROHIBITED BY LAW, MS SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL MS BE LIABLE FOR ANY AMOUNT IN EXCESS OF U.S. TWO HUNDRED FIFTY DOLLARS (U.S.\$250.00).

Limitations on Reverse Engineering, Decompilation, and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

SOFTWARE TRANSFER ALLOWED BUT WITH RESTRICTIONS. You may permanently transfer rights under this End User License Agreement only as part of a permanent sale or transfer of the Device, and only if the recipient agrees to this End User License Agreement. If the SOFTWARE is an upgrade, any transfer must also include all prior versions of the SOFTWARE.

EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is of US-origin. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use, and country destination restrictions issued by U.S. and other governments. For additional information on exporting the SOFTWARE, see <http://www.microsoft.com/exporting/>.

Brady Warranty

Our products are sold with the understanding that the buyer will test them in actual use and determine for him or herself their adaptability to his/her intended uses. Brady warrants to the buyer that its products are free from defects in material and workmanship, but limits its obligation under this warranty to replacement of the product shown to Brady's satisfaction to have been defective at the time Brady sold it. This warranty does not extend to any persons obtaining the product from the buyer.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND OF ANY OTHER OBLIGATIONS OR LIABILITY ON BRADY'S PART. UNDER NO CIRCUMSTANCES WILL BRADY BE LIABLE FOR ANY LOSS, DAMAGE, EXPENSE OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING IN CONNECTION WITH THE USE, OR INABILITY TO USE, BRADY'S PRODUCTS.

警告使用者：

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

FCC Notice-US Only

Warning: This equipment generates, uses and can radiate radio frequency energy. If not installed and used in accordance with the manufacturer's instructions, it may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart B of Part 15 of the FCC rules, which are designed to provide reasonable protection against interference when operating in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case required corrective measures will be at the owner's expense. The user is cautioned that any changes or modifications not expressly approved by Brady Worldwide, Inc. could void the user's authority to use the equipment.

Canada

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Europe

This is a Class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

Specifications

Physical characteristics

Size: Height 10" Width 16" Depth 11"

Weight: approximately 30 pounds

Environmental characteristics

Operational requirements

Ambient operating temperature: 50° F to 105° F (10° C to 41° C)

Relative humidity: 20% to 80% (non-condensing)

Storage requirements

Ambient storage temperature: 0° F to 140° F (-18° C to 60° C)

Relative humidity: 10 to 95% (non-condensing)

Electrical characteristics

Input current: 2.0 Amps

Input voltages: 100-240 VAC

Input frequency: 50 to 60 Hz

International Power Cords

Users in countries outside of North America may be required to supply their own power cord for connecting the system to an AC electrical outlet. Choose an AC power cord and plug that is suitable for the country in which the equipment is to be installed. The AC power cord and plug must meet all national regulations and requirements for that intended country.

The table below shows the specifications for the power cord to be used in various countries:

In this country:	Use this power cord:
Sweden, Norway, Finland, Austria, Germany, Belgium, France, Spain, Portugal, Netherlands	Specifications plug: CEE-7/7 connector: IEC 320 60320 C13 conductor size: 3 x 1.00 mm ² description: H05VVF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length
United Kingdom, Ireland	Specifications plug: BS 1363A connector: IEC 60320 C13 conductor size: 3 x 1.00 mm ² description: H05VVF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length: less than 3 meters

In this country:	Use this power cord:
Australia, New Zealand	<p>Specifications plug: AS 3112-1981 connector: IEC 320 60320 C13 conductor size: 3 x 1.00 mm² description: AS 3191H05WF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length: less than 3 meters</p>
Italy	<p>Specifications plug: CEI 23-16/VII connector: IEC 60 320 C13 conductor size: 3x 1.0 mm² description: H05VVF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length: less than 3 meters</p>
Denmark	<p>Specifications plug: Afsnit 107-2-D1 connector: IEC 60 320 C13 conductor size: 3x 1.0 mm² description: H05VVF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length: less than 3 meters</p>
Switzerland	<p>Specifications plug: SEV 1011 connector: IEC 60 320 C13 conductor size: 3x 1.0 mm² description: H05VVF3G1.0 typ. stranding: 32/0.2 mm current rating: 10A voltage rating: 250 VAC maximum length: less than 3 meters</p>



Welcome

Thank you for purchasing our label maker, which you use to create and print professional-looking labels and signs for use just about anywhere. All you have to do is:

- Drop in a ribbon cartridge, choosing from a wide range of single-color ribbons, paneled ribbons, and CMYK ribbons for blended colors.
- Drop in a tape cartridge, choosing tape in widths that range from 1/2 inch to 4 inches, and come in many colors, in many different styles, and in a wide range of materials.
- Type your text and plug in objects or symbols of your choice, or choose a pre-formatted layout design to use.

This chapter introduces you to your printing system. Topics include:

- About This Book**
- Features and Functions**
- Contacting Technical Support**

About This Book

This manual documents the basic Monocolor printing system, all of whose features are common to all three systems (described in **The three printer systems** on page 1-3).

You'll also find complete information about the Multicolor system and the Color & Cut system features and special applications in specially-designated sections and chapters. This book also provides an appendix listing all special characters you can use on your labels, and instructions for those of you with the Color & Cut system about how to maintain your system's cutter mechanisms.

Features and Functions

Listed below are just some of the features that make this system so easy to use and ready to meet your label-making requirements:

- Small, lightweight (approximately 30 pounds), ready for your desktop.
- Touch screen LCD display, plus keyboard input for ease of use, with optional mouse capabilities provided.
- Pre-designed layouts for many standard-use labels included.
- Hundreds of graphics provided for inclusion on your labels.
- QuickText special application for speedy print of text-only labels.
- HotShapes feature for printing non-standard labels of various shapes. Cut-out capability comes with Color & Cut system.
- Single color job printing at 300 DPI up to 100 mm wide, up to 100 inches (2540 mm).
- Color job printing at 300 DPI, 2 inches (51 mm) to 38 inches (965 mm).
- Tape supplies from .5 (13mm) to 4 (102) inches, in vinyl, polyester, phosphorescent, reflective, polypropylene, tamper evident, tag stock, brushed metallic polyester tapes, custom-color vinyl offered.
- Wide variety of monochrome ribbons, panel ribbons in panel lengths of 6 to 16 inches (152 to 406 mm), and CYMK ribbons that blend to make many colors.
- File or graphic transfer from PC available.

The three printer systems

All three label-printing systems use Microsoft Windows CE[®] as the basis for the operating system and application. As the user, most of the Windows CE operating system will be invisible to you. You don't need to use your computer skills to operate this printing system.

Hint! You do have the option to connect to a desktop computer to use the system as a peripheral printer or to manage and store files. See **CHAPTER 12: Connecting to a PC**, beginning on page 12-1, for information.

The three systems are:

Monocolor system

The base system, which produces monochrome labels only.

Hint! The definition of **monochrome** in this context is not necessarily black, white, and shades of gray as you may see on a black-and-white television screen. In this system, monochrome means a single color, plus shades of that color, plus white. In the Monocolor system, the single color is determined by the color of the ribbon you have installed.

The Monocolor system automatically shears labels to the correct length after printing, but does not have the ability to produce cut-outs and cut-arounds.

The system is designed to run as a standalone system without support from a PC, but you can attach a PC to access special file management features. The Monocolor system LCD screen displays in grayscale only, like a black and white television.

Multicolor system

The base system, plus color printing capability. The Multicolor system is provided with a color LCD display, and can take full advantage of spot and process color printing supplies available. See **CHAPTER 8: Applying Color**, beginning on page 8-1, for information about using color.

Color & Cut system

The base system, plus color printing capability and a color LCD display, plus cut-out capability, which means the system can not only print your labels, but can cut labels into shapes. See **CHAPTER 10: Working with Cut-outs**, beginning on page 10-1, for information about using the cutter.

Specialty applications

Your system provides these specialty label applications:

- **Custom**, for creating labels you design yourself.
- **QuickText**, for creating text-only labels quickly and easily
- **Pipe Marker**, with pre-designed layouts for creating standard, roll-form, or symbol and arrow labels for marking pipes.
- **Tags**, with pre-designed layouts for creating hazard prevention, maintenance, production, and quality labels you can print on tag label stock.
- **Right to Know**, with pre-designed layouts for creating U.S. Occupational Safety and Health OSHA-compliant chemical warning labels, including the entire OSHA database of chemical names and hazard information, with all relevant safety data.
- **Safety**, with pre-designed layouts for creating Caution, Notice, Danger, and other warning labels.
- **Equipment**, with pre-designed layouts for creating equipment placards, panel and switch labels, bin and shelf labels, and property or asset identification labels.
- **Warehouse**, with pre-designed layouts for creating warehouse facility labels such as shelf, rack, and bin labels, or production quality control labels.
- **WHMIS**, with pre-designed layouts for creating Workplace Hazardous Materials Information System-compliant chemical warning labels, which communicate safe-handling procedures for hazardous products in the workplace.

Note: WHMIS is available only in North American markets.

Contacting Technical Support

Please contact Brady Worldwide, Inc., with your questions or concerns. The contact support numbers for each region are listed below.

Americas

www.bradycorp.com

United States	800-643-8766	technical_support@bradycorp.com
Canada	888-262-7576	techsuppcanada@bradycorp.com
Mexico	0 1-800-112-7239	bradymexico@bradycorp.com
Brazil	55 11 3604-7700	brady_service_brazil@bradycorp.com
Other (Americas)	414-438-6868	bradyintl@bradycorp.com

Europe

www.bradyeurope.com

Austria	+49 6032 8091 800		tsbelgium@bradyeurope.com
Benelux and other European countries	+32 52 457 397 (Dutch)	+32 52 457 393 (French)	tsbelgium@bradyeurope.com
	+32 52 457 394 (English)	+32 52 457 390 (German)	
France - Signmark	+33 4 72 66 26 80		tsfrance@bradyeurope.com
Germany - Signmark	+49 6032 8091 800		tsgermany@bradyeurope.com
Italy	+39 02 96 28 60 14		tsitaly@bradyeurope.com
Spain	+33 437 245 234		tsspain@bradyeurope.com
Switzerland	+49 6032 8091 800		tsbelgium@bradyeurope.com

United Kingdom	+44 1295 228205	tsuk@bradyeurope.com
Nordic Region	+46 85 90 057 33	tssweden@bradyeurope.com
Eastern Europe	+ 36 23 42 85 26	ts_ece@bradyeurope.com

Pacific

www.bradyaust.com.au

New Zealand	0800 446 269	brady_aust@bradycorp.com
Australia	1800 644 834	brady_aust@bradycorp.com

Setting Up

This chapter tells you how to set up and maintain your label printing system. Topics are:

- ❑ **Connecting Peripherals**
- ❑ **Installing supplies**
- ❑ **Installing a compact flash memory card**
- ❑ **Cleaning your system**

If you plan to connect your printer to a desktop computer, be sure to see **Connecting to a PC** on page 11-1.

Connecting Peripherals

This section describes how to get your system connected and powered up. You should have already unpacked your printer, using the instruction sheet included in the shipping box.

You connect your keyboard and your mouse, if you have one, and then the power cord, to begin setting up your system. (The USB connection is discussed in **Placing Your System Online** on page 11-4.)




Figure 2-1. The label printer, side view.

- Step 1:** Plug the keyboard cable into the keyboard connector, shown in Figure 2-2.
- Step 2:** If you have a mouse, plug the mouse cable into the mouse connector, as shown in Figure 2-1

Step 3: Plug the power cord into the printer as shown in Figure 2-1. Plug the other end of the cord into an AC power outlet.

Important! Be sure the AC power outlet is located near the printer and is easily accessible.

Installing supplies

The next step in setting up your printer is installing a ribbon cartridge and a tape cartridge. Your system reads information stored in the memory cell located on each ribbon and tape cartridge, and uses that information when you compose a label and when you print a label.

Hint! Before composing a label, install the supplies you want to use for printing the label. You may change supplies during the label composition process, but you then may have to make length or color adjustments to your label before you can print it.

The system reads the memory cells on the cartridges every time you open and close the printer, whether you install new supplies or not, and when you print a label.

Opening the printer

- Step 1:** To open the printer, squeeze the release bar.
- Step 2:** Raise the printer cover up and away to the right.




Figure 2-2. Opening the printer.

Make sure all internal packing materials have been removed before you proceed.

Installing a ribbon cartridge




Figure 2-3. Installing a ribbon cartridge.

- Step 1:** Hold the ribbon cartridge with the open part of the tab on top and facing you.
- Step 2:** Place the lower cylinder of the cartridge (with the unused ribbon), in the lower slot in the cover, as shown.
- Step 3:** Position the upper cylinder of the cartridge in the upper slot and push gently until the tab clicks in place.
- Your ribbon is now installed.

Adjusting the ribbon cartridge

If a ribbon cartridge has been stored outside the printer, the ribbon between the take-up spool and the wiper may have been exposed to dust. The dust on the ribbon may transfer to the print head causing streaks or scratches on your labels.

When a ribbon cartridge has been stored outside the printer, before installing it, you should first advance the ribbon approximately 2 inches (or 250 millimeters) counterclockwise, as shown in Figure 2-4.




Figure 2-4. Adjusting the ribbon cartridge.

This will prevent any dust that may have accumulated on the ribbon from transferring to the print head and affecting how your labels print.

Installing a tape cartridge

There are three simple steps to installing a tape cartridge: (1) adjusting the tape cartridge receptacle to accommodate the width of the tape, (2) dropping in the cartridge, and (3) feeding the tape through the advance rollers.

Adjusting the tape receptacle

Since the printer accepts tape widths from .5 inches (25 mm) to 4 inches (102 mm), you must use the tape guides to adjust the tape receptacle inside the printer to accommodate the size of the cartridge you are installing.




Figure 2-5. Tape guide, print tape receptacle and color-coded measuring guide.




Figure 2-6. Color-coded measuring guide detail.

- Step 1:** Verify your tape's size by noting the colored label in the center of the tape cartridge's handle. **For example**, if your tape is 4", you will see a red label in the center of the tape handle. That red label corresponds to the red bar on the color-coded measuring guide (Figure 2-6).
- Step 2:** Grasp both tape guides. **Note:** Each tape guide is made up of two parts: a movable lever (1) and sliding tape guide (2) (Figure 2-5). Squeeze the movable lever and sliding tape guide together to position them.
- Step 3:** Align the tape guides to the corresponding color on the measuring guide. Be certain to also match the arrows on the tape guides with the arrows on the measuring guide to ensure the guides are aligned properly. The tape guides will lock in place. (**For example**, if your supply is 4", align both tape guides with the arrows on the red bars on each side of the measuring guide.)

Important! Be certain to center justify the guides and make sure that each guide is equidistant from the edges of the inside of the printer. This will ensure that the tape is perfectly centered when it's installed. If the guides aren't centered when you install the tape, you will get an error message saying that the tape was not properly installed.

Inserting the tape cartridge




Figure 2-7. Installing a tape cartridge.

- Step 4:** Hold the tape cartridge by the handle with the feet pointed downward and parallel with the surface the printer is sitting on, as shown in Figure 2-7. Make sure the tape extends through the slot in the cartridge.
- Step 5:** Slowly lower the tape cartridge until the tape roller cylinder ends nest in the circular slots of the tape receptacle.

Advancing the tape

Step 6: Advance the tape over the first roller with your hand as shown in Figure 2-8:





Figure 2-8. Advancing the tape.

Step 7: Place the end of the tape between the tape guides as shown above in Figure 2-8.

Step 8: Advance the tape only halfway through the guides

Step 9: Your tape is now installed.

Step 10: As you are positioning the tape, the color-coded measuring guide may become obstructed. Use the corresponding color-coded guide in the rear of the printer (see Figure 2-9 and Figure 2-10) to assist you as you position the tape.



A. Color-coded guide - rear inside view

Figure 2-9. Color-coded guide - rear inside view.



Figure 2-10. Color-coded guide - rear inside view detail.

Closing the printer cover

Close the printer cover when you are finished installing the supplies. When the cover closes, your printer reads the memory cells in the ribbon and tape cartridges, and updates the supply attributes - the color choices available, the size parameters and label lengths allowed - that will be applied to the labels you compose.

You're ready to print!




Figure 2-11. The complete label printing system, with optional mouse.

Installing a compact flash memory card

Your label printing system has a card slot you can use to attach a compact flash memory card to your system.

Memory cards provide additional storage besides your printing system's internal storage. You can save labels as files in folders to this external memory, then open them and edit or print them, and save them again.

The compact flash memory card slot is shown here




Figure 2-12. Compact flash memory card slot.

Hold the card so that the edge with the two rows of small holes is facing the card slot (with the card logo facing the front of the printer), and gently insert the card into the slot.

Note: The unit should be powered down before inserting or removing memory cards.

Cleaning your system

If you notice streaks or scratches in your labels, it may be time to clean the print head.

You can purchase a cleaning kit, which includes:

- A plastic bottle (to contain Isopropyl alcohol, minimum 90% alcohol, You must purchase the alcohol separately.)
- Two foam tip swabs

To clean the print head:

- Step 1:** Turn the printer power off.
- Step 2:** Remove the ribbon cartridge.
- Step 1:** Pour Isopropyl alcohol into the plastic squeeze bottle provided in the cleaning kit.
- Step 2:** Apply the Isopropyl alcohol to one of the swabs.
- Step 3:** Clean the print head with the wet swab, using a swiping motion across the print head. The print head is behind the ribbon cartridge, identifiable by the green horizontal line. The area to clean is the upper edge of the print head (above the green line).
- Step 4:** Repeat with a clean swab to ensure that the print head is clean.

Note: Only use a swab once per cleaning. To keep new swabs free of dust, store them in the plastic bag provided. Replacement cleaning kits are available.

If you have the Color & Cut system, you may occasionally want to clean the cutter stylus as well. For instructions for cleaning the stylus and for replacing it as well, see **Appendix B: Cutter Maintenance**.

Starting Up

This chapter provides basic reference information about your system components, how to use those components, and how to set your preferences for the system. Topics include:

- Launching Your System**
- Keyboard Basics**
- Mouse Basics**
- Checking System Status**
- Accessing Online Help**

Launching Your System

When you turn on the power for your system, a decorative screen (also called a “splash screen”) displays briefly while your system powers up.

When the system is ready to use, the **Main Menu** screen displays, providing you with a choice of buttons you use to access system functions, files you may have created, sets of pre-designed template labels, and applications designed for producing specialty labels.

The Main Menu

This is a sample **Main Menu** screen:




Figure 3-1. The Main Menu screen.

Your **Main Menu** screen may not contain all choices this one shows, or it may contain additional choices not shown in Figure 3-1, depending on the applications that have been installed in your system:



Custom, for creating and designing your own labels without using pre-designed layouts or templates. (See **Creating Custom Labels on page 6-2** for more information.)




Saved Files, for accessing stored label files you previously saved. (See **CHAPTER 9: Working with Files**, beginning on page 9-1, for more information.)



QuickText, for creating text-only labels quickly and easily. (See **Creating QuickText Labels on page 6-5** for more information.)



Pipe Marker, with pre-designed layouts for creating standard, roll-form, or symbol and arrow labels for marking pipes. (See **Creating Template Labels on page 6-11** for more information.)



Tags, with pre-designed layouts for creating hazard prevention, maintenance, production, and quality labels you can print on tag stock or adhesive-backed stock. (See **Creating Template Labels on page 6-10** for more information.)



Right to Know, with pre-designed layouts for creating U.S. Occupational Safety and Health Administration (OSHA)-compliant chemical warning labels. (See **Creating Template Labels on page 6-10** for more information.)




Safety, with pre-designed layouts for creating Caution, Notice, Danger, and other warning labels. (See **Creating Template Labels on page 6-10** for more information.)



Equipment, with pre-designed layouts for creating equipment placards, panel and switch labels, bin and shelf labels, and property or asset identification labels. (See **Creating Template Labels on page 6-10** for more information.)



Warehouse, with pre-designed layouts for creating warehouse facility labels such as shelf, rack, and bin labels, or production quality control labels. (See **Creating Template Labels on page 6-10** for more information.)




WHMIS, with pre-designed layouts for creating Workplace Hazardous Materials Information System-compliant chemical warning labels, with safe-handling procedures for hazardous products in the workplace. (See **Creating Template Labels on page 6-10** for more information.)

Note: WHMIS is available on North American systems only.



My Templates, where templates that have been downloaded, copied, or moved to a folder using the File Management Utility are stored. This option appears only if you have downloaded templates new to your system. (See **Using My Templates on page 9-12** for more information.)

The button at the bottom of the screen access system features:



Setup, which you choose to set your system preferences. (See **CHAPTER 5: Setting Preferences**, beginning on page 5-1, for instructions.)

Keyboard Basics

You use your printing system's keyboard to enter text characters on labels you create or change, and to access certain system functions available only with special function keys.

You'll find descriptions of all keyboard keys and common keyboard functions, including the familiar PC functions, the special print system functions, and common operations you perform using the keyboard, in the sections that follow.

The standard keyboard

The standard PC keyboard provided with your system is divided into four sections for purposes of description in this manual:

- System function keys unique to this printing system, page 3-5
- Alphabetic keys and functions, page 3-9
- Arrow and command keypads, page 3-11
- Numeric keypad and functions, page 3-14

System function keys

The function keys (or F keys) along the top row of the keyboard perform specific operations. The label above the F key row shows the functions available for each key. Each key has one or two functions:

- Primary function keys** are used most often, so they require a single key press to access the function.
- Secondary function keys** are used less often, so they require that you hold down the **Alt** key along with the appropriate **F** key to access the function.

Primary functions	Print	File Opt	Label Prop	Add Label	Next Label	Edit Object	Insert Object	Scale	Copy	Paste	Undo	Menu
	Cancel Print	Adv & Sheer	Clear	Edit Data		Object Prop					Status	Pref
Secondary functions												
	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12

Figure 3-2. The system function keys

Table 3-1 lists definitions of the system function keys.

TABLE 3-1. System function keys and definitions

Function	Key(s)	Description
Print	F1	Displays the Print screen.
File Options	F2	Displays the File Options screen, which provides options you use to save, retrieve, or delete files.
Label Properties	F3	Displays the Label Properties screen, which provides options you use to change default properties settings for your labels.
Add Label	F4	Creates a new label or begins the prompt sequence for creating a new label.
Next Label	F5	Displays the next label in the set. If there is no label beyond the current one, the system beeps.
Edit Object	F6	Opens the selected object for editing, displaying the screen used to create the object (text prompt, graphic selection, bar code attributes, and so on). If you have not selected an object, the system beeps.
Insert Object	F7	Displays the Insert Object screen, which you use to select the type of object to insert: text, variable text, bar code, graphic, HotShape, and so on.
Scale	F8	Displays the Scale screen, allowing you to specify a scale percentage for the select object. If no object is selected, the system beeps.
Copy	F9	Copies the selected object and makes it available for pasting into a new location, leaving the original in its current location (the standard Microsoft Windows “Copy” function). If no object is selected, the system beeps.

TABLE 3-1. System function keys and definitions (Continued)

Paste	F10	Pastes the object in memory into a new location on the label (the standard Microsoft Windows “Paste” function). If nothing has been copied into memory previously, the system beeps.
Undo	F11	Reverses the previous action. Undo affects the most recent set of editing changes to an object. If the previous action cannot be undone, the system beeps. Undoing the last several actions is possible in some cases, depending on system memory. Redoing actions is not supported.
Menu	F12	Closes the current application and displays the system’s Main Menu screen, allowing the user to select a different application without restarting the system.
Cancel Print	Alt+F1	Displays the Cancel Job screen, allowing the user to cancel a print job regardless of what is displayed on the screen.
Advance & Shear	Alt+F2	Advances the supply such that any printing currently under the print head clears the cutter and shears it from the tape. “Shear” should not be confused with the cut operation performed by the plotter cutter (cutting out shapes, label borders, etc.).
Clear	Alt+F3	Displays the Clear screen, providing options for the user to clear the current label or all labels in the current set.
Edit Data	Alt+F4	Active in the Pipe Marker and Right-to-Know specialty applications only. Provides access to the prompt screens so you can edit objects. Note: Substitutes for the Edit Object key, which is unavailable in Pipe Marker and Right-to-Know.
Previous Label	Alt+F5	Displays the previous label in the file. If there is no label prior to the current one, the system beeps.

TABLE 3-1. System function keys and definitions (Continued)

Object Properties	Alt+F6	Displays the property screen for the selected object. Use the Properties screens to set attributes, such as absolute position, rotation, special text attributes, and so on. If no object is selected, the system beeps.
Object Color	Alt+F8	Displays the Object Color screen (same effect as selecting the Color toolbar button). If no object is selected, the system beeps.
Help	Alt+F10	Displays the online help screen for the system.
Status	Alt+F11	Displays information about the current machine status, such as the OS version number and the installed supply width.
Preferences	Alt+F12	Displays the preferences screen for the application you are using when you press the Preferences key.

Alphabetic and command keys

The standard key section of the PC keyboard provided with your printing system has both alphabetic character keys and command keys.

Note: Blank keys in Figure 3-3 are not operational in this system. Grayed out keys are system function keys, described in **System function keys on page 3-5**.




Esc	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	
~ `	! 1	@ 2	# 3	\$ 4	% 5	^ 6	& 7	* 8	(9) 0	- _	+ =	Backspace
Tab	Q	W	E	R	T	Y	U	I	O	P	{ [}]	 \ _
Caps Lock	A	S	D	F	G	H	J	K	L	; ,	" '	Enter	
Shift	Z	X	C	V	B	N	M	< ,	> .	? /		Shift	
Ctrl		Alt	Space						Alt			Ctrl	

Figure 3-3. Alphabetic character and command keys

TABLE 3-2. Keyboard keys definitions.

Key	Description
Alphabetic characters	Enters lowercase character text for labels and to enter information in entry screens. Press alphabetic character keys in combination with the Shift key to produce uppercase characters.
Numeric characters	Enters numbers. Press numeric character keys in combination with the Shift key to produce symbols shown on the key face. (Alternatively, you can type numbers by pressing Num Lock on the numeric keypad and use the numeric keypad numbers. See Numeric keypad on page 3-14 for information.) Note: This procedure may differ outside North America.
Esc	Same as choosing Cancel on a system screen.

TABLE 3-2. Keyboard keys definitions. (Continued)



Tab	<ul style="list-style-type: none"> • Advances to the next option on a screen. • In the Enter Text screen, adds a tab indent in the text entry area. • Cycles through multiple objects layered on the display screen.
Caps Lock	<p>Locks on the uppercase for each alphabetic key. This function is a toggle. If Caps Lock is off, pressing the Caps Lock key turns caps lock on. Pressing it again turns it off. The Caps Lock LED indicates the current caps lock status. If Caps Lock is on, pressing Shift and an alphabetic key prints a lower case letter, just like on a computer keyboard.</p>
Shift	<p>Makes the next key pressed uppercase when Shift key is held down. With Caps Lock is on, Shift makes the next key pressed lowercase.</p> <p>When an object is selected, press Shift and an arrow key to move the object by greater increments than if you use the arrow keys alone.</p> <p>In text entry fields, press Shift in combination with the arrow keys to select characters.</p>
Ctrl	<p>Used in combination with specific alphanumeric keys, provides keyboard “shortcuts” to certain standard Windows functions, such as copying and pasting. See Shortcut keys on page 3-16 for specific details</p>
	Disabled.
	Disabled
Alt	<p>Used in combination with the system function keys to access secondary functions.</p>

TABLE 3-2. Keyboard keys definitions. (Continued)

Space	Also called Spacebar . Enters a space character or blank space the size of a single character in text entry fields. Also, with a radio button or checkbox, you can use the Space key as a toggle: if the radio button is active or the checkbox is checked, pressing Space inactivates the button or removes the check, and vice-versa.
← (Backspace)	Deletes the character to the left of the cursor. When the cursor is at the beginning of a line other than the first line of a text entry or edit field on a dialog, pressing Backspace removes the line break.
↵ Enter	Indicates the end of a line when entering text in a multi-line text field. Moves the cursor down to the beginning of the next line. On screens with entry fields, in most cases Enter is the same as selecting Next or OK , indicating that you have completed entries on the screen.

Arrow and navigation keypads

Use the arrow and navigation keypads to move around on the screen or to delete an item.

Note: Keys shown grayed out are inactive in this system.



Figure 3-4. Arrow and navigation keypads.

TABLE 3-3. Keypad keys descriptions

Key	Description
Home	Used within a text entry field to return the cursor to the left of the first character
Delete	Within an edit field on a dialog box, deletes the character at the cursor position. If the cursor is positioned at the end of a line in a multi-line text entry field, pressing the Delete key removes the line break
End	Used within a text entry field to return the cursor to the end of the text (that is, in a multi-line text entry field, the cursor is placed to the right of the last character, not at the end of a line).
↑	Moves the cursor up one line at a time in the Enter Text screen. In the Editor window, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.

TABLE 3-3. Keypad keys descriptions (Continued)

↓	Moves the cursor down one line at a time. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.
←	Moves the cursor to the left one character at a time. If the cursor is at the beginning of a line, moves it to the end of the line above. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.
→	Moves the cursor to the right one character at a time. If the cursor is at the end of a line, moves it to the beginning of the line below. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.

Numeric keypad

Use the numeric keypad as an alternate way to enter numbers and to perform several other commands as well. The LED displays above the numeric keypad light up to indicate the status of the functions named.




Figure 3-5. The numeric keypad and LED indicators.

TABLE 3-4. Numeric keypad keys definitions

Key or LED	Description
Num Lock LED	The Num Lock LED indicates the current Num Lock status. When the light is ON, the number keys are active. When the light is OFF, the command and arrow functions are active.
Caps Lock LED	When lit, indicates Caps Lock (on the keyboard) is ON, which lets you type in all uppercase (or capital) characters. When OFF, alphabetic characters are in normal, lowercase form.
Num Lock	Toggles (or turns on and off) the ability to type numbers using the numeric keypad. (Numbers on the top row of the alphabetic keyboard are always accessible.) When ON, press any key to type that number. When OFF, pressing a key results in the secondary function of that key.
/ (slash)	Types slash character. Num Lock does not affect this key.
* (asterisk)	Types asterisk character. Num Lock does not affect this key.

TABLE 3-4. Numeric keypad keys definitions (Continued)

- (hyphen or minus sign)	Types hyphen or minus sign character. Num Lock does not affect this key.
Home	With Num Lock OFF, when entering text in an entry field, returns the cursor to the beginning of the field, left of the first character. With Num Lock ON, types the number 7.
End	With Num Lock OFF, when entering text in an entry field, moves the cursor to right of the last character entered. With Num Lock ON, types the number 1.
Del	With Num Lock OFF, deletes the character at the cursor position. If the cursor is at the end of a line, deletes the line break. With Num Lock ON, types the period character.
+ (plus sign)	Types plus sign character. Num Lock does not affect this key.
Enter	Indicates the end of a line when entering text in a multi-line text field. Moves the cursor down to the beginning of the next line. Also, on screens with entry fields, Enter is the same as selecting Next or OK , indicating that you have completed entries on the screen. Num Lock does not affect this key.
↑	Moves the cursor up one line at a time in the Enter Text screen. In the Editor window, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.
↓	Moves the cursor down one line at a time. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.
←	Moves the cursor to the left one character at a time. If the cursor is at the beginning of a line, moves it to the end of the line above. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.

TABLE 3-4. Numeric keypad keys definitions (Continued)

→	Moves the cursor to the right one character at a time. If the cursor is at the end of a line, moves it to the beginning of the line below. In the Editor window and in text entry fields, use to move selected objects one character space at a time in the direction indicated by the arrow, or use with Shift held down to move selected objects at a greater increment.
---	--

Shortcut keys

In addition to the key functions listed above, the system provides some shortcut key combinations for frequently-used system function keys or key combinations. You may prefer to use these shortcut keys instead of the system function keys, especially if you are an experienced Microsoft Windows user.

Table 3-5 lists the shortcut keys and their definitions::

TABLE 3-5. Shortcut keys definitions.

Ctrl + C	The standard Windows “Copy” function, which copies the selected text or object so you can paste it in another location.
Ctrl + V	The standard Windows “Paste” function, which pastes the previously copied text or object.
Ctrl + X	The standard Windows “Cut” function, which deletes the the selected object.
Ctrl + Z	Undoes the previous action (when possible).
Shift + Arrow	Used to select text in a text entry field. Use also to reduce or add to the text already selected.

Mouse Basics

Attaching a mouse is not necessary for using this printer, but if your system is equipped with a mouse, you can use it to select items on labels, to move items on labels, to click buttons on screens, and to navigate on screens.

Using a mouse on labels

You can use any of several methods to select a text object or graphic on a label you are previewing in the **Editor** window, depending on your preference and the equipment your system offers.

To select an item on a label

Use the mouse to move the cursor to the item and click the left mouse button. The item is highlighted with selection markers to indicate that it is selected.

To select multiple items on a label

Hold down the Shift key, then click on the first item, continue to hold **Shift**, then click on the second item, and so on.

To move items on a label

Move the mouse cursor to the item, click on it to select it, and hold the left mouse button down.



The mouse cursor changes to a four-way movement cursor, which indicates that you can “drag” or move the selected object in any direction.

Release the button when finished.

Checking System Status

To check how much tape or ribbon you have left, or the color of the ribbon installed in your system, press the **Status** key (Alt+F11). The system **Status** screen, shown here, also tells you your system’s version number and current available memory.



Figure 3-6. The Status screen.

Hint! You can press the **Status** key at any time to access the system **Status** screen.

Accessing Online Help

You can get help on tasks using either of two methods:

- Press the **Help** key (**Alt + F10**) on your keyboard at any time to display a brief description of the editing tools.
- Watch the Status bar at the bottom of the **Editor** window. It displays information about the task you are currently performing.

Basic Procedures

This chapter describes the basic functions of your system and how to use them. Your familiarity with these concepts and processes will simplify your work when you create labels.

Topics include:

- Working in the Editor window**
- Working in Entry Screens**

Working in the Editor window

The **Editor** window is displayed at the beginning of the label creation process for some labels, during the process and at the end of the process for all labels, and it is displayed again when you open a saved label file for editing. You might think of it as the palette upon which your labels are created and displayed.




Figure 4-1. The Editor window with label

When you create a label, you build it by creating or adding **objects** to it. The system displays the objects in the **Editor** window in the Preview area. When objects are displayed in the Preview area, you can move them around and make changes to them. Objects can be text, graphics bar codes, and a variety of supplied designs called HotShape.

In this manual, when we describe basic processes, we'll refer to alphabetic and numeric characters as **text**, and to all other objects as **graphics**. When we discuss processes designed for specific objects, we'll specifically name those objects: for instance, **Adding bar code objects** on page 7-17, or **Formatting text objects** on page 7-6.

The sections that follow describe the elements of the **Editor** window, how to navigate inside it, and how to use its tools to perform basic editing procedures.

Inside the Editor window

Use these editing and navigation tools within the **Editor** window, shown in Figure 4-1, to create and to edit labels:

- The preview area
- The toolbar
- The rulers
- The scroll buttons
- The status bar

The preview area

When you create a label, you build it by adding objects to it. You view the objects on the **Editor** window in the **Preview area**. The system displays the objects in the **Preview area**, shown in Figure 4-1, as you work. The Preview area also reflects the size of the tape supply you have installed, and color (if you have a color display) of the tape you have in the machine.

After you add an object or change an object, the system returns you to the **Editor** window.

The Editor window toolbar



Figure 4-2. The standard Editor window toolbar

The standard **Editor** window toolbar appears at the top of the **Editor** window (shown in Figure 4-1) and contains icons (or “buttons”) that represent the tools you use to view, format, and print labels. You activate a tool using one of these methods:

- Touch it on the screen.
- Move the cursor with the mouse, then click the left mouse button.

Some tools are active at all times, such as **Zoom In** and **Zoom Out**, and others have no effect unless you have selected an object (such as **Increase Size** or **Decrease Size**) or unless you have already performed some action (such as **Undo**).

Hint! When a toolbar button is *inactive*, it is grayed out, or appears on the screen as dimmer than the others.

The **Editor** window is used for all types of labels you create, but the **Editor toolbars** vary according to which tools are appropriate for the type of label you are working with.

This is a complete list of **Editor** window tools:



Print. Follow the instructions on the Print screen to print your label. See **Printing** on page 11-1 for details.



Zoom In. Increases the magnification, making the objects on the label look larger. Does not change the actual size of the printed label, but is used as a viewing aid. See **Zooming in and zooming out** on page 4-6 for details.



Zoom Out. Decreases the magnification, making the objects on the label look smaller. Does not change the actual size of the printed label, but is used as a viewing aid. See **Zooming in and zooming out** on page 4-6 for details.



Undo. Reverses the last action you performed, when possible. When actions may not be undone, the Undo button is grayed out. See **Undoing in the Editor window** on page 4-9 for details.



Insert Object. Allows you to select the type of object you want to insert in the label, such as text, graphic, bar code, and so on. See **Adding Objects** on page 7-3 for details.



Edit Object. Allows you to edit the object selected, depending on the type of object. For example, for text, you'll see the text editing screen. For graphics, you'll see the graphics selection prompt. See **Opening and editing an object** on page 7-31 for details.



Increase Size. Increases the size of the selected text or graphic. The text or graphic remains in its original proportions, but displays and will print 10% larger for each time you press the Increase Size button. See **Using Increase Size and Decrease Size** on page 7-28 for details.



Decrease Size. Decreases the size of the selected text or graphic. The text or graphic remains in its original proportions, but displays and will print 10% smaller for each time you press the Decrease Size button. See **Using Increase Size and Decrease Size** on page 7-28 for details.



Properties Menu. Displays different options that apply to the object selected including: Color, Object Properties, Move to Back, and Move to Front.



Color. Lets you choose color for the selected object or change the default color the system uses for drawing new objects. See See **CHAPTER 8: Applying Color**, beginning on page 8-1 for details.



Object Properties. Lists information about the object selected, which can be either text or graphic, including height, width, rotation, and so on. This button is valid only when a single object is selected. See **Changing object properties** on page 7-32 for details.



Move to Back. Moves the selected object to the back of any layered objects, so that the other objects obscure or cover up the selected object.



Move to Front. Moves the selected object to the front of any layered objects, so that the selected object obscures or covers up any objects behind it.



Exit. Returns to the Main Launcher screen.

Scrolling functions

Use the **scroll buttons** (shown in Figure 4-1) to move the view shown on the screen to the left or right, and up or down.

If the entire label is already visible in the viewing area of your screen, scrolling has no effect. But if you have chosen a zoom level that results in your label exceeding the size of the preview window, you'll find the scroll buttons useful.



Press the **left scroll button** to shift the view toward the right edge of the label.



Press the **right scroll button** to shift the view toward the left edge of the label.



Press the **down scroll button** to shift the view toward the bottom edge of the label.



Press the **up scroll button** to shift the view toward the top edge of the label.

To continue scrolling in the direction indicated

- Press and hold the scroll button.
- With the mouse, click on the appropriate scroll button, and hold down the left mouse button to continue to scroll.

Ruler functions

The horizontal and vertical rulers in the **Editor** window preview area (shown in Figure 4-1) use the same scale. This means that each increment on the horizontal ruler equals the same increment on the vertical ruler.


Zooming in and zooming out

Magnification changes by 25% each time you use a **Zoom** tool. As you use the **Zoom In** or **Zoom Out** tools to change the view of your label in the preview area, the numeric values shown on the rulers are increased or decreased accordingly.

Note: Zooming does not change the actual size of your label or the size of your label objects. It only affects your view.



As the view zooms in, the magnification level increases, which means that less of the label is visible, and the tick marks on the rulers appear to be farther apart:



Hint! **Zoom in** to make your label display appear less cluttered and easier to work with.



As the view zooms out, the magnification level decreases, which means that more of the label is visible, and the tick marks on the rulers appear closer together:



Hint! Here's a quick way to zoom in or out by 100%:
Hold down **Shift**, then press **Zoom in** or **Zoom out**.

The status bar

The status bar displays a system message related to the task you are performing. Sometimes the messages are instructive, as in Figure 4-1, which tells you how to proceed to create your label. In some instances, such as when you are working with sequence labels, the number of the label displayed is shown: for instance, Label 1 of 3, Label 2 of 3, and so on.

Editing procedures

Selecting in the Editor window

Before you can use many of the tools and features shown on the **Editor** window to format a label, you must **select** the part of the label shown in the preview area of the **Editor** window that you want to work on.

When you select an object, small squares or **selection markers** appear at the corners and midpoints of the sides of a dotted-line box around the object. The

dotted lines disappear, but the markers always indicate that you have successfully selected the object, as shown here:




Figure 4-3. The Editor window with a graphic selected.

For instance, if you want to enlarge the coffee cup graphic in the label in Figure 4-3, you first select the graphic on the label using one of the methods described below, then choose the **Increase Size** tool.

You can use either of the methods below to select an object in the Preview area on the **Editor** window, depending on your preference and the equipment your system offers:

- Touch the object you want to select. Selection markers appear around the object, indicating that it is selected.
- Using the mouse, move the cursor to the object and click the left mouse button. The object is highlighted to indicate that it is selected.

The changes you make will apply only to the object you have selected.

Hint! When your label contains multiple objects, if any object is selected, you can press <Tab> to cycle through the objects on the screen.

Selecting multiple objects

To select multiple objects on a label, hold down the **Shift** key, then use either of the methods described above.

Deselecting in the Editor window

You can deselect an object after you perform an action on a selected object, or if you change your mind before you make changes to the selected item.

To remove the selection markers, touch any non-highlighted area of the screen. If you are using a mouse, move the cursor to a non-highlighted area and click the left mouse button to deselect.

Undoing in the Editor window



You can use this tool to reverse or **undo** your most recent action in the **Editor** window:

The **Undo** icon is not valid at all times, however, as some formatting actions cannot be undone. When **Undo** is not possible, this icon will be grayed out (or appear to be dimmer) on the toolbar.

Working in Entry Screens

Entry screens are screens upon which you enter the parts that make up your label and in which you enter information about the design of your label. You enter label text and information about your label by using:

- Text entry areas
- Entry fields
- Buttons
- Checkboxes
- Radio buttons
- Size adjustment buttons

Screens usually contain one or more of these information entry devices, as shown in Figure 4-6 on page 4-12 and Figure 4-7 on page 4-13.

Some screens may show options or areas as dimmed, or grayed out. This indicates that particular option is *disabled*, or not available on your system or in the context in which you are operating.

Navigating in entry screens

You can move around inside entry screens by touch, keyboard, or mouse:

By touch: Simply touch the part of the screen you want to activate.

By keyboard: Press **Tab** to move between options or fields.

By mouse: Use the mouse to move the cursor to an option or field. Click the left mouse button to choose the option or field.

Tabbed entry screens

Some entry screens contain additional tabbed screens with related options. Select the tab to get to its options. Touch the scroll arrows to scroll to any additional tab screens.




Figure 4-4. The Text Properties screen with tabs.

Entering information in entry screens

You construct your label text in a text entry area on the **Enter Text** screen, as shown here:




Figure 4-5. The Enter Text screen.

You can get to the **Enter Text** screen by pressing <Insert Object> on the keyboard, then selecting **Text** from the **Insert Object** screen. (See **Adding Objects** on page 7-3.)

To enter text in a text entry area, type the characters on your keyboard. To start a new line, press <Enter>.

Typing uppercase

To type text in UPPERCASE (or capital) letters, press the <Caps Lock> key. To turn off uppercase, press <Cap Locks> again.

To capitalize a single character, hold down **Shift** and press the key.

Typing special characters

You can insert accented characters, subscripts, and other special characters that do not appear on your keyboard on your labels by choosing the **Special** button on the **Enter Text** screen. The **Special Characters** screen lets you enter codes that automatically place the special character at the insertion point in your text entry area. See **Adding special characters to text** on page 7-8 for detailed information.

Choosing options

You enter your option choices on entry screens via entry fields, option buttons, checkboxes, and other devices, described below.

Using entry fields

You type information directly into **entry fields**. Some entry fields are ready for your entry as soon as you navigate to them, while others are associated with other screen elements.

The **File name** field on the **Save File** screen is an example of an entry field ready to accept your typed text:




Figure 4-6. The Save File entry screen.

An example of another type of entry field is the **Labels from** field in Figure 4-7 on page 4-13. In this field, you enter the beginning and end number for the range of labels you want to print. This type of entry field is activated only when

you choose the attached radio button. (See **Using radio buttons** on page 4-15 for more information.)




Figure 4-7. The Advanced print entry screen.

Using option buttons

Touch an option button to implement the command or function listed on the button. For instance, in Figure 4-7, the **File Group** button is disabled, but when it is active it takes you to the **File Group** screen, where you choose a File Group to print. The **Cancel** button cancels any entries you made on the **Advanced Print** screen, and returns you to a previous screen.

Using option lists

Some fields provide lists of options from which you can choose, such as the **Density** fields on the screen shown here:




Figure 4-8. The Bar Code screen, Dimensions Tab.



To select from an option list, touch the down arrow next to the field to see the list of options. Then select an item on the list.

Using scroll lists

Figure 4-6 on page 4-12 shows an example of a scroll list. Scroll lists contain lists of items for you to choose from. To make your choice, you can move up and down the list using the scroll buttons, which are also shown in Figure 4-6. When you find the item you want, touch or select it to choose it.

Hint! The scroll buttons duplicate the function of the up and down arrow keys.

Using checkboxes

Checkboxes with checkmarks inside indicate that an option is enabled. Empty checkboxes indicate the option is not enabled. Figure 4-7 shows an example of a checkbox.

To indicate your choice in a checkbox, touch the checkbox or click on it with the mouse.

For example, in Figure 4-7, check the **Print Files in Group** option checkbox to indicate that you want to print a group of files all at once. Leaving it unchecked indicates that you accept the default status, which is printing a single file.


Using radio buttons

Radio buttons are empty circles when not in use, and circles with dots inside when activated. Figure 4-7 shows examples of radio buttons.

If there are one or more radio button options on a screen, you can activate only one option at a time.

To choose a radio button option, touch the circle or move the cursor to it and press **Enter**, or use the mouse to move the cursor to it and click the left mouse button.

Using size adjustment buttons



These adjustment devices appear in various places in the system (for example, on the **Font** screen shown in Figure 7-4 on page 7-7), where you need to increase or decrease dimension or magnitude.

Touch + to increase the dimension or magnitude.

Touch - to decrease the dimension or magnitude.

Exiting entry screens

You can always choose to save or to cancel your entries on an entry screen.

To exit an entry screen and save your entries

Press or choose **OK** or **Next**.

- The **OK** button may be at the top right of the entry screen, as shown in Figure 4-8, or it may be a full-sized button near the bottom of the screen, as shown in Figure 4-7.
- **Next** takes you to the next screen you need to complete in the process.

To exit an entry screen without saving your entries

Use one of these methods:

- Press or choose the **X** button, as shown in Figure 4-8.
- Press or choose **Cancel**, as shown in Figure 4-7.
- Press **Esc**. You can also use the **Back** button when present to return to the previous screen. **Back** does not save your information.

Setting Preferences

Your label printing system ships with pre-set settings called *default* system settings. You can customize your system settings to reflect your own preferences.


This chapter tells you how to change system settings. Topics include:

- Accessing System Setup**
- Setting Printing Tab Options**
- Setting Localization Tab Options**
- Setting Hardware Tab Options**
- Setting Other Tab Options**
- Setting Text Tab Options**
- Setting On Line Tab Options**

Accessing System Setup

When you change the pre-set system settings your system shipped with, you change the default values your system uses to determine how your printer works. The changes you make in the System Setup screens apply to your entire system.

Note: Be cautious about changing system settings. Remember that changes you make will apply to your entire printing system.

-  To cancel changes and return to the default settings, touch or click the **Cancel** button, shown at the left, while displaying any of the system preference option tabs. Or press <Cancel> on your keyboard.

To access the System Setup settings options

1. Choose the **Setup** button on the **Main Menu** screen (shown in Figure 3-1 on page 3-2).

You'll see the **System Setup** screen, shown here:




Figure 5-1. The System Setup screen.

The **System Setup** screen has as many as six tabs with options. Five tabs are visible at one time on the screen. You may see fewer tabs at times, depending on where you are in the system.

The **System Setup** tabs are:

- Printing
- Localization
- Hardware
- Other
- Text
- On Line



The **Tab arrows** indicate the presence or absence of additional tabs. In Figure 5-1, for instance, the **Tab arrows** indicate that there are additional tabs to be seen when you choose the right Tab arrow, but not if you select the left Tab arrow.

2. Choose a tab to set those options.

You'll find information about setting the tab options in the sections that follow.

3. Use the two buttons at the top right corner of the screen to:



Save the changes you made.



Return to the **Main Menu** screen or to the **Editor** window in some cases, without saving changes.

Setting Printing Tab Options

The **Printing** options tab is shown in Figure 5-1. You specify your system's print job defaults on this tab. The options are:

Supply saver	<p>Turns basic multiple-up printing ON or OFF. The default setting is OFF. The Supply saver printing feature saves supplies by arranging labels of the same size together in the print queue. This saves tape because it stacks labels that are smaller than the full width of the tape so that the full width of the tape is used, and it saves ribbon because it groups labels to print within a set of ribbon panels. (The sample in Figure 11-10 on page 11-20 illustrates a print job with five separate labels that have been stacked by supply saver.)</p> <p>In addition, if you have the Color & Cut system, when Supply saver is ON, your system cuts out each label individually. See Checking Supplies on page 12-10.</p>
Recalibrate Columns during Cutting	<p>Applicable only when cutting out multiple labels using the Supply saver option. If you select Recalibrate Columns during Cutting, the printer rewinds the tape to the leading edge after each column of labels is cut out, making the cut output more accurate.</p> <p>If Supply saver is not selected, this option is not available.</p>

Overprint	<p>Turns overprinting ON and OFF. OFF is the default. Overprint controls the order in which colors are printed on the label so that black prints last.</p> <ul style="list-style-type: none"> • With Overprint ON, black prints over (on top of) any previously printed colors. This ensures that there will be no gaps between colors and black print areas. However, with Overprint ON, printing may be slower, because the system must analyze the colors in the print job and order them accordingly. You may have to swap ribbons more often as well. • With Overprint OFF, areas of colors that will print behind black are removed before black is printed. However, you may see a slight gap between the color areas and the black areas.
Print Label Boundary	Indicates the edge of the label.
Auto Cut Between Labels	<p>Lets you turn off the automatic shear between labels for monochrome print jobs. When selected, the printer does not shear between labels, letting you keep the output together on the roll for use in another location.</p> <p>Labels are sheared after 120” of printing (since that is the maximum monochrome print length supported), and at the end of the print job, even if Auto Cut Between Labels is OFF.</p> <p>Note: When Auto Cut Between Labels is OFF, the output length of each label may shift from the true defined label length because the system does not continually find the front edge of the tape as the labels are output. This should not be an issue for die-cut monochrome jobs because the die-cut positioning routine in the firmware registers the position of each label.</p> <p>The Auto Cut Between Labels option is not used for multi-pass print jobs, cut jobs, or when printing to notched continuous supplies.</p>

For more information about printing options, see **Printing Tab Options** on page 11-19.

Setting Localization Tab Options

Use the options on the **Localization** tab to set your system's text language, keyboard language, and the unit of measure used in determining the size of your labels:




Figure 5-2. The System Setup Localization tab.

Note: You must restart your system before **Localization** preferences that you set take effect. After you make Localization option changes, choose **OK**, then when the **Main Menu** screen displays again, turn your printer OFF and ON again.

The options are:

Language	Sets the language the system uses for the screens, prompts, and messages. Language options available depend on your system: <ul style="list-style-type: none">• North American: English (default), French, Spanish• Europe I: English (default), German, French, Dutch• Europe II: Spanish (default), Italian, Portuguese, English• Europe III: Danish (default), Finnish, Norwegian, Swedish
Unit of measure	Sets the unit of measure used in the system for displaying label length, label width, and so on. Options are: <ul style="list-style-type: none">• Inches• Millimeters The default unit of measure varies by country.
Keyboard language	Sets the language for your system keyboard. Available languages are: <ul style="list-style-type: none">• English - United Kingdom• English - United States• French• German• Spanish• Italian• Norwegian The default language varies by country.

Setting Hardware Tab Options

Use the **Hardware** options tab for settings that affect your system's hardware.




Figure 5-3. The System Setup Hardware tab.

The options are:

Speaker volume (0-5)	Controls the volume of your system sounds. Enter a value from 0-5, where 0 turns your sound off completely.
Check Supply Colors	When enabled, tells your system to read the current supply cell. If there are any missing color names, the system prompts you to supply them. See Naming supply colors on page 5-9 for instructions.

<p>Cutter Calibration: Horizontal (x) Vertical (y)</p>	<p>Color & Cut system only. Re-sets the factory-set calibration values for the plotter cutter in your system. Enter positive or negative whole numbers to adjust the horizontal or vertical values by one/one thousandth of an inch for each increment.</p> <p>Note: Use caution when calibrating your plotter cutter. To return to the factory-set values, see the calibration label placed inside your printer at the factory, and reinstate the values shown on that label.</p> <p>See Calibrating the Cutter on page 10-11 for more information.</p>
---	---

Naming supply colors

When new tape or ribbon supplies become available after your print system is shipped to you, your system will not have internal information about those new supplies. The **Check Supply Colors** button lets you supply the names of new supplies and store them in your system.

To supply names for new ribbons or tapes

1. Install the new tape or ribbon in your system.
2. Choose the **Check Supply Colors** button on the **Hardware** options tab.

The **Check Supply Colors** screen displays:




Figure 5-4. The Check Supply Colors screen.

3. Enter a name for the color, up to 32 characters in length. Be sure the name is not already in use in your system.
4. If you change your mind or make a mistake, press **Cancel**. To save the name you typed, choose **OK**
5. If the system detects additional missing color names, it prompts you again with the **Check Supply Color** screen, and repeats the process until you have supplied names for all new colors.

When all colors are named, the system displays a message.

Setting Other Tab Options

Set default grid preferences and line width using the **Other** tab, shown here:




Figure 5-5. The System Setup Other tab.

The **Other** tab options are:

Snap to grid	Check this option to make new objects or objects that you are re-positioning <i>automatically</i> move to vertical and horizontal alignment on the grid. This option is OFF by default. Hint! Snap to grid helps you align objects precisely.
Display grid	Check this to turn the grid lines ON in your display screen. This option is OFF by default. See Displaying the screen grid on page 5-11 for more information. Hint! Display the grid to help position objects precisely on your labels.
Line Width	Specifies the default line width value for HotShape objects and label frames. Higher numbers indicate wider lines. The sample line next to this field displays the line width as you set it.

Displaying the screen grid

The screen grid is the pattern or structure that underlies your labels. It consists of invisible horizontal and vertical lines of dots, arranged like a graph paper pattern. The grid is not visible to you by default, but you can choose to display it.

Hint! Displaying the grid can help you set objects in precise locations on your labels, such as when you want to line up several objects, or when you must place an object in an exact location on your label.

This is a sample screen with the **Display grid** option turned on:




Figure 5-6. The Editor window with grid enabled.

Setting Text Tab Options

Set the default text preferences for your system by using the options on the **Text** tab.




Figure 5-7. The System Setup screen Text tab.

Note: **Text** tab option changes affect only **new** text objects you create. These settings do not affect objects provided by templates or QuickText labels.

The options are:

Units	Sets the unit of measure used for the type on your labels as: <ul style="list-style-type: none">• Points• Inches• mm (Millimeters) The default setting varies by country.
Font	Sets the default font style. Pull down the list and select a font style. The factory-installed fonts are: <ul style="list-style-type: none">• Arial 65 for BRC• Arial for BRC (default)• Brush Script for BRC• Tahoma• Times New Roman for BRC Your system may offer additional fonts installed by your organization.
Type Size	Sets the default type size. Enter the size you want to use as the default. Note that the system default size of 24 points is based on the largest type size that will fit on the smallest tape width (.5 inch). Hint! If you are working exclusively with a certain tape supply, you may find it useful to set the Type Size default setting to one appropriate for that tape width.

Free Form Text Object	<p>Sets the default for any new free form text object you create.</p> <p>Note: To change this setting for an individual text object, go to the Options tab on the object Text Properties screen. See Setting options on the Options tab on page 7-40 for details. Changing this setting on the Options tab will not affect the setting you have selected here.</p>
Text Object With Boundaries	<p>Sets the default for any new text object with boundaries you create.</p> <p>Note: To change this setting for an individual text object, go to the Options tab on the object Text Properties screen. See Setting options on the Options tab on page 7-40 for details. Changing this setting on the Options tab will not affect the setting you have selected here.</p>
Auto Size Font	<p>Available only when a Text Object With Boundaries is selected. Sets the default point size of text to fit within the text object.</p> <p>Note: To change this setting for an individual text object, go to the Options tab on the object Text Properties screen. See Setting options on the Options tab on page 7-40 for details. Changing this setting on the Options tab will not affect the setting you have selected here.</p>
Justification	<p>Sets the alignment that will be the default for labels with a single line or with multiple lines within a single text object.</p> <ul style="list-style-type: none"> • Left aligns the text so that each line starts on the left side of the text object. • Center aligns the text so that each line is centered on the text object (default). • Right aligns the text so that each line ends against the right side of the text object.

Setting On Line Tab Options

Set the default PC connection type settings for your system by using the **On Line** tab option:




Figure 5-8. The System Setup screen On Line tab

The **Connection Type** option sets the port type to be used when connecting to a PC. Choose **USB** or **Serial**.

Working with Labels

Working with labels is what your printing system and this manual is really all about. This chapter describes the most important part of that process: how to create labels.

You'll learn how to use the applications this system offers on the Main Menu to create all kinds of labels. You'll also learn how to change the physical properties of your labels, and how to create and use sets of multiple labels to your advantage.

The topics in this chapter are:

- Creating Custom Labels**
- Creating QuickText Labels.**
- Creating Template Labels.**
- Creating Sets of Labels**
- Changing Labels**
- Setting Application Preferences**

Creating Custom Labels

This procedure shows you how to use the Custom application to create labels that you design, without using pre-designed layouts.

You will find information about using pre-designed layouts, called *templates*, in **Creating Template Labels** on page 6-10.

To create a Custom label

1. From the **Main Menu** screen, as shown here, choose **Custom**.



Figure 6-1. The Main Menu screen

2. On the **Custom** screen, shown here, choose **Create New Label**:




Figure 6-2. The Custom screen.

You'll see the **Editor** window:




Figure 6-3. The Editor window.

The **Editor** window is ready to display the label as you create it.

Hint! The most typical next step in creating a label would be to add an object. See *Working with Objects* for instructions.

At this point, the system operates with these defaults:

- The blank label displayed reflects the size and color of the tape installed. If no supply is installed when you launch **Custom**, the system assumes you are using a white, 4-inch (102 mm) wide tape.
- The ribbon installed in your printer determines your color choices for the objects you insert on your labels. If no ribbon is installed, the system assumes a black continuous ribbon. See **About Color** on page 8-2 for more information.

Hint! For best print results and greatest ease-of-use, before you create a label, install the supplies you want to use to print it. The system then automatically adjusts label length and offers you the appropriate color choices.

- The blank label displays with landscape print orientation assumed.
- The magnification (or zoom level) is set to display 12 inches of label length, but this does not reflect the actual printable length of the label. The objects you add to the label determine the final length of the label, or, if you have a paneled ribbon installed, the length of the panel determines the maximum length of the label. See **Checking Length** on page 11-12 for more information.

Hint! To control the length of your label, set the length before adding objects. Use the **Set Length** option on the **Size** tab of the **Label Properties** screen.

From inside the **Editor** window, you can:

- Add text, graphics, HotShapes, or bar codes to your label. See **Working with Objectsn page 7-1** for instructions.
- Edit or change the properties of the objects you added to your label. See **Changing Objectsn page 7-31** for instructions.
- Print your completed label. See **Printingn page 11-1**.
- Save your label as a file so you can access it later. See **Working with Files** on page 9-1 for instructions.

Hint! Be sure to browse through the standardized label designs, called *templates*, on your system. You may find a pre-designed label that meets your needs. See **Creating Template Labelsn page 6-10** for information about these easy-to-create labels.

Also see **Inside the Editor windown page 4-3** for more information about working in the **Editor** window.

Creating QuickText Labels

QuickText helps you create plain text labels very quickly. When you choose **QuickText** on the **Main Menu** screen (Figure 6-1), all you have to do to create a label is enter your text.

QuickText supports only a single text object on a single label. The system automatically creates the text object when you type the text.

The system automatically:

- Sizes the printable area equal to the tape you have installed.
- Determines the text color by the installed ribbon. You may not use the Reverse text color option (described in **Setting options on the Options tabn page 7-40**).
- Sizes the text you type to fit the width of the label.
- Determines the label length based on the text you enter. You may not change the length.
- Assumes the print orientation.
- Displays the entire label for you to print or edit.
- Sets the label for printing only. If you have the Color & Cut system, you may not use the Cut feature with a QuickText label.
- If no tape or ribbon is installed, assumes you are using the default supplies: a white four-inch tape and a black ribbon.

See **About Objectsn page 7-2** for definitions and descriptions of objects.

Note: **QuickText** is designed for printing simple labels only, and does not support some of the features this printing system offers. If you anticipate adding objects like graphics or HotShapes to your label, build it using the Custom application, as described in **Creating Custom Labelsn page 6-2**.

To create a QuickText label

1. Choose **QuickText** from the **Main Menu** screen (Figure 6-1).

You'll see the **Enter Text** screen:




Figure 6-4. The QuickText Enter Text screen.

2. Follow the on-screen instructions and type your text. You can change the font or add special characters at any time on this screen, but you cannot change the **Type size** on this screen. This is because after you type your text, the system automatically calculates a type size for you, based on the number of lines you typed and the width of the installed tape.
3. When the text is complete, select **OK**. (If you select **Cancel** at this point, the text you entered is erased and you'll be returned to the **Main Menu** screen.)

QuickText formats your label and displays it on the QuickText version of the **Editor** window: [




Figure 6-5. The QuickText Editor window.

Once the label shows in the **Editor** window, you can either print it as is, or edit the text. (See **Opening and editing an object page 7-31** for instructions for editing text objects.)

Note: You may not use **Object Properties** to change the text object in QuickText labels.

You can save **QuickText** labels as files, and you can retrieve them, just as you save and retrieve other labels in this system. See **Saving Labels as Files page 9-3** for more information.

QuickText toolbar functions

QuickText offers a subset of the tools you normally see on the **Editor** window toolbar (shown in Figure 6-5). Use the QuickText tools to perform these functions:



Print. Prints the label. Choose and then follow the instructions on the **Print** screen. Advanced functions are not available in **QuickText**. See **Printing page 11-1** for details.



Zoom In. Increases the magnification, making the objects on the label look larger. Does not change the actual size of the printed label, but is used as a viewing aid. See **Zooming in and zooming outn page 4-6** for details.



Zoom Out. Decreases the magnification, making the objects on the label look smaller. Does not change the actual size of the printed label, but is used as a viewing aid. See **Zooming in and zooming outn page 4-6** for details.



Undo. Reverses the last action you performed, when possible. When actions may not be undone, the Undo button is grayed out.



Insert Object. Allows you to select the type of object you want to insert in the label, such as text, graphic, bar code, and so on. See **Adding Objectsn page 7-3** for details.



Edit Object. Allows you to edit the object selected, depending on the type of object. For example, for text, you'll see the text editing screen. For graphics, you'll see the graphics selection prompt. See **Opening and editing an objectn page 7-31** for details.



Increase Size. Increases the size of the selected text or graphic. The text or graphic remains in its original proportions, but displays and will print 10% larger for each time you press the Increase Size button. See **Using Increase Size and Decrease Sizen page 7-28** for details



Decrease Size. Decreases the size of the selected text or graphic. The text or graphic remains in its original proportions, but displays and will print 10% smaller for each time you press the Increase Size button. See **Using Increase Size and Decrease Sizen page 7-28** for details.



Properties Menu. Displays different options that apply to the object selected including: Color, Object Properties, Move to Back, and Move to Front.



Color. Lets you choose color for the selected object or change the default color the system uses for drawing new objects. See **CHAPTER 8: Applying Color**, beginning on page 8-1 for details.



Object Properties. Lists information about the object selected, which can be either text or graphic, including height, width, rotation, and so on. This button is valid only when a single object is selected. See **Changing object propertiessn page 7-32** for details.



Move to Back. Moves the selected object to the back of any layered objects, so that the other objects obscure or cover up the selected object.



Move to Front. Moves the selected object to the front of any layered objects, so that the selected object obscures or covers up any objects behind it.



Exit. Returns to the Main Launcher screen.

Hint! Press **Shift** along with **Decrease type size** or **Increase type size** to change the type size in larger increments.

QuickText key functions

Not all system function keys are operative in the QuickText application, either because the functions are irrelevant, or because of limitations on the design and functions of QuickText labels.

Available key functions are:

- **Advance & Shear**
- **Edit Data** (edits text object)
- **Help**
- **Status**
- **Clear**
- **Undo**
- **Edit Object** (edits text object)
- **Object Color**
- **Menu**
- **File Options**
- **Print** (not including Advanced features)

See **System function keysn page 3-5** for more information about the key functions.

Creating Template Labels

Your label printing system provides many *templates* you'll find useful for creating standardized labels. Templates are pre-designed specialty layouts you use to set up and format a standard label.

Creating labels using these layouts is particularly easy. Once you have chosen a label group, which is called an *application*, (shown in **Choosing a label applicationn page 6-11**) and the template category (shown in **Choosing a categoryn page 6-12**) for the label you want to create, you simply respond to the on-screen prompts the system displays as it takes you through choosing graphics, adding text, setting dimensions, or a combination of all of these processes.

The basic process for creating labels using templates is very similar for all applications and templates:

- Step 1:** You choose a label application.
- Step 2:** You choose a category.
- Step 3:** You choose a template from the category.
- Step 4:** You respond to prompts that add text or graphic objects to the label as the template requires. The prompts are numbered so you can track your progress as you go through the process.
- Step 5:** You print or save your label.

Some label types require more steps and involve more prompt screens than others, but the general process is comparable.

The following sections take you through a generic example, to give you a basic understanding of the process.

Note: You'll be able to edit some of the objects on some of the templates to meet your own label requirements. Some objects and some templates are designed to meet established stock or regulatory requirements, however, and may not be edited.

Pipe Marker and Right-to-Know exceptions

The Pipe Marker and Right-to-Know applications contain highly specialized templates created for special situations. Most of you who use these applications are already familiar with the standards and requirements for these types of labels.

When you create Pipe Marker and Right-to-Know labels, you follow the general steps listed above, but you will encounter more exceptions to the generic examples with these applications than with other applications.

For the most part, you will be able to create Pipe Marker and Right-to-Know labels easily by simply following the prompts on the display screen. When the exceptions to this process are significant, we'll provide special instructions. Watch for this designation:

Exception: This note contains special information about the Pipe Marker or Right-to-Know applications.

Choosing a label application

The templates are organized in groups of similar designs, called applications, which are listed on the system's **Main Menu** screen (as seen in Figure 6-1 on page 6-2). With the exception of the Custom application and the QuickText application, each application contains one or more categories of pre-designed templates, and are referred to as *template-based applications*.

All template-based applications use pre-designed layouts supplied with your system. (See **The Main Menu page 3-2** for full descriptions of all applications.)

Hint! You can set default application preferences (similar to system settings) for each application, though the settings you may change vary according to the application. See **Setting Application Preferencesn page 6-33**.

To choose an application

1. On the **Main Menu** screen (Figure 6-1), select the application for the label you want to create.

You'll see a version of the Create or Open screen, such as the Safety application version shown here:




Figure 6-6. The Create or Open screen, Safety application.

You'll encounter a version of this screen every time you start an application. The screen title varies according to the application chosen, but the options are the same each time you create a new label.

2. Choose **Create New Label**. Next, you'll be prompted to choose a template category.

Choosing a category

Each application offers a choice of categories as the first step in creating a label. The categories listed on the template categories screens each offer a group of related templates.

The **Template Categories** screen is very similar for most applications, but the list of categories varies:.




Figure 6-7. The Template Categories screen, Tags application.

Exception: Pipe Marker next lists *styles* on the **Pipe Marker Style** screen. Right-to-Know next lists *formats* on the **Right-To-Know Format** screen.

Both **Pipe Marker** and **Right-to-Know** also provide the **Preferences** option on these screens. See **Setting Application Preferencesn page 6-33** for information.

To choose a template category

1. On the **Template Categories** (or similar) screen, choose a category from the list.
2. Choose **Next** to proceed to the next prompt screen.

For most applications, next you'll see the **Select Template** screen.

Selecting a template

Exception: In Pipe Marker and Right-to-Know skip this step and proceed directly to prompting you for setting label dimensions. You select a template on a previous screen.

Each template listed on the **Select Template** screen represents a pre-designed layout.




Figure 6-8. The Select Template screen

The content of the **Select Template** screen depends on the type of label you are creating.

- The **Category** field reflects the category chosen in the previous screen.
- The **Label size** field displays the default size for the template currently highlighted. This reflects the total output size of the final label, with no changes applied. The label size is determined by the template you select, however. For instance, for a *scalable-label* template, the Label size field is determined in part by the installed tape size -- the template sets the label to be sized as large as will fit on the installed tape. Some templates call for *preset-size labels*, and some templates produce a *fixed-size label* only. In both cases, you may not change the label size. In those cases, the **Change Size** button is grayed out on the **Select Template** screen.

Hint! Some preset labels may also be set to turn on the Supply saver option for printing. See **Supply saver optionn page 11-21** for information.

- The **Change Size** button may or may not be enabled, according to the template chosen.
- The list of templates provides a miniature graphic representation (called a “thumbnail”) for the highlighted template. This feature may help you choose the appropriate template for your purpose. In the template shown in Figure 6-8,

for instance, you'll be prompted to add a graphic sign header (or *signal word*) to the top part of the label, and a text object to the bottom part. Using the template shown in Figure 6-8 above, you could create a label that looks like this:




Figure 6-9. Sample Signal Word label.

To select a template

1. Choose a template from the template list by highlighting it.
2. Next, you have two choices:
 - Click **Next** for the next prompt in the sequence, and go to the **Following prompt sequences** section below for further instructions.
or
 - Choose **Change Size** to change the label size, as described in the **Changing Labels** page 6-24.

Following prompt sequences

Each label type that uses pre-designed layouts has *prompt sequences* unique to its type. These prompts are designed specifically to help you create the content of your label.

Depending on the application and template you are using and the label you are creating, you may be prompted for one or more of the items listed below. You may even be prompted for multiple instances of the same one of these items:

- Text entries
- Text list entries
- Graphic objects
- Bar codes

Exception: See **Responding to Pipe Marker promptsn page 6-19** and **Responding to Right-to-Know promptsn page 6-20** for other prompt screens you may encounter when working with the Pipe Marker and Right-to-Know applications.

During the prompt sequence, you may have these options:

- **Back** to go back to the previous screen
- **Back to Launcher** to return to the **Main Menu** screen.
- **Cancel** to interrupt the prompt sequence. You'll see the label in the **Editor** window. None of your prompt responses are saved.
- **Next** to proceed to the next prompt.
- **Finish** on the final prompt screen in the sequence. When you choose **Finish**, the label you created is displayed in its final form in the **Editor** window.

Hint! If you want to go back and rerun an entire prompt sequence to edit the data you entered, use the <**Edit Data**> key. See **Changing Labelsn page 6-24** for complete information.

Since you will be prompted for information each step of the way, we're confident that you'll find each process simple and straightforward. To help accustom you to the process, however, the sections that follow take you through some generic prompt sequences.

Responding to text prompts

Figure 6-10 shows a generic version of a text prompt screen:




Figure 6-10. A text prompt screen.

You'll see a similar text entry prompt screen when you are working with a template that requires you to enter your own text. (You see a similar text entry screen when you create a text object using the Custom application and when you create a QuickText label.)

Some templates require that you enter specific text: for example, the prompt may instruct you to "Enter product identifier" or to "Enter risk phrases."

Note: Space limitations make it unable to document all possible responses to these prompts. If you are using templates with this kind of specialized request, we assume you understand the requirements.

Complete this screen as you would any text entry area, by typing in the appropriate text. (See **Adding and formatting text objects** on page 7-4 for complete instructions.)

Responding to pick list prompts

When the template you are using calls for a certain type of word or phrase, you may see a pick list prompt screen from which you can choose the appropriate word or phrase:




Figure 6-11. A pick list prompt screen.

You can choose text and you can also go on to create your own word or phrase from this screen. When you choose **Next**, you have the option to enter your own text phrases.

Responding to graphics prompts

Figure 6-12 shows a graphics prompt. For this template sequence, you are being prompted to choose a HazMat graphic:




Figure 6-12. A graphics prompt screen.

Complete this screen by choosing a graphic from the thumbnails displayed. You can also:

- Use the scroll arrow keys to view additional thumbnails.
- Use the **Change Category** option to go to the **Graphic Categories** screen (for an example, see Figure 7-14 on page 7-22), where you can open another category and see more graphics.

Responding to Pipe Marker prompts

A typical Pipe Marker application template prompt sequence includes some or all of these prompt screens:

- **Pipe Marker Style**, where you choose the type of Pipe Marker you want to create: standard, rollform, or symbol or arrow tape
- **Dimensions**, where you select width, length, and height for your Pipe Marker label
- **Pipe Contents**, where you choose the contents that describe the pipe you are marking
- **Legend**, where you enter legend lines and supplemental data for Pipe Marker labels

- **Graphics**, where you choose one or more graphics from various categories to apply to your Pipe Marker labels
- **Arrows**, where you may specify arrow directions for Pipe Marker labels. This feature differs for North American and European standards.
- **Symbol Type**, where you choose symbols for Pipe Marker labels

Responding to Right-to-Know prompts

A typical Right-to-Know application template prompt sequence includes some or all of these prompt screens:

- **Right-to-Know Format**, where you choose the type of Right-to-Know label you want to create
- **Label Size**, where you select from label sizes available for the format you chose
- **Chemical Name**, where you enter information about the chemical you are labelling
- **Health Hazards**, where you select a health hazard rating if applicable
- **Signal Word**, where you select an OSHA- signal word for the label if applicable
- **Fire Hazard**, where you select a fire hazard rating if applicable
- **Reactivity**, where you select a reactivity rating if applicable
- **Specific Hazard**, where you select a hazard rating if applicable
- **Physical and Health Hazards**, where you choose the appropriate hazards for the chemical you are labelling if applicable
- **Temperature**, when a temperature must be indicated on the label
- **Target Organs**, which lists the available target organs for the chemical, where you select appropriate target organs
- **Statement of Hazards**, where you type text stating hazards when applicable
- **Precautionary Statements**, where you type text specifying precautions when applicable
- **Effects of Overexposure**, where you type text describing the condition when applicable
- **First Aid Procedures**, where you type text providing first aid information when applicable
- **Color Bar and NFPA Manufacturer**, where you designate protective equipment codes and manufacturers.
- **Comments**, where you can add relevant comments to your label

Creating Sets of Labels

When you know in advance that you want to print a group of labels all at the same time, you can create the labels as a *set*. Sets of labels can save you time, such as when you don't want to supervise a long print job, or when you need to print a number of labels with similar characteristics that won't require changing supplies.

Hint! For best results, before you compose the labels in the set, install the supplies you plan to use to print the label set.

As you add labels to the set, the system records the number of each label in sequence, calculates the total number of labels in the set, and notes it all in the **status bar** at the bottom of the display screen. You can view all the labels in the set by using the **Next Label** and **Previous Label** keys.

For best results, before you create a set of labels, make sure the labels meet these assumptions and requirements. When you create a set of labels, the system:

- Assumes you intend to print all labels in the set at the same time.
- Assumes you intend to create all labels in the set using the same method and color settings.
- Prompts you at print time for ribbon changes, if you changed colors during the label creation process.

Note: You may not create sets of labels with labels containing **variable text** objects. (For more information, see **Adding variable text objectsn page 7-10**).

Adding labels to a label set

You create labels individually when you are making a set, but after the initial label, you use the **Add Label** function to create the next label. The system then assumes you are making a set of labels and adjusts the process accordingly, with some differences for custom-created labels and those you create using pre-designed templates.

Adding custom labels

To create a set of custom labels

1. Create the first label in the set.
2. When it is complete and displayed in the **Editor** window, press **<Add Label>**. You do not have to close the initial label first or do anything to save it. The system automatically stores it in a temporary location.

Note: The label is saved only temporarily. If you don't save it as a file at the end of the editing session, it will be discarded when you close the **Editor** window.

You'll see a new blank label in the **Editor** window, and the status bar displays the message:

Label 2 of 2.

3. Repeat the process for as many labels as you need in the set.
4. When the set is complete, choose **Print**. See **Printing labels in a label set** page 11-6 for further instructions.

Adding template labels

To create a set of standardized template labels

1. Create the first label in the set.
2. When it is complete and displayed in the **Editor** window, press **<Add Label>**.
3. You'll see the Template Categories screen, where you can begin the process again by selecting a template again. Select the same template or a different one.
4. From this point, you'll be prompted for the same kind of information the system prompted you for with the original label. The status bar displays the message:

Label 2 of 2.

5. Repeat the process for as many labels as you need in the set.
6. When the set is complete, choose **Print**. See **Printing labels in a label set** page 11-6 for further instructions.

Moving between labels in a label set

You can view all labels in a label set sequentially. To move between labels in a set, press the <**Next Label**> or <**Previous Label**> keys. Each label is displayed in turn in the preview area of the **Editor** window. The status bar updates with the label's number in the sequence and the total number of labels in the group.

Editing labels in a label set

You can edit a label that is part of a set when it is displayed in the **Editor** window. Any editing changes you make will affect the current label only.

Clearing labels in a label set

To clear or remove a single label or all labels in the current label set, press the Clear key. You'll see the **Clear** screen, which provides these options:

Clear Current Label	The system removes the current label in the set, and updates the data in the status bar. The labels in the set are renumbered, and the next label in the set displays (with its new number).
Clear All Labels	The system removes all labels in the set.
Cancel	The last label constructed displays in the Editor window.

Clearing Custom labels

When you clear a Custom label, the next label in the set appears. If the label you cleared is the last one in the set, when you are returned to the **Editor** window, a blank label displays.

Clearing template labels

When you clear template labels, the next label in the set appears. If the label you cleared is the last one in the set, the system displays the **Template Categories** screen. Then you can either re-start the label creation process, or select **Back** to return to the **Main menu** screen.

Saving label sets

When you save labels you created as a set, the set is saved as a single **file**. You are prompted to name that file.

The system then prompts you to save the file in a **file group**. File groups can contain one or many label files. It's important to remember at print time that each label file can contain a single or multiple labels.

To save a label set

Follow the instructions in **Saving Labels as Files** on page 9-3.

Changing Labels

With most applications, you can change the size of a label you create, and you can edit the objects placed on that label. There are various methods for making changes, and each method affects different parts of your label.

- You can change the size of a label from the **Select Template** screen during a prompt sequence.
- You can edit template labels either by editing an object or by re-entering the prompt sequence.
- You can change label properties for a single label that include size, orientation, and framing.
- You can set preferences that apply to all labels or, with some application attributes, for labels are created with a specific application. See **Setting Application Preferences** on page 6-33 for information.

Exception: Some Pipe Marker and Right-to-Know application templates do not allow you to make some changes to labels you create (though sometimes you can make changes using the <Edit Data> function, which reruns the prompt sequence).

Changing the size of template labels

When the **Change Size** button is enabled on the **Select Template** screen (as shown in Figure 6-8), you may change the size of the label you are creating, even though it uses a pre-designed template. If the button is disabled, the template you chose does not allow size changes.

To change the size of a label

1. Choose **Change Size**. You'll see the **Custom Label Size** screen:




Figure 6-13. The Custom Label Size screen.

The value shown in the **Set width** field matches the currently installed tape. That is the maximum size label you can create for the tape currently installed, but you can set lesser width values, or you can set length values on this screen as well.

2. Choose **Match tape size** or **Use custom size**.

With **Match tape size** enabled, the system calculates the correct label margins for the tape currently installed, and updates the **Set width** and **Set length** fields to contain those values

You may not make changes in those fields with **Match tape size** selected.

- With **Use custom size** enabled, you can:

Set a custom width. When you choose **Set width**, the **Set length** field becomes unavailable (grayed out).

or

Set the label length. If you choose **Set length**, the **Set width** field is unavailable (grayed out).

3. Once you make changes, choose:
 - **OK.** Note the changed label size.
 - **Cancel** to restore the default label size.

In both cases, you'll go back to the **Select Template** screen (Figure 6-8).

4. When you have completed the **Select Template** screen, choose **Next**. Even if you pick a different template than the one selected when you changed size, you still set a new size.

Editing template labels

Most templates allow you to make changes to the objects placed on a label by the template. Those templates that do not allow changes will not allow you to perform the following procedure.

You can edit an object on a template label, or, when you want to make multiple changes, you can go back through the prompt sequence used to create the label.

To edit an object on a template label

1. After the prompt sequence for creating the label is complete and the label is displayed in the **Editor** window, select the object you want to change.

Hint! If the object may not be changed, the system will not allow you to select the object.

2. Press the **<Edit Object>** key or choose the **Edit Object** tool:

The appropriate **Graphics screen**, **Enter Text** screen, or whichever screen is appropriate to the type of object selected appears.



3. Make your changes, and choose **OK**.

Exception: <Edit Object> is not available in the Pipe Marker and Right-to-Know applications. Use <Edit Data>, which is described below, instead.

For detailed information about editing objects, see **Changing Objectsn page 7-31**.

You can also make some changes to some template labels using <Label Properties>. See **Changing Label Propertiesn page 6-27**.

To re-enter the application prompt sequence

With the label you want to change displayed in the **Editor** window, press <Edit Data>. You'll see the first prompt screen in the prompt sequence you followed to create the label. Follow the prompts and make the required changes.

Changing Label Properties

The **Label Properties** screens describe the size, orientation, and framing status of your current label. You can also use the **Label Properties** options to:

- Change the size of a label
- Change the print orientation of a label
- Add a frame to a label

To change label properties

1. Display the label you want to change on the **Editor** window.
2. Access the **Label Properties** screen by pressing <Label Properties> on the keyboard.
3. Choose the appropriate tab screen for the settings you want to change. The **Label Properties** screen has two tabs:
 - **Size**, for controlling the dimensions of your labels (Figure 6-14)
 - **Frame**, for adding frames to your labels (Figure 6-16)

Changing label size and orientation

Use the options on the **Size** tab, shown in Figure 6-14, to change the size of a label and to set print orientation.:




Figure 6-14. The Label Properties screen, Size tab.

The options are:

Match tape width	Check to set the label size to the maximum that can be printed on the currently installed tape. When this option is checked, the Set custom width field is unavailable (grayed out).
-------------------------	---

<p>Set custom width</p>	<p>Check this option to set a custom label width. Enter the new width in the entry field. The value entered must be less than the maximum printable width appropriate for the installed tape, because unlike the default width, this value indicates the total output width, with no margins applied. This means that the printable area will equal the amount you specify here. (See Checking Sizen page 11-11 for more discussion on this topic.)</p> <p>With the Monocolor and the Multicolor systems, the label prints with dashed lines that indicate the label's dimensions.</p> <p>With the Color & Cut system, the label is cut around its outside dimensions.</p> <p>Note: Objects previously placed on the label keep their original size when you resize a label using this feature. You must manually resize any objects that no longer fit within the new label size. For information on resizing objects, see Sizing Objectsn page 7-27.</p> <p>This option is not available when Match tape width is enabled. When Match tape width is enabled, the value in this field shows the current width of the label for display only.</p>
<p>Auto calculate length</p>	<p>Check this option to accept the length the system automatically sets, based on the contents of the label. If you have a paneled ribbon installed, the maximum label length is set to the panel length.</p> <p>Hint! When this option is enabled, your label automatically prints with the objects centered on the length dimension of the label. The system achieves this by calculating the space between the leading edge of the label and the first object on the label, then adding that same amount of space after the last object on the label.</p> <p>When this option is selected, the Set length option is unavailable (grayed out).</p>

Set length	<p>Choose to set your own length for a label, and to enter the new length in the entry field.</p> <p>Note: The minimum length label you should print is 2 inches or 51 mm. If you set a shorter label length, the printer still delivers a two-inch long label, unless you are printing in Supply Saver mode. See Minimum length on page 11-12 for more information.</p> <p>When Set Length is selected, the Auto calculate length option is unavailable (grayed out).</p> <p>If you have a paneled ribbon installed, you can set the label length to less than the panel length, but you may not increase the label length to beyond the limits of the panel. If you do, the label length defaults to the panel length.</p>
Landscape	<p>Sets the label to print in Landscape mode, where the height of the label is the width of the tape supply. This is the default.</p>
Portrait	<p>Sets the label to print in Portrait mode, where the width of the label is the width of the tape supply.</p>

Choose **OK** when your settings are complete. If your label width is larger than the printable area of your tape supply, the system displays a message that provides the maximum size you can use.

Choose **Cancel** to return to the **Editor** window without making changes to the label.

Adding a label frame

You can add a frame around the edge of a label in the shape of a rectangle or a rectangle with rounded corners. This is a sample label with a rounded rectangle frame added:



Figure 6-15. A sample label with a frame.

You can make the frame line thick or thin, and if you have the Multicolor or Color & Cut system, you can set a color for the line. If you have the Color & Cut system, you can also cut out the label around the frame boundaries. See **Cutting Around Label Frames** for instructions.

Hint! For best results, create and finish your label before applying a frame.

Use the options on the **Label Properties Frame** tab to frame a label:





Figure 6-16. The Label Properties screen, Frame tab.

The **Frame** tab options are:

Frame shape	Set to select the shape of the label frame. Choices are: <ul style="list-style-type: none"> • Rectangle (default) • Rounded rectangle
Cut out frame	If you have the Color & Cut system, check this option to cut the label along the frame boundary. This option is not available on the other systems.
Print frame	Choose to print the label frame. If you have the Color & Cut system, you can check both Cut out frame and Print frame to have the system automatically size your label to fit within the cut out boundary. This option is not available on the Monocolor and Multicolor systems, where Print frame is the only choice.

Line width	Use to set a width for the line that composes the frame. The default is 0, which means no line appears on the label. If Cut out frame is enabled, the system ignores the Line width value.
Line color	Use to access the Object Color screen, which lets you set a line color appropriate for the installed ribbon. See Applying Color to Objectsn page 8-5 .
OK	Choose to signal that your settings are complete. The completed label displays in the Editor window. If you have set a Line width value greater than 0, a frame of the shape you selected appears around the outer edge of the label.
 Cancel	Choose to return to the Editor window, where the label displays unchanged.

Setting frame length

The system uses the length of the label you set in the **Label Properties Size** screen to set the length of a frame.

When you do not set a length, leaving it to be automatically calculated by the system, it sets the frame length according to the data it finds.

If you add or remove objects from the label, the system does not automatically resize a frame. To resize the frame, you must remove the existing frame and add a new one.

Setting Application Preferences

Application Preferences settings are very similar to **System Setup** settings (described in **CHAPTER 5: Setting Preferences**, beginning on page 5-1). In some applications, the **Application Preferences** screens allow you to set application-specific preferences that apply to the application only. In most cases, however, the **Application Preferences** tabs provide system-wide settings. In fact, several

Application Preferences tabs are identical to those that appear on the **System Setup** screen.

Important! When you make a change to **Application Preferences** or **System Setup** options, that change is in effect for *all* labels you create from that point on, until you change the settings again.

Some templates, particularly those in the Pipe Marker and Right-to-Know applications, contain instructions telling them to override preferences you may try to set. This is to maintain the integrity of the templates, some of which are designed to comply with federal regulations.

Accessing Application Preferences screens

Press the <**Preference**> key while inside a label you are creating or one you have previously created. You'll see the **Application Preferences** screen appropriate for the application in which you are working. This screen can have many tabs, but the most common configuration is shown here:




Figure 6-17. The Application Preferences screen.

Exception: The **Pipe Marker Preference** screen offers two tabs: **Printing** and **Color Norm**. The options on the **Printing** tab apply system-wide. The options on the **Color Norm** tab apply only to Pipe Marker labels. See **Setting Pipe Marker preferencesn page 6-35**.

The **Right to Know Preference** screen offers five tabs: **Printing**, **Format**, **Size**,

Hazards List, and Organs list. The options on the **Printing** tab apply system-wide. The options on the other tabs apply only to Right-to-Know labels. See **Setting Right-to-Know preferences** on page 6-36.

Note that the **Application Preferences** screen **Printing**, **Other**, **Text**, and **On Line** tabs offer the same options as the **System Setup** screen tabs of the same names. These are provided from within applications as well for your convenience, so that you can change the settings without having to close the application and return to the **Main Menu** to access **Setup**.

Hint! The options on the **Printing**, **Other**, **Text**, and **On Line** tabs work exactly the same whether you choose them from Application Preferences or from System Setup. The settings apply system-wide and remain until you change them again.

Setting Print tab preferences

The **Print** tab Preference options are fully described in **Printing Tab Optionsn** page 11-19.

Setting Other tab preferences

The **Other** tab Preference options are fully described in **Setting Other Tab Optionsn** page 5-10.

Setting Text tab preferences

The **Text** tab Preference options are fully described in **Setting Text Tab Optionsn** page 5-12.

Setting On Line tab preferences

The **On Line** tab Preference options are fully described in **Setting Other Tab Optionsn** page 5-10. Also see **Placing Your System Onlinen** page 12-4 for instructions for using these options.

Setting Pipe Marker preferences

The **Pipe Marker Preference** tabs are:

Printing, which contains the same options as described in **Printing Tab Optionsn** page 11-19.

Color Norm, where you choose the appropriate color norm setting for your country and language. Your choices vary according to your location and your organization. For example, your choices in North America are:

- ANSI/ASME (USA)
- CAN/CGSB (CANADA)
- AS1345-1995 (Australia/NZ)

Setting Right-to-Know preferences

The **Right-to-Know Preference** tabs are:

Printing, which contains the same options as described in **Printing Tab Options** page 11-19.

Format, where you set the default format for subsequent Right-to-Know label files you create.

Size, where you select the default size for the default format chosen.

Hazards List, which lists possible physical and health hazards. You add hazards or delete them from the list. The resulting list displays on the **Physical and Health Hazards** screen for all subsequent Right-to-Know labels.

Organs List, which lists possible target organs. You add organs or delete them from the list. The resulting list displays on the **Target Organs** screen for all subsequent Right-to-Know labels.

Note: In the **Hazards List** tab and in the **Organs List** tab, changes you make in one language do not affect the listed hazards when viewed in a different language. You must edit these lists in each language you intend to use on your Right-to-Know labels.

Working with Objects

When you create a label, you build it by adding **objects** to it. Objects can include text, variable text, graphics, bar codes, and HotShapes.

This chapter describes how to add objects to your labels and how to format them. Topics in this chapter include:

- About Objects**
- Adding Objects**
- Selecting Objects**
- Moving Objects**
- Sizing Objects**
- Copying and Pasting Objects**
- Changing Objects**

About Objects

Before you begin this chapter, it's important to understand the term **objects**.

When you create a label, you build it by creating or adding **objects** to it. The objects can be made either for printing or for cutting out (if you have the Color & Cut system).

It may be useful to think of objects as “containers” that can hold various types of content or data. You decide where to put an object and what to put in the container when you create your labels. Once you have “filled” an object, it is named for its contents, so it is called a text object, a graphic object, a bar code object, and so on.

The object types you can add to labels in this system are:

- Text objects
- Variable text objects
- Graphic objects
- Bar code objects
- HotShape objects

A single label can include multiple objects, such as graphics and variable text, or text and bar codes. (For an example of a label that contains multiple objects, see Figure 4-1 on page 4-2. The label pictured contains a graphic and a block of text.)

The system displays the objects on the **Editor** window, within the preview area. The **Editor** window is ready to display the label as you create it. At this point, the system operates with these defaults:

- The blank label displayed reflects the size and color of the tape installed.
- The blank label displays with landscape print orientation assumed.
- The magnification or zoom level is set to display 12 inches of label length, but this does not reflect the actual printable length of the label. The objects you insert determine the final length of the label, or, if you have a paneled ribbon installed, the length of the panel determines the maximum length of the label. See **Checking Length** on page 11-12 for more information.

Hint! You can set the length of your label before adding objects. Use the **Set Length** option on the **Size** tab of the **Label Properties** screen.

- The color of the objects you insert is determined by the ribbon you have installed. If no ribbon is installed, the system assumes a black continuous ribbon. See **About Color** on page 8-2 for more information.

After you have added an object to a label, you can move it around and make changes to it. After the label is complete, you can print it, or if you have the Color & Cut system, you can cut out some object types.

Adding Objects

You can create objects for a label, such as when you write your own text for a label, and you can insert existing objects on a label, such as when you choose a graphic from the graphics categories to put on your label. In either case, you are **adding** an object to the label.

To add an object to a label

1. Create a new label as described in Creating Custom Labels on page 6-2.

The **Editor** window is displayed with a blank label in the preview area:




Figure 7-1. The Editor window.



2. Choose the **Insert Object** button in the tool bar on the **Editor** window, or press **Insert Object** on the keyboard.

The **Insert Object** screen displays:




Figure 7-2. The Insert Object screen.

Note that the **Insert Object** options vary according to your system's features. The Monocolor and Multicolor systems do not offer the **Cut out object** option, so **Print object** is assumed and does not appear on the Insert Object screen.

You select options on this screen to choose the kind of label you are going to make, and to indicate what type of object you want to add. Each type is described in the sections that follow.

3. If you have the Color & Cut system, choose **Print object**. All other systems assume the object is a Print object.

Note: The sections that follow describe **Print objects** only. To use the **Cut out object** option on the **Insert Object** screen, you must have the Color & Cut system. See **CHAPTER 10: Working with Cut-outs**, for instructions.

Adding and formatting text objects

It's important to understand that when you add a text object, you are not simply typing text on your label. You create a text object, you type text into the text object, and you **add** that text object to your label. This concept is especially useful to understand for later, when you want to change or edit the objects on your labels.

Adding a text object

This procedure creates and adds a text object to your label.

To add a text object to a label

1. Choose **Text** from the **Insert Object** screen.

You'll see the **Enter Text** screen.




Figure 7-3. The Enter Text screen.

2. Enter text in the text entry area by typing the characters on your keyboard. To start a new line, press **Enter**. Note that the size of the text you type as shown in the **Enter Text** screen is not the actual size it will be on your label, but is displayed at a size you can easily edit.

Hint! You can change the type size or font style of the text, or add special characters to the text, at any point after you open the **Enter Text** screen, even before you type any characters. See *Formatting text objects* on page 7-6 for instructions.

3. When you are finished, choose **OK**. You'll see the **Editor** window with your new text object displayed in the preview area.

Formatting text objects

The **Enter Text** screen provides these options for formatting your text object:

Font	Lets you choose the style of the characters. See To select a font below.
Type size buttons	Lets you change the size of the characters. See To change the type size on page 7-7.
Special	Lets you insert special characters, like accented characters, foreign currency symbols, mathematical symbols, subscripts and superscripts, and more. See Adding special characters to text on page 7-8.
OK	Saves your settings and displays the label in the Editor window.
Cancel	Returns you to the Editor window with a text object containing no text displayed.

To select a font

You can choose from among several font styles, depending on which fonts are provided with your system. The *font* is the style and shape of the characters.

You can also use text formatting options to change the style of the fonts to bold, italic, and underline, or any combination of the three. You can change the color of your text as well, depending again on how your system is equipped and the supplies you have installed.

Note: When you apply the text formatting options, the system places invisible markers to indicate where to apply format changes. Normally you will not be aware of these markers, but if you inadvertently place the cursor before a marker, the **Delete** key will not function.

1. With the text you want to change displayed on the **Enter Text** screen, select the part of the text (or all of it) that you want to format.
2. Press **Font** on the **Enter Text** screen, shown in Figure 7-3 on page 7-5.

You'll see the **Font** screen:




Figure 7-4. The Font screen.


The options are:

Font	Lists the fonts installed on your system. As you select a font, a preview displays in the Font Preview box.
B	Bolds the selected text. If no text is selected, Bold is applied to the next text you type.
I	<i>Italicizes</i> the selected text. If no text is selected, Italic is applied to the next text you type.
U	<u>Underlines</u> the selected text. If no text is selected, Underline is applied to the next text you type.
Color	Takes you to the Color screen appropriate for your system. See CHAPTER 8: Applying Color , for complete information about color.

To change the type size

Changing the type size makes the characters larger or smaller, not just as you see them on the screen, but on the printed label as well.

1. On the **Enter Text** screen, select the text you want to change.



2. Use the + or - button to increase or decrease the size of the text. The text changes size on the **Enter Text** screen.

Note: The unit of measurement (e.g., points, inches, millimeters) used here is determined by the defaults set in the **System Setup** screen. See Setting Text Tab Options on page 5-12 for details.

3. When you are satisfied with the type size, press **OK**. The system takes you back to the **Editor** window, where you will see changes you made to the label displayed in the preview area.

Hint! On some types of labels, the system automatically sizes the font. See Creating QuickText Labels on page 6-5 for information.

Adding special characters to text

You can insert accented characters, subscript numerals, some superscript numerals and characters, characters in other languages, and other special characters that do not appear on your keyboard on your labels. For a complete list of special characters you can add, see **Appendix A: Special Characters**.

You can also customize your system with **Special Characters** buttons that display the special characters you use most frequently. The first time you use the **Special Characters** screen, the **Special Character** buttons are blank. You personalize the buttons on this screen with your own choice of frequently-used special characters, so you can access them easily in the future.

This example shows some **Special Character** buttons already personalized.




Figure 7-5. The Special Character screen, customized.

To personalize Special Characters buttons

1. On the **Enter Text** screen (Figure 7-3), choose **Special**.
You'll see the **Special Characters** screen.
2. Type a code in the **Enter code** field. The codes available to you depend on the currently active font. See **Appendix A: Special Characters** for a list of characters and codes.
3. Choose **Add**. The system displays the special character whose code you entered on the face of the first available blank special character button.
4. Repeat for as many special characters as you want to assign to buttons.
5. Choose **OK** when complete.

To delete Special Character buttons assignments

1. Select one or more **Special Character** buttons for which you previously assigned special characters. Touch each button you want to delete. The system allows you to delete more than one special character assignment at one time.
2. Press **Delete**. The special characters previously assigned to those buttons are removed. Remaining special character buttons are reordered to the top of the group.

To add a special character to label text

1. On the **Enter Text** screen, position the cursor where you want to insert a special character.
2. Choose **Special**.
You'll see the **Special Character** screen.
3. Select a character from the Special Character buttons you previously customized. Or, if the buttons are still blank, enter the code of the character you want in the **Enter code** field.
4. Choose **OK**.

Hint! You do not have to personalize a **Special Characters** button to use a special character. Just enter the code and press **OK**.

To add multiple special characters to label text

1. On the **Enter Text** screen, position the cursor where you want to insert a special character.
2. Choose **Special**.
You'll see the **Special Character** screen.
3. Select multiple special character buttons before you choose **OK**.
4. Choose **OK**. You'll see the **Text Entry** screen displayed with all characters you selected added at the cursor position. The characters are added in the order you selected them.

Adding variable text objects

You can design labels that automatically generate multiple labels from a single label layout. For instance:

- You can make a set of labels that look the same but are numbered sequentially, or a group of labels formatted the same, but with different names on them.
- You can create a set of labels to number packing boxes when you move, or a set of alphabetic labels you can use to organize file folders.
- You can create a set of name labels for the members of your group.

The object that varies with each group of labels is called a **variable text** object. Variable text can consist of either **Sequence** (numerical or alphabetical characters sequentially added to a group of labels) or a **Text list** (such as names of items) data. The first step in creating labels with variable text is to choose a data source for the labels.

Choosing a data source

From the **Insert Object** screen (Figure 7-2), select the **Variable Text** button. The **Data Source** screen displays.




Figure 7-6. The Data Source screen.


The options are:

Sequence	Data consisting of increasing or decreasing numbers or alphabetic letters
Text list	Data consisting of a list of items you create

Creating sequential labels

To create sequential labels, choose **Sequence** on the **Data Source** screen.

Use the options on the **Sequence** screen to define a **Sequence variable text object** or **variable bar code object** for your labels.



The screenshot shows a dialog box titled "Sequence". It has a blue header bar. Below the header, there are four input fields: "Starting value" (text box with "1"), "Ending value" (text box with "1" and a radio button), "Change by" (text box with "1"), and "Total number" (text box with "1" and a radio button). Below these are two text boxes for "Include text: Before sequence" and "After sequence". At the bottom are "OK" and "Cancel" buttons.

Figure 7-7. The Sequence screen.

For example, the screen shown above defines a set of ten labels that user Jean Martin plans to use to identify packing boxes. The labels are set to be numbered from 1 to 10, with the text “#” before the sequence, and the text, “Jean Martin” after the sequence.

With the information entered as shown in Figure 7-7, the system would produce ten labels similar to this one, numbered 1 through 10 consecutively:




Figure 7-8. A sample Sequence label

Hint! Make sure the text object you define is large enough to accommodate all possibilities in your sequence.

For instance, in the example above, if Jean Martin creates 100 numbered labels, when the system prints the label with the number 100, the text area

may no longer be large enough for the entire text string. The text will be cut off on the printed label.

The **Sequence** options are:

Starting value	Enter the starting value for the sequence in this field. You can enter any number, or a single letter of the alphabet, but you may not mix both letters and numbers in a single sequence. (You may, however, enter alphabetic or symbol characters if the first character entered is a number: for example, 1A, 2%, 3*.) The default value is 1.
Change by	Enter the amount by which you want the sequence to change on each label. A positive number increases the number or letter of the alphabet on the label; a negative number decreases the number or letter of the alphabet on the label. The default value is 1, but you can use larger increments with numeric sequences. Note: When you use the letters of the alphabet as the sequence, the only valid values for this field are 1 and -1.
Ending value	Enter the ending value for the sequence. Using the Starting value , the Change by value, and the Ending value , the system calculates the total number of labels to be generated for the sequence, and enters it in the Total number field . The default value is 1. Hint! You can leave this field blank and instead enter the Total number of labels you want to produce, and the system automatically calculates the Ending value for you.

Total number	Enter the total number of labels you want to produce in this field. The default value is 1. Hint! You can leave this field blank and instead enter the Ending value for labels you want to produce, and the system automatically calculates the Total number for you.
Before sequence	Enter text that you want to print on all labels in the sequence before the sequence number or letter. Note that text you enter here will be exactly the same on each label.
After sequence	Enter text that you want to print on all labels in the sequence after the sequence number or letter. Note that text you enter here will be exactly the same on each label.
OK	Press when you are ready to save your entries and create the sequence object. Your new variable text object appears on the Editor window.
Cancel	Choose to return to the Editor window without saving entries you made.

Creating text list labels

A classic example of variable text labels is name tags for attendees of a convention. A sample label might look like this one;

<p>Hello! My name is</p> <p>Jean Martin</p> <p>Global Industries, Ltd.</p>

The top line and the bottom line are the same for all labels. By listing the members' names on a **Text list**, every label produced will contain a different name. The next label will print with the next name on your Text list, and so on.

Hint! Make sure the text object you define is large enough to accommodate all possibilities in your sequence. For instance, in the example above, make sure the object is large enough to accommodate the longest name on your list.

To create a Text list

1. Choose **Text List** on the **Data Source** screen (Figure 7-6).

You'll see the **Text List** screen, which you use to enter the list of words you want to use on your labels:




Figure 7-9. Text List screen with example.

2. Type the first item you want to appear on a label.
3. Press **Enter**.
4. Repeat Steps 2 and 3 for each label you want to print.
5. You can choose to save text lists you create for future use, or you can just use the list once:

- To use the list once, then discard it, press **OK**.
- To save your list, press **Save List** when the list is complete. You'll see the **Save Text List** screen. Name your new list in the **Enter list name** field, then press **OK**.

The **Editor** window displays, with the first item on your Text list shown on the label.

To use saved Text lists

You can use a Text list you saved previously to create a new set of labels with the same variable text. For instance, if you have a list of club members saved, you can use that same list to create name tag labels, mailing labels, and so on.

Hint! If your system is connected to a PC, you can also download list files from files stored on the PC. See **CHAPTER 12: Connecting to a PC**, beginning on page 12-1, for instructions.

1. Choose **Text List** on the **Data Source** screen (Figure 7-6 on page 7-11).
You'll see the **Text List** screen (Figure 7-9 on page 7-15).
2. Choose **Open List**. The **Select Text List** screen displays.
3. Select a list from the **Select list** box, and press **OK**.
The **Text List** box appears, with the entries from the list you previously saved displayed.
4. Choose **OK** to return to the **Editor** window.

Adding vertical text objects

Select **Vertical Text** on the **Insert Object** screen (Figure 7-2 on page 7-4) to add vertical text objects to your labels.

Note: The characters appear horizontally on the screen as you type the text. When you press OK, the vertical attribute is applied and the text appears vertically on the label.

The label orientation does not change when you insert a vertical text object. To manually change the label orientation, go to the **Label Properties** screen. See Changing Label Properties on page 6-27 for details.

To change the text orientation to vertical after you have created an object, go to the Options tab on the Object Properties screen. See Setting options on the Options tab on page 7-40.

Adding bar code objects

Select **Bar Code** on the **Insert Object** screen (Figure 7-2 on page 7-4) to add bar code objects to your labels.

The first step in creating bar codes is choosing a data source.

Choosing a bar code data source

From the **Insert Object** screen (Figure 7-2), select the **Bar Code** button. The **Data Source** screen displays.



Figure 7-10. Data Source

The options are:

Bar Code	The Bar Code dialog box displays with the Content tab activated.
Variable Bar Code	The Sequence dialog box displays.

If you select **Bar Code** on the Data Source dialog box, the Bar Code dialog box displays where you can specify the content of the bar code.




Figure 7-11. The Bar Code screen Content Tab.

The **Bar Code** screen has five tabs. When you add a bar code, you'll use the **Content** and **Dimension** tabs. The remaining tabs -- **General**, **Size and Location**, and **Font** -- are mainly used to change default settings for bar codes (see Editing bar codes on page 7-21).


Setting bar code content

Use the **Content** tab to set these options:

Symbology	<p>Select a symbology code from this list box. Symbologies are universal bar code formats. This system supports these symbologies:</p> <ul style="list-style-type: none"> • Code 128 Auto • Code 39 • Interleaved 2-of-5 								
Data value	<p>Specify a data value for the bar code here. The symbology codes limit the data to a specific number of characters:</p> <table data-bbox="598 605 1103 727"> <thead> <tr> <th><u>Symbology</u></th> <th><u>Max. # Characters</u></th> </tr> </thead> <tbody> <tr> <td>Code 128 Auto</td> <td>2-50</td> </tr> <tr> <td>Code 39</td> <td>2-50</td> </tr> <tr> <td>Interleaved 2-of-5</td> <td>2-50</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • If you enter an incorrect number of characters in the Data value field, a message prompts you for a corrected value. • If you enter invalid characters in the Data value field, you'll see a message telling you so. 	<u>Symbology</u>	<u>Max. # Characters</u>	Code 128 Auto	2-50	Code 39	2-50	Interleaved 2-of-5	2-50
<u>Symbology</u>	<u>Max. # Characters</u>								
Code 128 Auto	2-50								
Code 39	2-50								
Interleaved 2-of-5	2-50								
Human-readable text	<p>Select the placement of the text that people can read (as opposed to machine-readable code). You can choose:</p> <ul style="list-style-type: none"> • No text • Text above bar code • Text below bar code (the default) 								

Setting bar code dimensions

Choose the **Dimension** tab on the **Bar Code** screen to set bar code measurements:



The screenshot shows a window titled "Bar Code" with a blue header bar containing "OK" and "X" buttons. Below the header are four tabs: "Size and Location", "Content", "Dimensions" (which is selected), and "Font". The "Dimensions" tab contains the following settings:

- Height:** A text box containing "4.87" followed by "in" and a checkbox labeled "Include check character".
- Density:** A dropdown menu showing "20" followed by "mils" and a checkbox labeled "Print readable check character".
- Ratio:** A dropdown menu showing "3:1" and a checkbox labeled "Print readable start/stop (*)".

Figure 7-12. The Bar Code screen, Dimensions tab.

Use the **Dimension** tab to set these bar code options:

Height	<p>Set the bar code height (in the unit of measure specified on the System Setup screen Localization tab) by entering a height or choosing from the options list.</p> <p>Hint! If you want to make a bar code taller, setting the height here is preferable to using the Height option on the Bar Code Size and Location tab.</p>
Density	<p>Set the density in mils by choosing from this list. The density is the thickness of the bars and how far apart they are.</p> <p>Hint! This setting determines the width of the bar code.</p>
Ratio	<p>Set the width ratio by choosing from this list. Ratio determines the relative width of the wide bars to the narrow bars in the bar code.</p>

Include check character	Check this box if you want to print a check character on the label.
Print readable check character	Check this box if you want to print a check character on the label in a format people can read. This option is unavailable (and therefore grayed out on your screen) unless you have already checked Include check character .
Print readable start/stop (*)	Check this box to indicate whether the start and stop characters (which are asterisks) should appear in human-readable text.

Editing bar codes

Of the remaining tabs, **General**, **Size and Location**, and **Font**, only **Location** has options that apply to bar codes. The options on the remaining tabs correspond to the options on the same tabs in the **Bar Code Properties** screen. See Changing object properties on page 7-32 for information about these options.

Specifying bar code sequence

You select the bar code sequence from the sequence dialog box. For explanation of the Sequence dialog box options, see Creating sequential labels on page 7-11.




Figure 7-13. Sequence dialog box,

Adding graphics objects

You choose graphics from groups of pre-defined graphics supplied with your printing system. The graphics are organized in categories, with the name of the category shown. After you select a graphic category, you'll see small versions of the graphics on your screen. You can look at all graphics offered in a category, and you can change categories.

To add a graphic object

1. Select **Graphic** on the **Insert Object** screen (Figure 7-2 on page 7-4). You'll see the **Graphic Categories** screen:




Figure 7-14. The Graphic Categories screen.

2. Choose a category of graphics from the list. Use the arrow scroll buttons to move up and down the list.

3. Choose **OK**. The **Graphics** screen displays:




Figure 7-15. The Graphics screen.



Use the arrow buttons to step through thumbnail versions of the graphics offered in the category shown. Each time you press a scroll button, you'll see six (or fewer, depending on how many graphics are available in the category) new thumbnail graphics.

4. Select the thumbnail button that displays the graphic you want to add to your label.
5. Click **OK**. The system adds the graphic object to your label.

To change graphics categories

1. Choose **Change Category** on the **Graphics** screen. You'll see the **Graphic Categories** screen (Figure 7-14 on page 7-22) again, which lists all categories offered in your system.
2. Choose a category from the list and press **OK**. The **Graphics** screen displays again, this time displaying thumbnail versions of graphics from the new category you selected.

Adding HotShapes

HotShapes are pre-defined designs you can print on your label. If you have the Color & Cut system, your printer can automatically cut out these shapes. See **CHAPTER 10: Working with Cut-outs**, for more information.

To add HotShape objects to your label, select the **HotShape** option on the **Insert Object** screen (Figure 7-2 on page 7-4). The **HotShape** screen displays.




Figure 7-16. The Hot Shapes screen.

Choose a HotShape by selecting one of the **HotShape** buttons. The HotShape object is automatically added to your label on the **Editor** window.

Hint! You can change the size, color, rotation, and location of a HotShape object just like any other type of object, but you may not open and edit a HotShape.

To cancel adding a HotShape and return to the **Editor** window, choose **Cancel**.

Selecting Objects

You must select an object in the **Editor** window before you can move, resize, copy, or edit it. (See *Selecting in the Editor window* on page 4-7 for detailed information about selecting text objects using the touch screen, the keyboard, or the mouse.)

In brief:

To:	Do this:
Select an object	Touch the object
Select a different object	Touch another object. The new object is selected.
Select multiple objects	Touch each object while holding down the Shift key.
Select no objects or deselect the object selected	Touch the label background where there are no objects. All objects will be deselected.

You can tell an object is selected when a **bounding box**, which is a gray rectangle that encloses the object, appears on the screen. The bounding box has small squares, called selection markers, at the corners and midpoints of the sides.

Note: Depending on the resolution of your machine and the features it contains, the sides of the bounding box may be dim or may not be visible at all. But the selection markers will always display to indicate that an object has been selected.

If you select more than one object, the bounding box expands to enclose all the objects. See Figure 4-3 on page 4-8 for an example that shows a bounding box.

Hint! The ‘click’ you hear when you touch the screen indicates only that you have touched the screen with enough force for the system to recognize the touch. The click does not necessarily indicate that you have successfully selected an object on the screen.

A second ‘button activated’ cue sounds when you have successfully activated a button or control on the touch screen. The ‘button activated’ sound applies to the **Command** buttons and the Up and Down **Scroll** buttons. The ‘button activated’ sound does not apply to the **OK** and **X**

(Close) buttons in the dialog box title bar, the **Tab** controls in the property screen dialog boxes, **Radio** buttons, or **Option List** items. See **Working in Entry Screens** on page 4-9 for more information.

Selecting a layered object

When you have multiple layered objects on a label, it can be difficult to see and select the object of your choice. In some cases, you may be able to move the objects aside temporarily to find the object you want, but this alternative is not always practical on a crowded display screen.

To find and select a layered object

1. First, make sure you have an object, any object, selected on the screen.
2. Press **Tab** to cycle through all the objects on the screen one by one.

Hint! To help identify the object selected, press **Object Properties** and review the object's characteristics.

Moving Objects

The Move to Back and Move to Front buttons make it easy to move objects on the screen.

Hint! You can also assign a precise location for objects using the options on the **Size and Location** tab of the object **Properties** screens. See Setting options on the Size and Location tab on page 7-36 for more information.

To move an object using the touch screen

1. Touch the object to select it.
2. Click the **Properties** button to display a second row of functions, which contains the **Move to-** buttons.
3. Click the **Move to Back** button to move the selected object to the back of any layered objects.

OR

Click the **Move to Front** button to move the selected object to the front of any layered objects

4. Move your finger on the screen to take the object to its new location.

To move an object by keyboard

1. Select the object.
2. Press an arrow key on the keyboard.
3. Repeat pressing the arrow key or hold it down until the object is where you want it.

Each key press moves the object by one-tenth of an inch, so the procedure above works well for moving objects a small amount. If you hold down the arrow key, the moving process goes a little faster. But to move objects by a greater amount, there is a speedier process:

To move objects faster and farther

1. Select the object.
2. Hold down **Shift**.
3. Hold down the arrow key.

Sizing Objects

You have several options for sizing objects on the **Editor** window:

- Use the **Increase Size** or **Decrease Size** tools. This method is good for small changes. See the **Using Increase Size and Decrease Size** section below for instructions.
- Use the <**Scale**> key on the keyboard. Use this method for size changes of 25% and greater. See **Using the Scale function** on page 7-28 for instructions.
- Use the **Object Properties** tool or press the Object Properties key to set the **absolute size** of an object. To learn about this process, see the Changing object properties on page 7-32

Using Increase Size and Decrease Size

The **Editor** window toolbar provides these two size tools, which increase or decrease the size of the selected object proportionally by 10% of its **original size** each time you select the tool.

- When you select **Increase Size**, your selected object becomes 10% larger than its original size. If you repeat **Increase Size**, your selected object becomes 10% larger than its new size.
- When you select **Decrease Size**, your selected object becomes 10% smaller than its original size. If you repeat **Decrease Size**, your selected object becomes 10% smaller than its new size.

Use the **Increase/Decrease Size** tools when you want to make a small size change, or when you need to make the change in 10% increments.

Hint! **Increase/Decrease Size** changes are *always* proportional, which means that you change the width and height of the object at the exact same rate of change. The shape of the object remains the same, though the size changes.

To resize an object using the Size tools

1. Select the object.
2. Select **Increase Size** or **Decrease Size**.
The object remains selected, and the size changes by 10%.
3. Repeat Step 2 to continue changing the size by 10% of the original size.

Using the Scale function

Use <**Scale**> on the keyboard when you want to resize an object by 25% or more and still maintain its original proportions. When you use the **Scale** function, you choose a percentage that will reduce or increase the **current size** of the selected object by that amount. For example:

- When you choose 25%, the object is reduced to 25% of its current size. If you repeat the process, the object is reduced to 25% of its new size.
- When you choose 150%, the object is enlarged to 150% of its current size. If you repeat the process, the object is enlarged to 150% of its new size.

Hint! Scaling is *always* proportional, which means that it changes the width and height of the object at the exact same rate of change. The shape of the object remains the same, though the size changes.

To resize an object using Scale

1. Select the object
2. Press the **Scale** key on the keyboard.

The **Scale** screen displays.




Figure 7-17. The Scale screen.

3. Choose one of the percent buttons.

or

Enter a percentage in the **Percent** field.

- Percent field minimum = 10%
- Percent field maximum = 500%

Hint! Use the **Percent** field for percentage amounts not provided on the percent buttons.

If you enter a percentage outside the range, a system message directs you to re-enter a valid value.

Scaling text objects

Using <Scale> on text objects is not recommended, as it may result in the text wrapping to more or fewer lines on the label. (Resizing using the **Increase/Decrease Size** tools may have the same result.) If the **Auto Size Font** option on the **Options** tab of the **Text Properties** screen is turned on, the text size changes as the object is scaled. See Adding and formatting text objects on page 7-4 for information on Text objects.

Scaling bar codes

The size of the human-readable text does not change when you use <Scale> to resize a bar code. See Adding bar code objects on page 7-17 for information.

Copying and Pasting Objects

When you **copy** an object, the system leaves the object in its original location, and places a copy of the object in the system's internal memory. This lets you **paste** the object into another location.

To copy an object

1. Select the object using any of the methods described in Selecting Objects on page 7-25.
2. Press the <Copy> key, or use the **Ctrl+C** key combination.

A copy of the object is placed in the system's internal memory. The original stays where it is.

Hint! You can delete the original object while it is still selected by pressing **Delete** or **Ctrl+X**.

To paste an object

1. Copy the object you want to paste.
2. Press **Paste**, or use the **Ctrl+V** key combination.

The object is pasted in the center of display screen. You can move it to any location on the screen. Use the methods described in Moving Objects on page 7-26.

Hint! You can paste multiple instances of an object by repeating **Paste** or **Ctrl+V**.

Changing Objects

You make changes to an object by opening and editing it, or by changing its object properties.

Opening and editing an object

You must open an object for editing before you can make changes to it.

To open an object

1. With your label displayed in the **Editor** window, select the object to be edited. Use any of the methods described in Selecting Objects on page 7-25.
2. Choose **Edit Object** on the toolbar, or press **Edit Object** on the keyboard. Depending on the type of object selected, you'll see one these screens:



Text object	Enter Text screen, described in Adding and formatting text objects on page 7-4.
Variable text object	Sequence screen, described in Creating sequential labels on page 7-11, or Text List screen, described in Creating text list labels on page 7-14, depending on the type of variable text.
Bar code object	Bar Code screen, described in Setting bar code dimensions on page 7-20
Graphic object	Graphics screen, described in Adding graphics objects on page 7-22.

To edit an object

Use the fields and options on the screen that displays after opening the object, as shown in the table above, to make changes.

Changing object properties

Instead of manipulating the object you want to change within the **Editor** window as described in the preceding sections, you can use the options on the **Properties** screens to reset the properties of the objects. The **Properties** option let you control the physical properties of your objects, such as height, width, location, and color.

Important! The object **Properties** screens, tabs, and options vary according to the features your system offers and the properties of the type of object you have selected.

All objects that you can place on a label have common properties, such as height and width, location, and color. Some objects have properties unique to their type, such as text alignment (text objects), or bar code symbology (bar code objects). So while all the **Properties** screens have many options in common, they have different titles and also offer different options for each type of object.

The Properties screens and tabs displayed for each type of object are:

Text objects	Text Properties screen, with tabs: General Size and Location Font Placement Options
Variable text objects	Text Properties screen, with tabs: General Size and Location Font Placement Options

Bar Code objects	Bar Code Properties screen, with tabs: General Size and Location Font Placement Options
Graphic objects	Graphic Properties screen, with tabs: General Size and Location
Hot Shape objects	HotShape Properties screen, labelled according to the HotShape selected, with tabs: General Size and Location

The type of system you have also determines the options offered on each tab. For instance, the **Cut out object** option does not appear at all on the **Properties** screens of the Monocolor or Multicolor systems. Only Color & Cut systems contain the **Cut out object** option. Also, some options may be shown on the screen, but appear to be grayed out, which means they are unavailable for your system or for that object type.

Hint! For text objects and HotShape objects, you can change a print object to a cut out object and vice-versa. Go to the **General** tab on the object's **Properties** screen and choose the appropriate option.

Remember, however, that no object can be both a print object and a cut out object at the same time, so if you change a print object to a cut out, you need to change it back again before you can print it again. See **CHAPTER 10: Working with Cut-outs**, for more information.

To change object properties

1. With your label displayed in the **Editor** window, select the object you want to change, using any of the methods described in Selecting Objects on page 7-25.
2. Choose **Object Properties** from the toolbar, or press Object Properties.



You'll see the a **Properties** screen with tabs and options appropriate to the object selected. This is a sample Text Properties screen:




Figure 7-18. A generic Properties General tab.

The values shown on the screen are the current values of the selected text object.

Note: Object Properties screens are not accessible from the Pipe Marker or Right-To-Know applications. You must use the **Preferences** key to change properties for those specialty applications.

Setting options on the General tab

The **General** tab appears on the **Properties** screens for every type of object. Use the options on the **General** tab to set the rotation, the fill, the cut options, the line width, and to begin the select color process

Note: As noted below, options offered on the **General** tab vary according to your system features.

The **General** tab options are:

<p>Rotation</p>	<p><i>For all systems.</i> Use the scroll arrows to choose from the list of rotation angles. For example, to rotate an object 45 degrees, choose 45.</p> <p>Note: For bar code objects, the only valid values are 0 and 90 degrees.</p> <p>After rotating an object, you may not set an absolute size for that object. You may, however, use the Increase Size and Decrease Size tools to change the size. (See Using Increase Size and Decrease Size on page 7-28)</p>
<p>No fill/Solid fill</p>	<p><i>These options appear on the HotShape Properties General tab only.</i> Select to set the default fill for the HotShape object. The fill is the background pattern inside the object. Choose:</p> <ul style="list-style-type: none"> • No fill to leave objects transparent. • Solid fill to make the background inside the object a solid color.
<p>Print/Cut out</p>	<p><i>For the Color & Cut system only.</i> Set to indicate that the object is for printing or to be cut out. In the Monocolor and Multicolor systems, print object is the only option. See Creating Cut Out Objects on page 10-3 for complete information.</p>
<p>Cut bounding box</p>	<p><i>For the Color & Cut system only.</i> Use to apply a bounding box to a print object, so the object can be cut out.</p>
<p>Weeding</p>	<p><i>For the Color & Cut system only.</i> Use to apply a cut around the outside of a cut text object. You can then strip the waste from around the text.</p>
<p>Line width field</p>	<p><i>For all systems.</i> Use to set and to view a line width for a frame for a text object. The default is 0, which indicates that the object is not framed. A sample of the line width you select is shown next to the field. See Figure 7-18 on page 7-34.</p>

<p>Select color button</p>	<p><i>For all systems.</i> Select to change colors for the object. See Applying Color to Objects on page 8-5.</p> <p>Note: You may not change the colors of a multi-color graphic object supplied by the system. You may, however, change the entire color of a single-color graphic.</p>
-----------------------------------	---

Setting options on the Size and Location tab

The **Size and Location** tab appears on **Properties** screens of all object types. Use its options to set the height, width, and location of an object. The following is an example of a (**HotShape**) **Circle Properties Size and Location** tab screen:




Figure 7-19. The Circle Properties Size and Location tab.

To set the size of an object

You can set the **absolute size** of most objects by setting the height and width on the **Size and Location** tab. When you set an absolute size for an object, that object remains the same size regardless of other operations you perform.

Note: If you previously rotated an object, the **Size** options are not available on the **Size and Location** tab.

1. Select an object.

2. Press Object Properties to get to the object's **Properties** screen.
3. Choose the **Size and Location** tab.

Note: To set height and width for bar code objects, we recommend that you use the options on the **Bar Code** screen **Dimensions** tab instead of the **Size and Location** tab. See Adding bar code objects on page 7-17 for more information.

4. Enter a height in inches or millimeters in the **Height** field.
5. Enter a width in inches or millimeters in the **Width** field.
6. When you complete all settings changes on the **Size and Location** tab, click **OK**. The size you set becomes the default size for the object.

To set the location of an object

The advantage to using the options on the **Size and Location** tab to set the location for an object is that you can choose a precise location. This is useful for laying out complex labels, or when you want to line up multiple objects on a label.

To set location, think of the screen as a grid with the origin of 0,0 at the upper left corner of the printable area of the label.

For example, if you set the **Left** field to two inches and the **Top** field to one inch, the object prints two inches from the left of the label and one inch from the top of the label.

Note: If you previously rotated an object, the **Location** options are not available.

1. Press Object Properties to get to the object's **Properties** screen.
2. Choose the **Size and Location** tab.
3. In the **Left** field, enter the number of inches or millimeters from the left side of the printable area where you want to locate the object.
4. In the **Top** field, enter the number of inches or millimeters from the top of the printable area where you want to locate the object.
5. If you have completed all settings changes, click **OK**. The location you set becomes the default location for the object.

Setting options on the Font tab

Use the **Font** tab to change the font options for the selected text object. The **Font** tab is included on the **Text Properties** screen and on the **Bar Code Properties** screen.

Note: Changes you make using the **Font** tab options apply to the entire text object, and may override formatting changes you previously made to the text characters.




Figure 7-20. The Text Properties Font tab.

The options are:

Font	Lists the fonts installed on your system. As you select a font, a preview displays in the Font Preview box.
B	Bolds all the text in the entire object.
<i>I</i>	<i>Italicizes</i> the text in the object.
<u>U</u>	<u>Underlines</u> the text in the object.
Size (+ or -)	Determines the size of the characters. Setting the type size here makes the characters larger or smaller both on the screen and on the printed label as well.

Setting options on the Placement tab

Use the options on the **Placement** tab to set justification and position for text objects.




Figure 7-21. The Text Properties Placement tab.

Justification determines the horizontal alignment for a text object in your label. Choose:

- **Left** for traditional left-to-right justification, with text positioned against the left side of the text object
- **Center** to position the text in the horizontal center of the text object
- **Right** to position the text against the right side of the text object

Position determines the vertical alignment of a text object in the label. Choose:

- **Top** to position the text at the top of the text object
- **Middle** to position the text in the middle of the text object
- **Bottom** to position the text at the bottom of the text object

This sample label demonstrates both justification and position.



Setting options on the Options tab

Use the options on the object **Text Properties** screen's **Options** tab to set various text object properties:






Figure 7-22. The Text Properties Option tab.

The options are:

Free form text object	Choose to indicate that the selected text is a <i>free form text object</i> , which means that the object size is based on the amount and the size of the text inside. If you change the amount of text inside, the object size changes too. This type of text object is the opposite of a <i>text object with boundaries</i> .
------------------------------	---

<p>Text object with boundaries</p>	<p>Choose to indicate that the text object has set boundaries. This type of text object is the opposite of a <i>free form text object</i>.</p>
<p>Expand/Condense text</p>	<p>Create text, and then expand and condense text horizontally according to the percentage selected. Applicable percentages are</p> <ul style="list-style-type: none"> ● · 25% ● · 50% ● · 75% ● · 150% ● · 200% <p>If you select Free form text object or Text object with boundaries, the percentage combo box will be inactive.</p> <p>If you change the expand/condense text option to either Free form text object or Text object with boundaries, the default type size in the Font tab (text properties) will be used.</p>
<p>Auto size font</p>	<p>Available only when a <i>text object with boundaries</i> is selected. Choose to tell the application to automatically set the point size of the text to fit within the text object. The appropriate point size is implemented for your text.</p> <p>The limiting dimension is determined by the width or height of the text. When the text meets either the horizontal or vertical boundary, the sizing stops.</p> <p>In <i>variable text objects</i>, the text object size will be the same for each label generated, but the size of the font may vary, depending on the amount of text needed to fill the text object. For example, if “fox” and “elephant” are items in a text list, “fox” prints in a larger font size than “elephant.”</p> <p>If you change the font size yourself, for instance by using the Size option on the Font tab, the system disables the Auto size font option.</p> <p>Note: This option is disabled for free form text objects.</p>

<p>Reverse text colors</p>	<p>Choose to reverse the text and background colors on your label. The text assumes the background color, and the background assumes the text color.</p> <ul style="list-style-type: none"> • Reverse text colors option OFF: <div data-bbox="753 306 959 407" style="text-align: center;">  </div> <ul style="list-style-type: none"> • Reverse text colors option ON: <div data-bbox="758 488 959 581" style="text-align: center;">  </div>
<p>Vertical text</p>	<p>A B C D E</p> <p>Choose to format the text vertically instead of horizontally on your label. The system automatically center-justifies vertical text, so the characters are aligned down the center of the text box, as shown here</p> <p>Hint!<i>Free form text</i> works best with this option, but you are not restricted from applying it to <i>text with boundaries</i>.</p>

Setting options on the Content tab

Please refer to Adding bar code objects on page 7-17 for information about the **Content** tab.

Setting options on the Dimensions tab

Please refer to Adding bar code objects on page 7-17 for information about the **Dimensions** tab.

Applying Color

You apply color to your labels in several ways, depending on your system and the supplies you have installed.

The topics that follow in this chapter tell you how to compose color labels:

- ❑ **About Color**
- ❑ **Applying Color to Objects**
- ❑ **Printing Color**

About Color

You determine the color choices for your labels by the supplies you install.

When you compose a label, the system uses the ribbon supply installed in your printer to determine which colors you can select for print colors, and the tape supply to determine the background color. The information your system needs is stored in the memory cell flag located on each ribbon and tape cartridge. The system reads that information each time you:

- Turn on the system
- Retrieve a file stored in memory
- Change the tape or ribbon
- Print any label

When you print a label, the system checks the contents and size of the label against what it knows about the ribbon that is installed. If the job requires that you install different or additional ribbons or tapes, the system prompts you to do so at the appropriate time in the print process.

The system also checks the label background color against the installed tape color, and may display a warning message if there is a discrepancy.

Hint! Be sure to see the **Checking Supplies** section in the **Printing** chapter, beginning on page 11-10, for important information about how your ribbon and tape choices affect the way your label prints.

Ribbon color

The ribbon you install determines the color choices you have for the objects you place in your labels. Depending on your system, you can use several types of ribbon:

- Continuous single color ribbon**, which contains one color throughout the length of the entire ribbon. All three systems can use this type ribbon. This type ribbon is sometimes referred to as “monochrome,” because it contains a single color.
- Paneled ribbon**, which has two or four colors and always includes black. The panels are arranged sequentially in 8 inch (203 mm) or 16 inch (406 mm) lengths on each ribbon. The printer makes multiple passes over the tape to print those colors on the label. Only the Multicolor and the Color & Cut systems can use paneled ribbons.

- ❑ **CYMK paneled ribbon**, which has cyan, yellow, magenta, and black panels of 8 inches (203 mm) or 16 inches (406 mm). The printer uses all four color panels to produce 23 blended colors on your labels. Only the Multicolor and the Color & Cut systems can use CYMK ribbons.
- ❑ **Continuous process color ribbon**, which contains cyan, yellow, magenta, and black in a continuous ribbon and produces blended colors. Only the Multicolor and the Color & Cut systems can use Continuous process color ribbons.

Depending on the ribbon installed, you can produce several types of color on your printed labels:

- ❑ **Single color** uses a continuous single color ribbon or one of the colors in a paneled ribbon:
 - With the Monochrome system, the system prints the entire label with the installed monochrome ribbon.
 - With the Multicolor and Color & Cut systems, the system prompts you for the correct color ribbons, if you applied multiple colors when composing your label.

Note: If all objects on the label are the same color, the system prints with the installed monochrome ribbon, even if the color of the ribbon does not match the color of the objects.

- ❑ **Spot color** uses solid color ribbons, either paneled ribbons or continuous single color ribbons that you must swap in when required. Spot colors print without blending with other colors to achieve the desired output color.
- ❑ **Blended color** uses the cyan, magenta, yellow, and black CYMK ribbons, either paneled or continuous, that print in combination with each other to achieve 23 pre-defined blended colors, including black. This is sometimes referred to as *full color* printing.

In summary, your system and the installed ribbon together determine what kind of color you can apply to objects when composing a label:

System:	Produces:
Monocolor model	<ul style="list-style-type: none"> ● single color, using continuous color ribbons or one of the colors in a paneled ribbon
Multicolor model	<ul style="list-style-type: none"> ● single color, using continuous color ribbons or one of the colors in a paneled ribbon ● multiple spot colors, using paneled or continuous single color ribbons ● blended color, using CYMK paneled ribbons or continuous process color ribbons
Color & Cut model	<ul style="list-style-type: none"> ● single color, using continuous color ribbons or one of the colors in a paneled ribbon ● multiple spot colors, using paneled or continuous single color ribbons ● blended color, using CYMK paneled ribbons or continuous process color ribbons

Tape color

The tape you have installed in your system determines the background color of your labels. The system assumes that the tape color you install is the background color you want to use on your label.

Some template-driven applications may require specific background colors for the template you choose. If you have the wrong color tape installed for that template, at print time the system prompts you to install the correct color tape.

Applying Color to Objects

Your color choices and how you can use color for objects in your labels depend on your system and the ribbon you have installed.

- **With the Monocolor system**, you can change the color of an object from the print color to the background color, and vice-versa. This means, for example, that if you have a red ribbon with a white tape supply, you can:

Print the label with the object in red with a white background


or

Print the label with the object in white with a red background.

Hint! You can also inadvertently make an object disappear, if you make it the same color as the background.

- **With the Multicolor system**, you can print monochrome, spot color, and full color.
- **With the Color & Cut system**, you can print monochrome, spot color, and full color.

With all systems, to apply color to an object, you select the object and use whichever of these three methods is available:

- Press **<Object Color>** on the keyboard.
- Choose **Object Color** on the toolbar, shown here: 
- Select the **Color** option, which appears on the **Font** screen that is displayed when you press the **Font** button on the **Enter Text** screen.

In all three cases, you'll see **Object Color** screen.

About the Object Color screen

When you compose a label, the drawing color defaults to black regardless of the color or type of ribbon you currently have installed. You can select a color for the object on the Object Color screen, which provides different options depending on your system and the ribbon supplies you have installed.

Note: You may not change the colors of a multi-color graphic object supplied by the system. You may, however, change the entire color of a single-color graphic.

The **Object Color** screen differs according to your system and the ribbon you have installed.

Choosing color on the Monocolor system

When you have the Monocolor system, if you select an object and choose the **Color** option, the **Object Color** screen displays, similar to the one shown here:




Figure 8-1. The Object Color screen for the Monocolor system.

In Figure 8-1, the installed ribbon is a continuous color ribbon, and the installed tape is white.

When you click on one of the color boxes, the **Current color** field displays a sample of that color, and tells you what part of your label will print in that color.

Note: Tape always appears as a white background while the ribbon appears as black on the screen display.

Choosing color on the Multicolor and Color & Cut systems

If you have the Multicolor or the Color & Cut system, the options offered on the **Object Color** screen also depend on the type of ribbon installed at the time you choose the **Color** option.

Note: The Autocut function cannot be applied in multicolor mode.

If you swap in a different ribbon during construction of the label or while editing it, the **Object Color** screen changes according to the characteristics of the new ribbon, as described in the following sections.

With a continuous color ribbon installed

The **Object Color** screen looks similar to Figure 8-2 when you have a continuous color ribbon installed on your Multicolor or Color & Cut system:




Figure 8-2. Object Color screen, continuous color ribbon on the Color & Cut system.

Hint! Use this screen to set object colors at composition time without having to swap in each ribbon. You won't have to swap in the different ribbons until you print the label.

The color boxes show the continuous color ribbons available (including the currently installed ribbon). The **Current color** field shows the color of the currently selected object, or if there is no object selected, the current print color.

Important! If you are using a new supply color that you have not yet named, it will not show on this screen. See **Naming supply colors** on page 5-9 for instructions on how to make your system recognize new colors.

The final box in the series in Figure 8-2 shows the background color. When you choose that box, the **Current Color** text changes to “Background.”

See **Ribbon and color choices** on page 11-15 for more information.

With a paneled ribbon installed

The **Object Color** screen looks similar to this when you have a paneled ribbon installed:




Figure 8-3. The Object Color screen with paneled ribbon on the Color & Cut systems.

This screen shows you the colors available on the paneled ribbon you have installed. Choose a box to select a color for the object you have selected. The **Current color** field shows the color of the currently selected object, or if no object is selected, the print color.

The final box in the series shows the color of the currently installed tape. If you choose that box, the Current Color text changes to “Background.”

The panel length of the currently installed ribbon is shown at the top of the screen in the **Installed Ribbon** field. See **Checking Length** on page 11-12 for information about how panel length affects your label length.

With a CYMK ribbon installed

The **Object Color** screen looks like this when you have a CYMK ribbon installed:




Figure 8-4. The Object Color screen with CYMK ribbon on the Color & Cut systems.

You can choose any of the colors on this screen for your selected object, except the final box in the series, which is the background (or tape supply) color. The **Current color:** field shows you the color and the name of the color you select, unless you choose the background color. In that case, the text indicates “Background.” The **Installed ribbon** field shows the panel length for the ribbon installed your machine.

See **Checking Length** on page 11-12 for information about how panel length affects your label length.

Printing Color

See **CHAPTER 11: Printing**, beginning on page 11-1, for complete information on printing your labels.

Working with Files

This chapter explains how to store labels you create on your system so you can access them another time. You store them as *files*, and you organize the files in *file groups*. Topics in this chapter include:

- About Files and File Groups**
- Saving Labels as Files**
- Managing Files**
- Printing Files**
- Transferring Files**
- Using My Templates**

About Files and File Groups

When you store a label, you name it and **save** it, and it becomes a **file** on which you can then perform several operations. (You can also save multiple labels in a single file, such as when you create a label set or when you create labels with variable text. Refer to **Creating Sets of Labels** on page 6-21 for information on label sets, and to **Adding variable text objects** on page 7-10 for information on variable text labels.)

When you save a file, the system prompts you to put it into a **file group**. Ideally, your file groups contain labels with similar characteristics, such as subject, orientation, or size, but you can group any files together in a file group.

Hint! If you plan to print all the files in the file group in the same print job, it's best if the files are set in the same orientation and use the same supplies. See **Printing labels in a file group** on page 11-7 for more specific information.

The system saves the files in file groups in an internal storage area or on a memory card attached to your system. (You can also save file groups to a PC. See **CHAPTER 12: Connecting to a PC**, beginning on page 12-1, for more information.)

Once you save a label as a file in a file group, you can:

- Open it
- Add objects to it or remove objects from it
- Print it by itself or print its entire file group at the same time
- Create a new file of the same type
- Delete it

Saving Labels as Files

Every time you create a Custom label or a pre-designed template label, you have the option to save it as a file and to put it in a file group, so you can access it later.

Your label file is like a paper document you put in your file cabinet, and file groups are like the file folders in which you put your papers. You can organize similar label files into file groups in the same way as you organize similar paper files into file folders.

When you have an open, unsaved label displayed in the **Editor** window, there are two ways to save labels as files:

- By using the <**Menu**> key and following the prompts
- By using the <**File Option**> key and following the prompts.

There are two places you can save files as well:

- In your system's internal memory
- On a compact flash memory card attached to your system. (See **Installing a compact flash memory card** on page 2-13 for information.)

Hint! You can also save files to a PC if you are connected to one. See **CHAPTER 12: Connecting to a PC**, beginning on page 12-1, for instructions.

To save a label as a file in internal memory

1. With the unsaved label displayed in the **Editor** window, press <**File Options**>. You'll see the **File Options** screen:




Figure 9-1. The File Options screen.

1. Choose **Save File**. You'll see the **Save in Group** screen:




Figure 9-2. The Save in Group screen.

- The default group displayed in the **New file group** field is the name of the application you used to create the file. You have several choices for the **New file group** field:
 - Accept the default as the name for the group
 - Enter a new name.
 - Choose a name from the list of existing groups.

Hint! If your label doesn't fit into any particular category, you may find it useful to create a general group like "My Saved Files."

- Select **Next** when you have completed the **Save in Group** screen. (If you choose **Cancel**, the Save process is interrupted and you are returned to the **Editor** window.)

You'll see the **Save File** screen:




Figure 9-3. The Save File screen.

If you have previously saved files in that File group, you'll see them listed in the **Saved files** box.

The system displays a thumbnail view of the label highlighted on the **Saved files** list.

- Type a name for your new file in the **File name** field.

Hint! You can select a name for your new file from the **Saved files** list instead of typing a new name, but be careful not to overwrite an existing label you

want to keep. If you respond **Yes** when the system asks you if you really want to replace the old file, the system discards the old saved label and puts the new saved label in its place. You cannot recover the discarded file.

5. Choose **OK** when you have named your file. The system saves the new file and filename.
 - If you choose **Cancel**, no file is created and you'll see the unsaved file on the **Editor** window.
 - If you choose **Back**, you'll see the **Save in Group** screen again, where you can change the Group name or choose a different group.

To save a file to a memory card

If your system has a compact flash memory card installed, you can save the file and its file group to the memory card. (See **Installing a compact flash memory card** on page 2-13 for information about memory cards.)

1. With the unsaved label displayed in the **Editor** window, press **<File Options>**. You'll see the **File Options** screen (Figure 9-1).
2. Choose **Save File**. You'll see the **Save in Group** screen:




Figure 9-4. The Save in Group screen with memory card.

3. Enable the **Save group on card** option. When you complete the file saving procedure, the system will save the entire file group to the memory card.

Note that existing file groups you previously saved on memory cards are designated with **(card)** after their names.

4. Choose **OK**. You'll see the **Save File** screen (Figure 9-3).
5. Enter a name for the file in the **File name** field.
6. Choose **OK**. The system saves the file and the file group to the memory card.

Managing Files

You can open, edit, delete, or save the files you create to new groups.

Hint! You can also print all or some of the files in a file group at the same time. See **Printing labels in a file group** on page 11-7

Opening saved label files

You can open files from the **Main Menu** screen or from within the **Editor** window. Once the file is open and the label is displayed in the **Editor** window, you can edit it, print it, add new labels, and do anything else you can do to a newly-created file.

Note: When you open a saved file, you should be aware that the label in the file may not match the size and color of currently installed tape. When that is the case, the system displays the label with the characteristics of the current tape. You may still proceed to make changes, print, or perform any operations you can perform in the **Editor** window.

To open a file from the Main Menu screen

1. Choose the **Saved Files** option. You'll see the **File Groups** screen, which lists all file groups you have previously saved:



Figure 9-5. The File Groups screen with memory card.

If you have a memory card attached, the **File Groups** screen lists the file groups saved on the card also. Those groups are listed with **(card)** shown after the group name.

If you have no files saved yet, the **Group name** list is blank, and the **Next** button is disabled.

2. Choose the group in which you stored your file.
3. Press **Next**. (If you change your mind, press **Cancel** to return to the **Main Menu** screen.)

4. You'll see the **Open File** screen:




Figure 9-6. The Open File screen.

5. Select the file you want to open on the **Select file** list.
6. Press **OK** to open the file. You'll see the label (or the first label if the file contains a series of labels) from the file you opened displayed in the **Editor** window.

Alternatively, you can:

- Choose **Cancel** to cancel the operation and return to the **Main Menu** screen.
- Choose **Back** to return to the previous screen.

To open a file from the Editor window

1. While in the **Editor** window, press the **<File Options>** key. You'll see the **File Options** screen shown in Figure 9-1 on page 9-4.

2. Choose **Open Saved File**. If you have an unsaved label currently displayed, the system prompts you to save it or to discard it:



Figure 9-7. The Save Changes prompt.

(If you choose **Yes**, you'll be prompted for File Group and File Name, as described in **Saving Labels as Files** on page 9-3.)

3. After you deal with any unsaved labels, you'll see the **File Groups** screen, shown in Figure 9-5 on page 9-8.
4. Choose the File Group in which the label file is stored, then choose **OK**. You'll see the **Open File** screen, shown in Figure 9-6 on page 9-9.
5. Choose the file you want to open, and press **OK**. You'll see the label from the file you opened displayed in the **Editor** window.

Hint! You can also open a saved file from the **Create New Label** screen that displays when you launch an option from the **Main Menu** screen. For an example, see Figure 6-2 on page 6-3.

Editing files

Open the saved label file as described in **Opening saved label files** on page 9-7. Once the label is displayed in the **Editor** window, you can make changes, then print it or re-save it.

See **Opening and editing an object** on page 7-31 and **Changing Label Properties** on page 6-27 for information about editing labels.

Deleting files

When you delete a label file, the system deletes the file either from the internal storage area or from the memory card, if you have one installed.

Note: Use caution when deleting files. Once you delete a file, you cannot recover it.

To delete a label file

1. Press <**File Options**> on the keyboard.
2. On the **File Options** screen (shown in Figure 9-1 on page 9-4), choose **Delete File**. You'll see the **File Groups** screen (Figure 9-5 on page 9-8).
3. From the **Group name** list, select the File group that contains the file you want to delete.
4. Choose **Next**. You'll see the **Delete File** screen:




Figure 9-8. The Delete File screen.

5. Select a file from the **Saved files** list, then choose **OK**. The system deletes the file you selected, then returns you to the **Editor** window.

Printing Files

You can print a single file or you can print an entire file group. For instructions, see **Printing a single label** on page 11-4, **Printing labels in a label set** on page 11-6, and **Printing labels in a file group** on page 11-7.

Transferring Files

You can transfer templates and other kinds of files from a PC to your standalone system. This is useful in instances where you need to be able to use a file that normally resides on your PC on your printer when it is not connected to a PC.

Important! We recommend that only experienced PC users attempt file transfers from a PC to the standalone printer. The underlying file structures are complex and you risk losing data if your attempt is unsuccessful.

See **Transferring Files from a PC** on page 12-8 for information.

Using My Templates



The **My Templates** option on the **Main Menu** screen appears only if you or someone in your organization has previously downloaded, copied, or moved a file to your system using the File Management Utility. (The File Management Utility is the software your system uses to communicate with your PC, when you have one connected.) Otherwise, you will not see it on the **Main Menu**.

See **CHAPTER 12: Connecting to a PC**, beginning on page 12-1 for information about File Management Utility.

Accessing template files

You can access template files you created, or that you or someone in your organization has downloaded to your system, through **My Templates**. You may not access the template files supplied with the applications on your system.

Note: When you download template files to your system for the first time, you must re-start your system before you can use the **My Templates** feature. See **Managing files and folders on a PC** on page 12-10 for instructions.

To access My Template files

1. Choose **My Templates** from the Main Menu screen. The **Select Template** screen displays:




Figure 9-9. The Select Template screen.

2. Choose a template from the list of template files. Note that the preview area displays thumbnails of the selected file.
3. Choose **Next** to begin the template prompt sequence. Complete the prompts as instructed to make the label.

Changing My Template label size

Use the **Change Size** button on the **Select Template** screen (Figure 9-9) to customize the size of the label you are creating.

Note: This option is applicable only if the template is scalable.

Follow the instructions in the section **Changing Labels** on page 6-24.

Working with Cut-outs

If you have the Color & Cut system, read this chapter for information about the cut out functions.

(If you have the Monocolor system or the Multicolor system, the information in this chapter is not applicable to your system.)

This chapter defines and describes the capabilities of the plotter cutter included in your system. Topics include:

- About Cutting**
- Creating Cut Out Objects**
- Cutting Around Objects**
- Cutting Around Label Frames**
- Calibrating the Cutter**

Important! See **Appendix B: Cutter Maintenance** for information about adjusting and replacing the plotter cutter stylus, and for cleaning the plotter cutter stylus.

About Cutting

The term “cut” is used in multiple ways in the Color & Cut system. To help you avoid confusion, the terms as used are defined here:

Cut	The standard Microsoft Windows “Cut” command, which means removing an object from its current location and temporarily storing it for later retrieval. (This term is not used in this chapter.)
Cut out	The action of cutting out objects or text using the plotter cutter inside your printer. The cutter follows the shape of the object or text. An object that is cut out cannot be printed.
Cut out frame	The action of cutting out a label that has been framed. You apply a frame to a label using the Label Properties options (See Adding a label frame - 6-31). The plotter cutter cuts around the outside edge of the frame line. Also, when you apply the Supply Saver option or are printing multiple copies, the system performs this action automatically. (See Supply saver option - 11-21 for more information.)
Cut bounding box	The action of cutting around an object that is enclosed by a cut bounding box. The plotter cutter cuts the box shape, not the shape of the object inside it.
Print	To produce or to output the contents of the current file. For the Color & Cut system, the labels in a file may include both printed objects and cut out objects, even though print objects may only be printed and cut out objects may only be cut out.
Shear	A straight cut through the tape and liner that separates the output label from the remaining tape supply.
Weeding	A cut around the outside of a cut text object.

The Color & Cut system is equipped with a plotter cutter, which means the system can:

- Cut out **objects** that you have designated as a Cut out Object on the **Insert Object** screen. The cutter cuts out the actual shape of the object.

Important! Objects cannot be both print objects and cut out objects at the same time. See **Adding cut out objects - 10-4** for details.

- Cut out around a **cut bounding box** you can create for some print objects. A cut bounding box is a border you can set around objects that you want to print AND cut. See **To apply a cut bounding box to an object - 10-8** for instructions.
- Cut out around a **frame** you add to a label. See **To cut around a label frame - 10-10** for instructions.
- Perform weeding on cut out objects. See **To perform text weeding - 10-6**.

Table 10-1 shows your cutting options, listed by item:

TABLE 10-1. Cut options.

Item	Can be cut out (not printed)	Can be printed and cut around
Text object	Yes	Yes
Graphic object <ul style="list-style-type: none">• Most Adobe Illustrator[®] vector graphics• Bitmap and vector graphics	Yes No	Yes Yes
Bar code object	No	Yes
HotShape object	Yes	Yes
Label frame	No	Yes

(For additional information about these object types, see **About Objects - 7-2**.)

Creating Cut Out Objects

You create cut out objects by adding them to a label, the same way you create and add print objects. Once you choose the **Cut out object** option, your other choices are limited, however, to objects that may be cut out. See Table 10-1 for a list of those objects

Also, not all tape supplies are appropriate for cutting. If the cutter cannot use the tape installed in your printer, the **Cut out** option on the **Insert Object** screen will be grayed out.

Adding cut out objects

When you add objects to your label, the **Insert Object** screen gives you the choice to insert a Print object or a Cut out object, as shown here:




Figure 10-1. The Insert Object screen on the Color & Cut system.

- If you choose **Print object**, you may only print the object, although in some cases, the object may be *cut around*. See **Cutting Around Objects - 10-8** to learn how to cut around a print object.
- If you choose **Cut out object**, the object may only be cut out, and not printed.

Hint! You can change some existing print objects to cut out objects and vice-versa, by going to the **General** tab on the object's **Properties** screen and choosing the appropriate option. See **Changing Objects** on page 7-31 for instructions.

To create a cut out object



1. From the **Editor** window (shown in **A sample Editor window with cut bounding box displayed. - 10-9**), choose **Insert Object**.

2. On the **Insert Object** screen (Figure 10-1), choose **Cut out object**.
3. Select the type of object you want to cut out. The type you choose determines the screen you will see next:

<u>If you choose:</u>	<u>You'll see:</u>
Text object	<p>The Enter Text screen (Figure 7-3 on page 7-5). You can choose from these fonts for cut out text objects:</p> <ul style="list-style-type: none"> • Arial 65 for BRC • Arial for BRC • Times New Roman for BRC. <p>Only normal text is supported. Cut out text may not be bolded, italicized, or underlined.</p>
Graphic object	The Graphics screen, shown in Figure 7-15 on page 7-23, with special options for cut out graphics listed.
HotShape object	The HotShapes screen, shown in Figure 7-16,

Cutting out text objects

The cutter cuts out each individual character in a Text cut out object.

Hint! See **Weeding cut out text objects - 10-6** to learn how to make an additional cut *around* the cut out text, for ease of use when removing the cut out characters.

To cut out text objects


1. After selecting the **Cut out object** option on the **Insert Objects** screen, choose **Text**.
2. On the **Enter Text** screen (shown in Figure 7-3 on page 7-5), enter the characters you want to cut out.
3. Press **OK** when you're finished. You'll see the cut out new text object on the **Editor** window.
4. Choose **Print** to cut out the object.

Weeding cut out text objects

Your Color & Cut system can perform **weeding** on cut out text objects. Weeding makes it easier for you to strip out waste from around cut text characters.

In the weeding process, the cutter cuts a border around a cut out text object. In a text object with multiple lines of text, each line gets its own cut out border.

To perform text weeding

1. Create a cut out text object as described in the **Cutting out text objects** section above.
2. With the cut out text object displayed in the **Editor** window, select the object.
-  3. Press **Object Properties** or select the **Object Properties** tool.
4. You'll see the **Text Properties** screen, **General** tab:




Figure 10-2. The Text Properties screen for a cut out object

5. Check the **Cut bounding box** option.
6. Check the **Weeding** option.
7. Choose **OK**.
8. Choose **Print** to cut out your label.

Cutting out variable text objects

You might use variable text cut out objects to create and cut out the labels you create for names in a list of names, or to cut out a series of numbers you want to use for marking items. (See **Adding variable text objects** on page 7-10 for more information.)

To cut out variable text objects

1. After selecting the **Cut out object** option on the **Insert Objects** screen, choose **Variable text**.
2. You'll see the **Data Source** screen (shown in Figure 7-6 on page 7-11). Choose:
 - **Sequence** to create Sequential labels, with variable text objects consisting of increasing or decreasing numbers or alphabetic letters. Refer to **Creating sequential labels** on page 7-11.
 - **Text list** to create Text list labels, with variable text objects consisting of a list of items you create. Refer to **Creating text list labels - 7-14**.
3. When the creation sequence is complete and you are back in the **Editor** window, choose **Print** to process the labels and cut out the variable text objects.

Cutting out graphic objects

Not all graphic objects may be specified as cut out objects. The system offers only graphics suitable for cutting out when you choose the **Graphics** button on the **Insert Object** screen, and does not allow you to specify a graphic object as a cut out object if it is not suitable for cutting out.

To cut out graphic objects

1. After selecting the **Cut out object** option on the **Insert Objects** screen, choose **Graphic**.
2. You'll see the **Graphics Categories** screen (shown in Figure 7-14 on page 7-22). Select a category and choose **OK**.
3. You'll see the **Graphics** screen (shown in Figure 7-15 on page 7-23.) Select a graphic and choose **OK**.
4. When the creation sequence is complete, choose **Print**, which processes the labels and cuts out the graphic objects.

Cutting out HotShape objects

HotShapes are especially suited for cutting out. You can cut out stars, circles, arrows, and other shapes. See **Adding HotShapes** on page 7-24 for information about the HotShapes available on your system.

To cut out HotShapes

1. After selecting the **Cut out object** option on the **Insert Objects** screen (Figure 10-1 on page 10-4), choose **HotShapes**.
2. You'll see the **HotShapes** screen. Select the HotShape object you want to add as a cut out.
3. Your HotShape displays on the **Editor** window. Choose **Print** to process the label and cut out the HotShape.

Cutting Around Objects

While objects may not be both print and cut out objects at the same time, there is a way to *cut around* some print objects. You can apply a **cut bounding box** to a print object, which is like adding an invisible border around the object. The system then cuts around the cut bounding box that encloses your print object. You can apply cut bounding boxes to all types of print objects: text, graphics, HotShapes, and even bar codes.

Hint! You can also apply cut bounding boxes to cut out objects, to make it easier to strip the waste material from around the cut out object.

To apply a cut bounding box to an object

1. Create your label in the normal way, adding objects as described in **Adding Objects** on page 7-3.
2. With your label displayed on the **Editor** window, select the object to which you want to apply a cut bounding box. If you have many layered objects on the screen, use <Tab> to cycle through the objects to find the one you want to use. (For more information, see **Selecting a layered object - 7-26.**)



3. Select the **Object Properties** tool or press the **Object Properties** key.

You'll see the **Properties** screen appropriate for the type of object you selected. The values in the fields on the **Properties** screen reflect the current properties of the object selected.

Check the **Cut bounding box** option on the **General** tab, and choose **OK**. Your label displays again in the **Editor** window, with the cut bounding box indicated around the chosen object.




Figure 10-3. A sample Editor window with cut bounding box displayed.

When you print your label, the cutter cuts around the borders of the cut boundary box.

Minimum cut size

When you are ready to print, if any label in the print job contains cut text or cut out objects that are smaller than the minimum recommended size, the **Cut Items Too Small** screen appears:




Figure 10-4. Minimum cut size message.

You can select Yes to continue printing, or No to cancel the job at the offending label. (The printing of all subsequent labels will also be canceled.)

The minimum recommended sizes for cutting are:

Cut text	1/2"
Simple shapes (HotShapes only: rectangle, circle, rounded rectangle, arrow, ellipse, and star)	1/4"
Cut out graphics	1/2"

Cutting Around Label Frames

You can add a frame around the edge of a label in the shape of a rectangle or a rectangle with rounded corners. If you have the Color & Cut system, you can also choose to cut the label around the frame boundaries.

To cut around a label frame

1. After you have created your label and it is displayed in the **Editor** window, press the **Label Properties** key. You'll see the **Label Properties** screen, which has a **Size** tab and a **Frame** tab.

2. Choose the **Frame** tab:




Figure 10-5. The Label Properties screen, Frame tab., on the Color & Cut system.

3. Select a Frame shape option: **Rectangle** or **Rounded rectangle**.
4. Check the **Cut out frame** option.
5. When you finish setting Label Properties options, click **OK**. See **Adding a label frame - 6-31** for detailed information about the **Label Properties** options.

Calibrating the Cutter

If your cuts are not aligned correctly, you can adjust the plotter cutter calibration values previously set at the factory. You begin by using the **Setup** option on the **Main Menu** screen to calibrate the cutter.

Setting cutter calibration values

When you enter values in the Cutter Calibration fields, the values must be positive or negative whole numbers. Each increment of the number adjusts the cut made by .001 inch. For instance:

- 1 sets a positive change of .001 inch (.0025 mm)
- 1 sets a negative change of .001 inch (.0025 mm)
- 2 sets a positive change of .002 inch (.005 mm)
- 2 sets a negative change of .002 inches (.005 mm)

Where the change occurs depends upon the field you set:

In the **Horizontal(x)** field:

- Positive values adjust the cutter toward the machine.
- Negative values adjust the cutter toward the leading edge of the tape.

In the **Vertical(y)** field:

- Positive values adjust the cutter toward the bottom edge of the tape.
- Negative values adjust the cutter toward the top edge of the tape.

Figure 10-6 may help show how your calibrations affect your labels. The intersection of the x,y axes represents the center point of your label:




Figure 10-6. Cutter calibration axes

To calibrate the cutter

1. On the **Main Menu** screen, select **Setup**.
2. On the **System Setup** screen, choose the **Hardware** tab:




Figure 10-7. The System Setup Hardware tab

Hint! Write down the values (which were individually set at the factory) before you change them, in case you want to restore the defaults.

3. Enter a value in the **Horizontal (x)** field. The value must be a positive or negative whole number.
4. Enter a value in the **Vertical (y)** field. The value must be a positive or negative whole number.
5. Choose **OK**.

Note: You must close down and restart your printer for new settings to take effect.

Restoring default cutter calibration settings

To restore factory set calibration settings, you must re-enter the original values on the **Hardware** tab. Your system ships with a label inside the printer applied at the factory that lists those values.

To restore default calibration settings

1. Locate the factory-installed label on your machine.
2. On the **Main Menu** screen, select **Setup**.
3. On the **System Setup** screen, choose the **Hardware** tab.
4. Enter the original value in the **Horizontal (x)** field.
5. Enter the original value in the **Vertical (y)** field.
6. Choose **OK**.

Printing

This chapter tells you how to print the labels you create. Topics include:

- Printing Labels**
- Checking Supplies**
- Checking Size**
- Checking Length**
- Checking Color**
- Printing Tab Options**
- Canceling a Print Job**

Printing Labels



Most of the time, printing a label is a very simple process. When you finish creating a label or have opened a saved label, with the label displayed in the **Editor** window, you press the Print key or choose the **Print** tool (shown here at the left).

You may print a single label or multiple copies of a single label, or all labels in a label set, including variable text labels. You can also use Advanced print features to print partial label sets or file groups.

The processes described here assume that the supplies installed in your printer match the label you want to print. See **Checking Supplies** on page 11-10 for information about how the system prompts for supplies when it processes jobs, and what you do to meet the requirements.

About pages


You'll see references to **pages** in the print discussions that follow. It's helpful to understand that a page is not the same as a label, especially if you print multiple small labels or entire file groups. Information about both those cases follow in the sections in this chapter. (For the majority of print jobs, one page contains one label.)

A page is the area between the leading edge of the tape (where the label starts), and the shear cut. A page can contain one or more than one label, and the minimum size for a page is two inches or 51 mm. See Figure 11-1 and Figure 11-2 for illustrations of pages.

Hint! The **shear** cut is the straight cut your system makes through the tape and liner. This cut separates the output label from the remaining tape supply.

Single label on a page

For most print jobs, one page contains one label. A label may or may not use up an entire page. For example, if the label you create is shorter than the two inch (51mm) minimum page length, the label and page print like this:



A single page

Figure 11-1. Sample short label.

Note: The label length and shear lines in Figure 11-1 are shown to illustrate the concepts discussed here. Those lines will not display on your screen.

Since two inches (51 mm) is the minimum supply length the system permits for reliable delivery of a label, the shear cut is at two inches, although your label is only one inch long. (You will need to trim the excess supply by hand.) See **Checking Length** on page 11-12 for more information.

Multiple labels on a page

You may print multiple labels on a single page when the **Supply saver** option on the **Printing** tab of either the **System Setup** screen or the **Preferences** screen is enabled. (See **Supply saver option** on page 11-21 for more information.)

For example, if you submitted a print job for five copies of this label, and the **Supply saver** option is ON, the output looks like this:




Figure 11-2. Sample labels with Supply saver option enabled.

Printing a single label

Printing a single label is a simple two-step process.



1. With the label you want to print displayed in the **Editor** window, press **Print** or choose the **Print** tool on the toolbar. You'll see the **Print** screen:




Figure 11-3. The Print screen.

2. Choose **OK**. You'll see the **Preparing to Print** screen while the printer processes your label.




Figure 11-4. The Preparing to Print screen.

The printer prints, shears, and delivers your label.

Note: If any label in the print job contains cut text or cut out objects that are smaller than the minimum recommended size, the **Cut Items Too Small** screen appears. You have the option of continuing to print the label or canceling the print job. (See **Minimum cut size** on page 10-9.)

Printing multiple copies of a single label

This process requires a single additional step:

1. With the label you want to print displayed in the **Editor** window, press **Print**. You'll see the **Print** screen (Figure 11-3).
2. Enter the number of copies of the label you want to print in the **Copies** field.
3. Choose **OK**. You'll see the **Preparing to Print** screen (Figure 11-4), which tracks the system's progress as it processes each of the copies.

Note: If the **Supply saver** option is set to ON in the **Printing** tab screen, the total number of labels shown in the **Label** field may look incorrect. This is because the printer is counting the total number of *pages* in the job instead of the number of labels, and it may be possible to fit more than one label

on a page. See **About pages** on page 11-2 and **Supply saver option** on page 11-21 for more information.

Printing labels in a label set

When you know in advance that you want to print a group of labels all at the same time, you can create a label *set*. The section **Creating Sets of Labels** on page 6-22 tells you how to create label sets. (Be sure to note the guidelines to follow when creating the set to assure the print job will go smoothly.)

The following procedures describe how to print a set of labels or part of a set of labels.

To print a label set

1. When the label set is complete (see **Creating Sets of Labels** on page 6-22), choose **Print** . The **Print** screen displays, as shown in Figure 11-3.

The default setting of 1 in the **Copies** field means that the printer will print one copy of each label in the set. You can make multiple copies of each label in the set by changing this number.

2. Choose **OK** on the **Print** screen to start the print job. You'll see the **Preparing to Print** screen (Figure 11-4), which tracks the system's progress as it processes each of the labels in the set.

To print a subset of a label set

Use this procedure when you do not want to print all labels in a label set.

1. When the label set is complete (see **Creating Sets of Labels** on page 6-22), or you have opened a file containing a label set, choose **Print** . The **Print** screen displays, as shown in Figure 11-3.

2. Choose the **Advanced** button. You'll see the **Advanced Print** screen:




Figure 11-5. The Advanced Print screen for label sets.

3. In the **Labels from** field, enter the number of the first label in the set you want to print. In the **to:** field, enter the number of the final label you want to print.
4. Choose **OK**. You'll see the **Print** screen (Figure 11-3) again.
5. Choose **OK** on the **Print** screen to start the print job. You'll see the **Preparing to Print** screen (Figure 11-4), which tracks the system's progress as it processes the labels in the set you chose to print.

Printing labels in a file group

When you save labels as files, the system automatically prompts you to classify them into **file groups**. One of the advantages of saving similar files into the same file group is that you can save time by printing all label files in the group at the same time. You print file groups using the **Advanced** features available from the **Print** screen.

Hint! If you plan to print all the files in a file group in the same print job, for best results, set the labels in the files in the same orientation, and use the same ribbon and tape supplies.

Note that some restrictions apply when you print file groups:

- You may not choose a range of files to print when printing a file group. You must print all files in a file group, or only a single file from the group.
- Do not mix label application types within file groups. Labels created using the QuickText, Pipe Marker, and Right-to-Know applications will not print with the file group if labels from other applications are included in that group. You may still print those labels individually, of course.
- For best results, do not plan to swap paneled and continuous color ribbons within the same print job.

To print labels in a file group

1. With any file from the group you want to print open in the **Editor** window, press **Print**. You'll see the **Print** screen (Figure 11-3).
2. On the **Print** screen, enter the number of copies you want for **each** label in the file group.

Hint! The printer assumes the number of copies you enter applies to every label in the file group, including any files in the group that generate multiple labels.

3. Choose **Advanced**. You'll see the **Advanced Print** screen, with your current File group shown named on the screen:




Figure 11-6. The Advanced Print screen with open file group.

4. Choose the **Print files in file group** option. (Note that the Special Print options are now grayed out, and the **File Group** button becomes available.)
5. Choose **OK**. You'll see the **Print** screen (Figure 11-3).
6. Choose **OK** on the **Print** screen. You'll see the **Preparing to Print** screen (Figure 11-4), where you can track the printer's progress while it processes and prints the labels and pages in the file group.

To print a different file group

You can actually print any file group when you have any label displayed in the **Editor** window. It just requires a couple more steps:

1. Follow steps 1-4 in the **To print a file group** procedure above.
2. Choose the **File Group** button. You'll see the **File Groups** screen:




Figure 11-7. The File Groups screen.

3. Choose the file group that contains the files you want to print, then **OK**. The **Advanced Print** screen displays again, now with the name of the file group you selected displayed on the screen.




Figure 11-8. The Advanced Print screen for File Group printing.

4. Choose **OK**. You are returned to the **Print** screen (Figure 11-3).
5. Choose **OK** on the **Print** screen to start the print job. You'll see the **Preparing to Print** screen (Figure 11-4), which tracks the system's progress as it processes and prints each file in the file group.

Checking Supplies

When you choose **OK** to start a print job, the system checks the current label for size, length, and color against the supplies installed. The information your system needs is stored in the memory cell flag located on each ribbon and tape cartridge. The system reads that information every time you print any label.

If the installed supplies are not adequate or appropriate for the print job, in most cases you'll see a system message describing the problem, and prompts for the required supplies. But keep in mind that it's always a good idea to install the supplies you want to print with before you compose a label.

Checking Size

First, the system checks the **size** of the printable area of the label in the print job against the tape you have installed. The printable area is what is left after the margins are taken into account. Margins vary according to the size of the tape supply.

Hint! The view of your label on the display screen is a good representation of how it will print. Correct any size discrepancies before printing to avoid wasting supplies.

When an object on a label size extends beyond the printable area of the installed tape, there are two possible results:

- If the label is one you just created, the system prints the label anyway. Objects or portions of objects beyond the printable area of the tape can be truncated.
- If the label is a saved label you have opened to print, the system displays a message prompting you to change the tape supply.

When the label size is smaller than the printable area of the tape, the system proceeds to print your label without displaying messages, but *how* it prints varies according to how many labels the job contains and the system settings:

- If the job has just a *single* label, the system prints the label as is.
- If the job contains *multiple* labels, the system checks the **Supply saver** system setting.

With Supply saver ON, the system saves tape and ribbon by arranging labels of the same size together in the print queue. With the Monocolor system and the Multicolor system, the printer adds dashed lines to show you where to cut the labels apart. On the Color& Cut system, the printer cuts the labels apart for you.

With Supply saver OFF, the system prints the labels in the normal way: one per panel, one at a time.

See **Supply saver option** on page 11-21 for information and examples.

Checking Length

The system uses the ribbon supply installed in your printer to determine the maximum printable length for a label. When you start a print job, the system checks the length of your label page and compares it against the information it records from your ribbon's memory cell flag.

Important! The view of your label on the display screen is usually a reliable representation of how it will print. You should correct any size discrepancies before printing to avoid wasting supplies.

Minimum length

Two inches (51 mm) is the minimum supply length the system permits for reliable delivery of a label. If your label is shorter, the system automatically lengthens the page to meet the required minimum. The content and size of your label on the page remains the same. You can trim off the excess tape by hand.

Hint! If you turn the **Supply Saver** option on, you may be able to print multiple copies of a short label that fill up the two inch minimum page length. For instance, if you printed two copies of the label shown in Figure 11-1 on page 11-3, **Supply saver** would stack them vertically, using up the minimum page area. See **Supply saver option** on page 11-21 for instructions.

Maximum length

The page length the system supports is determined by the installed ribbon. The maximum supported lengths are:

- For single-color label printing using continuous color (monochrome) ribbons, 100 inches or 2540 mm.
- For multi-color label printing using continuous color (monochrome) ribbons, 38 inches or 965 mm.
- For printing using paneled ribbons (both spot-color paneled ribbons and CYMK paneled ribbons), the panel length. Panels are 8 inches (203 mm) or 16 inches (406 mm).

Note: Because a reliable value for the maximum supported cut length has not been determined, the printer will not perform a check prior to printing, to warn you if the label contains cut objects longer than a specific length.

When you create a label with the supply installed that you intend to print with, if the label length is longer than the supported print length of the installed ribbon, you'll be able to see it on your display screen, as shown in Figure 11-9.

Hint! Keep in mind that other changes besides color can affect the length of the label. For example, changing the font size or adding an object may increase the length of the text.

Also keep in mind that in some cases, the printer shows your label as truncated on the screen (as in Figure 11-9) and when you choose Print, it prints the label truncated as shown.

In other cases, the printer displays your label at the length you set it or as set by the template you used to create the label, but when you choose Print, displays a message and does NOT print the label until you correct the length condition.

For example, if you open a file with a label with a set length, the label is displayed with the correct length on the screen. If the label is too long to print on the current supply, you'll see a message telling you so, and you'll be returned to the **Editor** window. You *won't* see the label length truncated on the screen, as shown in **Sample of label too long for installed ribbon.** on page 11-14. You then have the option to:

- Install a longer panel ribbon
- Install a continuous color ribbon
- Shorten the label length

In this case, you must make one of these changes, or you will not be able to print this label.

When the printer truncates labels

Figure 11-9 is an example of a label with an object placed beyond the label length acceptable to the installed ribbon, where the printer will truncate the label when you print it:




Figure 11-9. Sample of label too long for installed ribbon.

For the label shown in Figure 11-9, the installed ribbon is a continuous color monochrome ribbon, and the circles shown are to be printed in various colors, as labeled. This combination carries a maximum supported length restriction of 38". The label shown on the screen is over 38" long. Note that the display indicates the cutoff point at 38".

If you attempt to print this label as it is, the printer truncates the job at the maximum length of 38", without displaying a warning message. The part of the circle that extends beyond 38" does not print, just as shown on the display screen.

Non-truncating conditions

You see the *actual* set label length on your display screen, and the system will not automatically truncate a label that exceeds the maximum length allowed for the supplies installed, under these conditions:

- When you create a label with continuous color ribbon installed, with single color objects, unless the objects you added to the label extend beyond the 100" maximum length for this type print job.
- When the length is set for the label, either by you when you create the label, or by the template you used to create the label.

- When you save your label, then retrieve it again with a panel ribbon installed, you will see the actual set label length indicated on the screen.

In these cases, when you attempt to print the label, the system displays a Label Too Long message, and you must correct the label before proceeding.

Cut out label length

The maximum length for cut out labels is 38" or 965 mm. See **CHAPTER 10: Working with Cut-outs**, beginning on page 10-1, for more information about cut out labels.

Checking Color

When you compose a label, the system uses the ribbon supply installed in your printer to determine which colors you can select. (See **CHAPTER 8: Applying Color**, beginning on page 8-1 for more information.)

When you print the label, after completing the length check described in the preceding section, the system checks your label against what it knows about the ribbon that is installed. If the job requires that you install different or additional ribbons, the system prompts you to do so at the appropriate time in the print process.

Note: For best results, we recommend that you do not plan to swap paneled and continuous color ribbons within the same print job.

The system also checks the label background color against the installed tape color, and displays a warning message if there is a discrepancy.

Ribbon and color choices

Depending on your system, you can use several types of ribbon:

- Continuous single color ribbon**, which is one color throughout the length of the entire ribbon. All three systems can use this type ribbon.
- Paneled ribbon** for spot color, which has two, three, or four colors in panels of 8 inches (203 mm) or 16 inches (406 mm) long on each ribbon. The printer

makes multiple passes over the ribbon to print those colors on the label. Both the Multicolor and the Color & Cut systems use paneled ribbons.

- ❑ **CYMK ribbon**, which has cyan, yellow, magenta, and black panels of 8 inches (203 mm) or 16 inches (406 mm). The printer uses all four color panels to produce a range of blended colors on your labels. The Multicolor and the Color & Cut systems can use CYMK ribbons.

Depending on the ribbon installed, you can produce several types of color on your printed labels:

- ❑ **Single color** uses a continuous single color ribbon or one of the colors in a paneled ribbon. If you apply multiple colors when composing your label:
 - With the Monochrome system, the system prints the entire label with the installed monochrome ribbon.
 - With the Multicolor and Color & Cut systems, the system prompts you for the correct color ribbons.

Note: If all objects on the label are the same color, the system prints with the installed ribbon, even if the color of the ribbon does not match the color of the objects.

- ❑ **Spot color** uses solid color ribbons, either paneled ribbons or continuous single color ribbons that you swap in when required. Spot colors print without blending with other colors to achieve the desired output color.
- ❑ **Blended color** uses the cyan, magenta, yellow, and black CYMK ribbons, either paneled or continuous, that print in combination with each other to achieve pre-defined blended colors. This is sometimes referred to as full color printing.

Hint! When a CYMK ribbon is installed, the system assumes that you want to print in blended color, even if all the objects on your label are the same color. For more efficient use of supplies, you may want to install a continuous color ribbon when you are printing a single color.

In summary, your system and the installed ribbon together determine what kind of color you can produce:

System:	Produces:
Monocolor model	<ul style="list-style-type: none">● single color
Multicolor model	<ul style="list-style-type: none">● single color● multiple spot colors using paneled or continuous single color ribbons● blended color, using CYMK ribbons, paneled ribbons, or continuous single color ribbons
Color & Cut model	<ul style="list-style-type: none">● single color● multiple spot colors using paneled or continuous single color ribbons● blended color, using CYMK ribbons, paneled ribbons, or continuous single color ribbons

Ribbon color needed

When the system needs a different color ribbon installed to complete your print job, it prompts you with a *Color Needed* message that asks you to install the required ribbon, close the printer cover, and click **OK** to continue the print job. This process is sometimes called *swapping* ribbons.

Note: For best printing results, we recommend that you avoid printing entire file groups that contain labels that require ribbon swapping. When printing file groups, the printer takes its information from the first label in the group. The system may not be able to process new ribbon information you add during the print job in time to affect the appropriate label(s).

Substituting ribbon colors

When printing multiple colors by swapping ribbons, you can substitute a different color for the color currently being prompted. If you open and close the printer cover, printing will continue with the current color regardless of whether or not it is the specific color required by the print job:

A series of dots appears on the **Color Needed** screen to indicate that the system is waiting for input, provided you have not installed a new ribbon (by opening and closing the printer cover), or selected the **Continue with Current Ribbon** button. The visual indicator appears on all messages where your input is required to continue. (See **Visual Indicator and Message Box Buttons** on page C-2 for details.)

- If a spot color paneled ribbon is installed when you select **Continue with Current Ribbon**, the next color panel on the ribbon is used to print the requested color.
- If a monochrome ribbon is installed when you select **Continue with Current Ribbon**, the print job continues with that single color.
- If you open and close the printer cover, the printer checks the new ribbon color and resumes printing if the requested color is available. If the requested color is not available on the new ribbon, the **Ribbon Color** prompt appears.

Tape color needed

The system response to tape color differs depending on the kind of label you are printing:

- When you are printing a **template** label and the system needs a different color tape installed to complete the print job, it prompts you with a *Color Needed* message. Install the required tape, close the printer cover, and click **OK** to continue the print job.

Hint! The system does not re-check the memory cell flag at this point to see if you installed the correct tape, but continues the print job with whatever tape is now installed. You may find this useful at times when you want to override the color choice dictated by the template or indicated on the label.

- When you are printing a **custom** label, the system always assumes you want to print using the installed tape, and does not check tape color.
- When you are printing **groups** of labels, for best results, make sure all labels in a group have the same tape supply requirements, including the color requirement. You should address this issue before print time, when creating the label group. See **About Files and File Groups** on page 9-2 for more information.

Checking for cut out labels

Only 4" (102 mm) wide tapes are appropriate for use with the plotter cutter feature in the Color & Cut system.

- If the cut out extends beyond the maximum allowed length or the width of the tape supply, the printer ignores the cut out area of your label. Your display screen shows a reliable representation of the cut out on your label, so you should correct the size problems before proceeding.
- If the cut out is narrower than the tape supply, the printer proceeds with the job.

Note: Not all 4" (102mm) tape supplies are appropriate for cut outs: for instance, magnetic tape may not be cut. Check with your supplier for more information.

Printing Tab Options

The **Printing** tab provides two additional print options:

- **Supply saver**, which saves tape and ribbon by arranging labels on pages
- **Overprinting**, which eliminates the possibility of gaps between colors in some types of print jobs

Accessing the Printing tab options

You can set the **Supply saver** option and the **Overprint** option from the **Main Menu** or, for convenience, from within most applications.

- Use the **System Setup** screen to set the defaults for your entire system. These settings you choose on the tab screens apply to every label you compose (with the exception of Pipe Marker and Right-to-Know labels). See **CHAPTER 5: Setting Preferences**, beginning on page 5-1, for more information.
- Use the **Application Preferences** screen to set the defaults for the system from within most applications. This saves you having to close an application to go back to the **Main Menu**. See **Setting Application Preferences** on page 6-35 for more information.

Note: You can set Printing options for Pipe Marker and Right-to-Know only from within those applications.
QuickText does not allow you to set preferences from within the application.

To set print options from the Main Menu

1. On the **Main Menu** screen (Figure 3-1 on page 3-2), choose **Setup**. You'll see the **System Setup** screen, with the **Printing** tab displayed:




Figure 11-10. The System Setup screen, Printing tab.

2. Set the options as described in the sections that follow.

To set print options from within an application

From within the **Editor** window of any application other than QuickText, press the <**Preferences**> key.

Exception: Access the **Pipe Marker Preference** screen also from the Pipe Marker Style screen. See **Setting Pipe Marker preferences** on page 6-37.

Access the **Right-to-Know Preferences** screen also from the **Right-to-Know Format** screen. See **Setting Right-to-Know preferences** on page 6-38.

Supply saver option

Supply saver printing, which is sometimes called *multiple up* printing, saves tape and ribbon by arranging labels together in the print queue and printing multiple labels on the same page.

This option saves tape because it vertically stacks labels that are smaller than the full width of the tape, so that the full width of the tape is used (see Figure 11-11). It also saves ribbon because it groups labels to print within a set of ribbon panels.

On the Monocolor and Multicolor systems, the printer adds dashed lines to show you where to cut the labels apart. On the Color & Cut system, the system cuts out the individual labels.

Supply saver applies only when:

- You are printing multiple labels. (They do not have to be multiple copies of the same label, as long as they meet the size criteria.)

and

- The labels are smaller than one-half of the printable area (to stack vertically)

or

The labels are shorter than one-half of the length of the panel (to group within a panel length), when you have paneled ribbon installed.

(See **Checking Length** on page 11-12 for information about paneled ribbon restrictions.)

Figure 11-11 and Figure 11-12 below illustrate how you can save tape with **Supply saver** enabled.

Figure 11-11 shows your output with **Supply saver** enabled and an 8" paneled ribbon installed. In this job, you want to print three copies of a single label. The system first checks to see if the labels meet the size criteria. If they do, the system stacks the labels and prints this output:




Figure 11-11. Sample output with Supply saver ON.

Figure 11-12 shows that same print job with the **Supply saver** option disabled. The system prints three consecutive 8” long labels:




Figure 11-12. Sample output with Supply saver OFF.

Overprint option

Overprinting eliminates possible gaps between the color areas and the black areas on your label.

Hint! Try your print jobs with **Overprint** disabled first. If you are unhappy with the results, enable the **Overprint** option.

- **With Overprint enabled**, the system arranges the order in which the colors on your label print so that black prints last and prints over any previously printed colors on objects that overlap.
- **With Overprint disabled**, areas where black is to be applied are left blank until black prints. You may see a slight gap between the color areas and the black areas.

Important! If you are printing using spot color and your label has colored layers over black background objects, be sure to turn **Overprint OFF**. Otherwise, black will obscure the colored layers.

Many users leave **Overprint** enabled at all times. The main disadvantage to using **Overprint** as the default setting is that printing may be slower, because the system takes the time to analyze the colors in the print job and orders them accordingly. You may have to swap ribbons more frequently as well.

Canceling a Print Job

When you start a print job, the **Preparing to Print** screen appears while the application rasterizes the print job:




Figure 11-13. **Preparing to Print** dialog box.

Printing may begin while this dialog box is displayed, before rasterization of the entire job is completed. If you press **Cancel**, printing will stop immediately and the printer will eject and cut off anything that has already printed. The Editor window appears.

The **Preparing to Print** screen disappears after the job is completely rasterized. To cancel a print job that continues to print after this dialog box disappears, press **Alt+F1 (Cancel Print)**.

Note: Pressing **Alt+F1** has the same effect as pressing **Cancel** on the **Preparing to Print** screen: printing stops immediately and anything that has printed is ejected and cut off. For multi-pass print jobs, the entire job is ejected and cut off, regardless of where the printer is in the print pass when the job is canceled.

When you press **Alt+F1**, the *Canceling job* message immediately appears. Upon completion, the *Job canceled* message appears; this message remains until you press **OK**:




Figure 11-14. *Canceling job* and *Job canceled* messages.

You can press **Alt+F1** at any time during printing, regardless of what appears on the screen (for example, main editor window, template prompt sequence, application launcher, error message, etc.).

You can also press **Alt+F1** to cancel a print job from a PC.

Note: For non-keyboard (peripheral-only) connections, you can press **Cancel** on the **On Line Status** screen to quit printing.

If multiple print jobs are stored, pressing **Alt+F1** will cancel all jobs in the printer, whether they are currently printing or being rasterized.

Note: There is one exception. If you print from a PC and the job has not downloaded to the printer, it may start to print after the original print job has been canceled.

Connecting to a PC

This chapter provides instructions and tells you how connecting to a PC can be useful.

Topics include:

- Working with a PC**
- Setting Up Your System as a Hardware Device**
- Placing Your System Online**
- Printing from a PC**
- Working with the File Management Utility**
- Upgrading the Operating System**

Working with a PC

If you have a PC that meets the system requirements, and has the appropriate software installed, you can connect it to your label printing system. When you connect your label printing system to a PC:

- You can use your label printing system as a peripheral printer for the PC. This means you can use the MarkWare[®] application running on your PC to make labels and then print them on your label printer.
- You can use the File Management Utility to transfer files between your label printing system and the PC. For example, you can transfer graphic files such as a logo to your system. The files you transfer can then be used to create output when your label printing system is not connected to a PC.

Note: If the PC does not support USB, you can use a serial cable to connect your printing system to a PC. See your PC's documentation on serial port connections.

Setting Up Your System as a Hardware Device

Before you can use a PC to print to your label printing system or to transfer files, your label printing system must be set up as a new hardware device.

To set up your label printing system as a hardware device

1. Before turning on the power for either your label printing system or your PC, connect one end of the USB cable to the printer and the other end to a USB port on the PC. See **Figure 2-2 on page 2-4** for an illustration.
2. Turn on your label printing system.
3. When you see the **Main Menu** screen, turn on the PC.
4. The operating system on the PC automatically detects your label printing system. Follow the PC prompts and instructions for setting up your printer as a new hardware device.

Note: If your PC is not “Plug & Play,” and does not automatically detect the label printing system, try adding the printer through the PC Control Panel. On the Control Panel, choose Add/Remove Hardware, and follow the PC prompts for “Add a New Device.”

5. When the PC procedure prompts you for the location of the device driver files, insert the CD-ROM labeled GlobalMark 2 Product CD in the CD-ROM drive of the PC, and enter the address for the CD-ROM drive when prompted.
6. Follow the prompts on your PC. The PC reads and installs the correct drivers.

Note: You may need to restart both systems after installation is complete.

Your PC is now set up to communicate with your label printing system.

Placing Your System Online

Before you place your printing system online, you must reset some system settings.

Setting Online Options

Use the **System Setup** screen **online** tab options to:

- Set up the type of connection you want to use: USB or serial.

To set Online options

1. On the **Main Menu** screen, choose **Setup**:




Figure 12-1. The Main Menu screen.

You'll see the **System Setup** screen (Figure 5-1 on page 5-2).

2. Choose the **online** tab, shown here:




Figure 12-2. The online tab screen.

3. Choose a connection type. If your PC does not have a USB connector, choose serial.

Note: You'll also use the **File Management Utility** to upgrade the operating system for your printer.

4. Choose OK. You'll be returned to the **Main Menu** screen.

Connecting your system and a PC

In this procedure, you make the actual connection between the PC and your printer.

To place your label printing system online

1. Connect one end of the cable to your printing system and the other to a PC.
The cable you use, USB or serial, should be same as you used in the procedure described in **Setting Up Your System as a Hardware Device** on page 12-3.
2. Turn on your printing system.

You'll see the **Online Status** screen, which displays the connection type and a progress box that indicates you are receiving print data from the PC:




Figure 12-3. The Online Status screen.

You can now print to your label printing system from MarkWare or transfer files using the File Management Utility.

Note: You can press **Cancel** to stop the data transfer and cancel the print job.

Printing from a PC

Before you can use your label printing system as a peripheral printer, you must perform these tasks:

1. Set up your label printing system as a hardware device. Follow the instructions in **Setting Up Your System as a Hardware Device** on page 12-3.
2. Install the MarkWare[®] application. Follow the installation instructions found in the *MarkWare User's Guide*.
3. Install the appropriate printer driver for your printer. Follow the instructions included with the driver.

Hint! Connect your label printing system to the PC and place it online before running the MarkWare and driver installation on the PC. The print driver install function includes a utility that will help you if you are using a serial port for your printer.

Working with the File Management Utility

The File Management Utility is an application included with the GlobalMark 2 printer. Use the File Management Utility to do the following:

- Transfer files from the PC to GlobalMark 2
- Transfer files from the GlobalMark 2 to a PC
- Manage existing GlobalMark 2 printer files
- Upgrade existing GlobalMark 2 printer files using an external FTP site or CD-ROM.

Note: File Management Utility can only be used with serial (COM) on Windows NT4.0

Storage locations for exported files

The MarkWare application contains a \Download folder in the main \MarkWare directory. In a standard system, this would be located at C:\Program Files\Brady\MarkWare\Download.

Document and Template files

The MarkWare application's export feature prepares document and template files for use on your label printing system. See the *MarkWare*® *User's Guide* for more information.

Table 12-1 shows file locations for both your PC and your printing system, and assumes you are using the \Download directory on the PC to organize the files you want to transfer to your label printing system.

Important! Your label printing system recognizes only files with the file extensions shown in **Source File Types on page 12-9**.

TABLE 12-1. Source File Types

File Type	Extension	Transfer to (Printing System)	Transfer from (PC Location)
Graphic Files	*.bmp, *.wmf	\Graphics\ <i>Category name</i> (It is recommended that you create a <i>My Graphics</i> folder in <i>Graphics</i> ; however, you can save the graphic in any existing category folder)	Retrieve files from storage locations on your PC
Cut Out Graphics	*.cog	\Cut Graphics\ <i>Category name</i> (It is recommended that you create a <i>My Cut Graphics</i> folder in <i>Cut Graphics</i> ; however, you can save the cut graphic in any existing category folder.)	Retrieve files from storage locations on your PC
Document Files	*.lbl, *.mw	\Saved files\ <i>Category name</i> (It is recommended that you create a <i>My Documents</i> folder in <i>Saved Files</i> ; however, you can save the document in any existing category folder.)	Retrieve files from storage locations on your PC
Template Files	*.tpl	\Applications\My Templates\Templates\Default category name	Retrieve files from storage locations on your PC
Fonts	*.ttf	\Fonts	Retrieve files from storage locations on your PC
Cut Out Fonts	*.tvf	\Cut Fonts	Retrieve files from storage locations on your PC
Text Lists	*.txt	\Saved Lists	Retrieve files from storage locations on your PC
Other	*.*	These files may not be compatible with the printer and will not be converted to the proper format.	Retrieve files from storage locations on your PC

Hint! You can download **Right-to-Know** and **Pipe Marker** documents. However, you must open these files through the **Custom** application on the standalone machine.

Note: In order to create a cut out graphic (*.cog), you must open the graphic in a graphic editor and save it as an *.ai file. Then, rename the file with the *.cog extension in Explorer.

Installing the File Management Utility

To install the **File Management Utility**, complete the following steps:

1. Insert the GlobalMark 2 Utilities CD-ROM.
2. Select Install File Management Utility.

OR If Autorun is disabled, you can begin the installation process manually:

1. Insert the GlobalMark 2 Utilities CD-ROM.
2. Click on **Start|Run**
3. Type **D:\File Management Utility\Setup.exe** and click **OK**.

Note: Follow the InstallShield Wizard's setup instructions until you have finished the installation. (If an error occurs, please verify that you meet or exceed the recommended system requirements.)

Launching the File Management Utility

Once the File Management Utility is installed on your PC, you can launch it by selecting the File Management Utility shortcut or icon (it will then attempt to connect with your computer).

Communication Status

The File Management Utility's Main Menu's screen shows the communication status between the PC and printer:

Communication Successful

If the *Communication Successful* message displays, you will be able to work with the File Management Utility.

Communication Failed

If the *Communication Failed* message displays, you will need to manually establish communication by completing the following steps:

1. Check the **Port** setting to be sure it matches the Printer to which it is connected.
2. Click the **Configure Port** button to verify the selected Port's settings. This button directs you to the *Port Configuration Tab* in the Windows operating system.
3. Click the **Test Connection** button after all communication selections are verified, making sure the printer is attached to establish communication.

Note: You may have to repeat this process if the Port or Configure Port selections are incorrect.

File Management Utility Main Menu



Figure 12-4. File Management Utility main screen

The File Management Utility main screen displays the following functions:

- **Transfer Files to Printer** lets you transfer files on your computer's hard drive to your printer's internal memory or to its external storage card.
- **Transfer Files from Printer** lets you transfer files from either your printer's internal memory or from its external storage card to your computer's hard drive.
- **Manage Printer Files** lets you manage files on your printer's internal memory and on the external storage card inserted into your printer.
- **Upgrade Printer Files** lets you upgrade files in your printer's internal memory online, using an automated process.

Transferring and Managing Files

To transfer and manage files between the PC and the printer, complete the following steps:

1. Select one of the following options:

- **Transfer Files to Printer**
 - **Transfer Files from Printer**
 - **Manage Printer Files**
2. Select the **Source File Type** from the drop-down box.
 3. Select the **Source** to copy, move or delete files.

Important! Your label printing system recognizes only files with the file extensions shown in **Source File Types on page 12-9**.

4. Select the **Destination** folder from one of the following locations:
 - GlobalMark 2\Internal\ (printer's internal memory) file directory structure
 - GlobalMark 2\External\ (printer's external storage card) file directory structure

Note: The File Management Utility may create folders for you. For example, if file type **Graphics** is selected, *Graphics\My Graphics* will be created for you. Click **New Category** to create a new category or folder on the Destination drive by entering its name in the field on the dialog box.

5. Select the **File(s)** from the **Source** or **Destination** by holding down the Shift or Ctrl key while clicking on each file name with the mouse to select multiple files.

Note: Only files of the selected File Type will appear. To return to the original folder, use the **Source** or **Destination** drop-down menus.

6. Select one of the following buttons:
 - a. **Copy:** to copy the files from one destination to another.
 - b. **Move:** to move files from one destination to another.
 - c. **Delete:** to delete files from the Source. The **Verify Delete** window will display, listing the files you are about to delete. Click **Yes** to continue or **No** to cancel.

Note: Click the **Refresh** button to refresh the contents of the File Directory Structure as needed.

TABLE 12-2. Error Messages

Insufficient Space window	Displays if there is not enough memory within the destination to transfer the selected files.
Loss of communication window	Displays if communication between the attached printer and PC is lost. You will need to exit the utility and follow the steps for connecting again.
Verify Valid Destination window	Displays if the entered file destination is incorrect. You will need to enter another destination for the files that you have selected.
Operation failed	Displays if the process failed.

7. Select **Back to Main Screen** to return to the Main menu or **Exit** to exit from the utility.

Upgrading the Operating System

Note: The **Upgrade Printer Files** button will be available but not functional until there is a new product release. You will see the message *No updates at this time.*

When new operating systems for your label printing system are available, if you have access to a PC, it's simple to upgrade.

Note: If you do not have access to a PC, instructions for upgrading will be shipped to you with your upgrade card.

To upgrade using the File Management Utility (online)

1. Place your system online for transferring files. See *Placing Your System Online* on page 12-4 for instructions.
2. After establishing a guest connection between your label printing system and the PC, start the File Management Utility program on the PC.
3. Select **Upgrade Printer files**.
4. Establish an Internet connection.
5. Select **Upgrade from Internet**.
6. After the upgrade is done, you will need to restart your label printing system.

To upgrade using a CD-ROM

1. Place your system online for transferring files. See *Placing Your System Online* on page 12-4 for instructions.
2. After establishing a guest connection between your label printing system and the PC, start the Upgrade Utility program on the PC.
3. After the upgrade is done, you will need to restart your label printing system.

Special Characters

The tables that follow provide the symbol, the unicode value, and the decimal value for special characters you can use with your label printing system.

Table 1 on page A-2 lists special characters you can insert when using these fonts:

- Arial 65 for BRC
- Arial for BRC
- Times New Roman for BRC

Table 2 on page A-6 lists special characters you can insert when using:

- Brush Script for BRC

See **Adding special characters to text** on page 7-8 for information about inserting symbols and other special characters on your labels.

TABLE 1. Special Characters for Arial 65 for BRC, Arial for BRC, and Times New Roman for BRC fonts, listing symbol, unicode value, and decimal value for each.T

!	0021	33
"	0022	34
#	0023	35
\$	0024	36
%	0025	37
&	0026	38
'	0027	39
(0028	40
)	0029	41
*	002A	42
+	002B	43
,	002C	44
-	002D	45
.	002E	46
/	002F	47
0	0030	48
1	0031	49
2	0032	50
3	0033	51
4	0034	52
5	0035	53
6	0036	54
7	0037	55
8	0038	56
9	0039	57
:	003A	58
;	003B	59
<	003C	60
=	003D	61
>	003E	62
?	003F	63

@	0040	64
A	0041	65
B	0042	66
C	0043	67
D	0044	68
E	0045	69
F	0046	70
G	0047	71
H	0048	72
I	0049	73
J	004A	74
K	004B	75
L	004C	76
M	004D	77
N	004E	78
O	004F	79
P	0050	80
Q	0051	81
R	0052	82
S	0053	83
T	0054	84
U	0055	85
V	0056	86
W	0057	87
X	0058	88
Y	0059	89
Z	005A	90
[005B	91
\	005C	92
]	005D	93
^	005E	94

~	005F	95
`	0060	96
a	0061	97
b	0062	98
c	0063	99
d	0064	100
e	0065	101
f	0066	102
g	0067	103
h	0068	104
i	0069	105
j	006A	106
k	006B	107
l	006C	108
m	006D	109
n	006E	110
o	006F	111
p	0070	112
q	0071	113
r	0072	114
s	0073	115
t	0074	116
u	0075	117
v	0076	118
w	0077	119
x	0078	120
y	0079	121
z	007A	122
{	007B	123
	007C	124
}	007D	125

TABLE 1, CONTINUED

˜	007E	126
ı	00A1	161
₣	00A2	162
£	00A3	163
¤	00A4	164
¥	00A5	165
ı	00A6	166
§	00A7	167
˘	00A8	168
©	00A9	169
ª	00AA	170
«	00AB	171
¬	00AC	172
®	00AE	174
ˉ	00AF	175
°	00B0	176
±	00B1	177
²	00B2	178
³	00B3	179
´	00B4	180
µ	00B5	181
¶	00B6	182
·	00B7	183
¸	00B8	184
ı	00B9	185
°	00BA	186
»	00BB	187
¼	00BC	188
½	00BD	189
¾	00BE	190
¿	00BF	191
À	00C0	192
Á	00C1	193

Ä	00C2	194
Å	00C3	195
Ä	00C4	196
Å	00C5	197
Æ	00C6	198
Ç	00C7	199
È	00C8	200
É	00C9	201
Ê	00CA	202
Ë	00CB	203
Ì	00CC	204
Í	00CD	205
Î	00CE	206
Ï	00CF	207
Ð	00D0	208
Ñ	00D1	209
Ò	00D2	210
Ó	00D3	211
Ô	00D4	212
Õ	00D5	213
Ö	00D6	214
×	00D7	215
Ø	00D8	216
Ù	00D9	217
Ú	00DA	218
Û	00DB	219
Ü	00DC	220
Ý	00DD	221
Þ	00DE	222
ß	00DF	223
à	00E0	224
á	00E1	225
â	00E2	226

ã	00E3	227
ä	00E4	228
å	00E5	229
æ	00E6	230
ç	00E7	231
è	00E8	232
é	00E9	233
ê	00EA	234
ë	00EB	235
ì	00EC	236
í	00ED	237
î	00EE	238
ï	00EF	239
ð	00F0	240
ñ	00F1	241
ò	00F2	242
ó	00F3	243
ô	00F4	244
õ	00F5	245
ö	00F6	246
÷	00F7	247
ø	00F8	248
ù	00F9	249
ú	00FA	250
û	00FB	251
ü	00FC	252
ý	00FD	253
þ	00FE	254
ÿ	00FF	255
À	0100	256
Á	0101	257
Â	0102	258
Ã	0103	259

TABLE 1, CONTINUED

À	0104	260
á	0105	261
Ā	0106	262
ă	0107	263
Ĉ	0108	264
ĉ	0109	265
Ċ	010A	266
ċ	010B	267
Č	010C	268
č	010D	269
Ď	010E	270
ď	010F	271
Ð	0110	272
đ	0111	273
Ē	0112	274
ē	0113	275
Ĕ	0114	276
ĕ	0115	277
Ė	0116	278
ė	0117	279
Ę	0118	280
ę	0119	281
Ē	011A	282
ě	011B	283
Ĝ	011C	284
ĝ	011D	285
G	011E	286
ġ	011F	287
Ĝ	0122	290
ġ	0123	291
H	0124	292
h	0125	293
Ī	012A	298

ī	012B	299
Ī	012C	300
ĭ	012D	301
Ĳ	012E	302
ĳ	012F	303
Ĭ	0130	304
ı	0131	305
J	0134	308
j	0135	309
Ƙ	0136	310
ƙ	0137	311
Ļ	0139	313
Ļ	013A	314
Ļ	013B	315
Ĵ	013C	316
Ĵ	013D	317
ƚ	013E	318
Ł	0141	321
ł	0142	322
N	0143	323
ń	0144	324
Ń	0145	325
ņ	0146	326
Ń	0147	327
ñ	0148	328
Ō	014C	332
ō	014D	333
Ō	014E	334
ō	014F	335
Ō	0150	336
ó	0151	337
Œ	0152	338
œ	0153	339

R	0154	340
ř	0155	341
R	0156	342
ŗ	0157	343
Ř	0158	344
ř	0159	345
S	015A	346
ś	015B	347
S	015C	348
š	015D	349
Ş	015E	350
ş	015F	351
S	0160	352
š	0161	353
T	0162	354
t	0163	355
T	0164	356
t	0165	357
U	016A	362
ū	016B	363
U	016C	364
ū	016D	365
U	016E	366
ū	016F	367
U	0170	368
ú	0171	369
U	0172	370
u	0173	371
W	0174	372
w	0175	373
Y	0176	374
y	0177	375
Y	0178	376

TABLE 1, CONTINUED

Ž	0179	377
ž	017A	378
Ž	017B	379
ž	017C	380
Ž	017D	381
ž	017E	382
Đ	0189	393
Σ	01A9	425
Z	01B5	437
z	01B6	438
DŽ	01C4	452
Dž	01C5	453
dž	01C6	454
Ā	01CD	461
ā	01DE	462
Ī	01CF	463
ī	01D0	464
Ō	01D1	465
ō	01D2	466
Ū	01D3	467
ū	01D4	468
Ġ	01E6	486
ġ	01E7	487
K	01E8	488
k	01E9	489
Q	01EA	490
q	01EB	491
Ž	01EE	494
ž	01EF	495
J	01F0	496
DŽ	01F1	497
Dz	01F2	498
dz	01F3	499

Ĝ	01F4	500
ĝ	01F5	501
Ñ	01F8	504
ñ	01F9	505
Ā	0200	512
ā	0201	513
Ā	0202	514
ā	0203	515
Ē	0204	516
ē	0205	517
Ē	0206	518
ē	0207	519
Ī	0208	520
ī	0209	521
Ī	020A	522
ī	020B	523
Ō	020C	524
ō	020D	525
Ō	020E	526
ō	020F	527
Ŕ	0210	528
ř	0211	529
Ŕ	0212	530
ř	0213	531
Ū	0214	532
ū	0215	533
Ū	0216	534
ū	0217	535
Ş	0218	536
ş	0219	537
Ť	0220	538
ť	0221	539
Ĥ	021E	542

ĥ	021F	543
Z	0224	548
z	0225	549
Ā	0226	550
ā	0227	551
Ē	0228	552
ē	0229	553
Ō	022E	558
ō	022F	559
Ÿ	0232	562
ÿ	0233	563
•	2080	8320
ı	2081	8321
ı	2082	8322
ı	2083	8323
ı	2084	8324
ı	2085	8325
ı	2086	8326
ı	2087	8327
ı	2088	8328
ı	2089	8329
£	20A4	8356
€	20AC	8364

TABLE 2. Special Characters for Brush Script for BRC font, listing the symbol, unicode value, and decimal value for each

<i>!</i>	0021	33
<i>"</i>	0022	34
<i>#</i>	0023	35
<i>\$</i>	0024	36
<i>%</i>	0025	37
<i>&</i>	0026	38
<i>'</i>	0027	39
<i>(</i>	0028	40
<i>)</i>	0029	41
<i>*</i>	002A	42
<i>+</i>	002B	43
<i>,</i>	002C	44
<i>-</i>	002D	45
<i>.</i>	002E	46
<i>/</i>	002F	47
<i>0</i>	0030	48
<i>1</i>	0031	49
<i>2</i>	0032	50
<i>3</i>	0033	51
<i>4</i>	0034	52
<i>5</i>	0035	53
<i>6</i>	0036	54
<i>7</i>	0037	55
<i>8</i>	0038	56

<i>9</i>	0039	57
<i>:</i>	003A	58
<i>;</i>	003B	59
<i><</i>	003C	60
<i>=</i>	003D	61
<i>></i>	003E	62
<i>?</i>	003F	63
<i>@</i>	0040	64
<i>A</i>	0041	65
<i>B</i>	0042	66
<i>C</i>	0043	67
<i>D</i>	0044	68
<i>E</i>	0045	69
<i>F</i>	0046	70
<i>G</i>	0047	71
<i>H</i>	0048	72
<i>I</i>	0049	73
<i>J</i>	004A	74
<i>K</i>	004B	75
<i>L</i>	004C	76
<i>M</i>	004D	77
<i>N</i>	004E	78
<i>O</i>	004F	79
<i>P</i>	0050	80

<i>Q</i>	0051	81
<i>R</i>	0052	82
<i>S</i>	0053	83
<i>T</i>	0054	84
<i>U</i>	0055	85
<i>V</i>	0056	86
<i>W</i>	0057	87
<i>X</i>	0058	88
<i>Y</i>	0059	89
<i>Z</i>	005A	90
<i>[</i>	005B	91
<i>\</i>	005C	92
<i>]</i>	005D	93
<i>^</i>	005E	94
<i>_</i>	005F	95
<i>`</i>	0060	96
<i>a</i>	0061	97
<i>b</i>	0062	98
<i>c</i>	0063	99
<i>d</i>	0064	100
<i>e</i>	0065	101
<i>f</i>	0066	102
<i>g</i>	0067	103
<i>h</i>	0068	104

TABLE 2, CONTINUED

ı	0069	105
ı	006A	106
ı	006B	107
ı	006C	108
ı	006D	109
ı	006E	110
ı	006F	111
ı	0070	112
ı	0071	113
ı	0072	114
ı	0073	115
ı	0074	116
ı	0075	117
ı	0076	118
ı	0077	119
ı	0078	120
ı	0079	121
ı	007A	122
{	007B	123
	007C	124
}	007D	125
~	007E	126
/	00A1	161
ı	00A2	162

ı	00A3	163
ı	00A4	164
ı	00A5	165
ı	00A6	166
ı	00A7	167
ı	00A8	168
ı	00A9	169
ı	00AA	170
ı	00AB	171
ı	00AC	172
ı	00AE	174
ı	00AF	175
ı	00B0	176
ı	00B1	177
ı	00B2	178
ı	00B3	179
ı	00B4	180
ı	00B5	181
ı	00B6	182
ı	00B7	183
ı	00B8	184
ı	00B9	185
ı	00BA	186
ı	00BB	187

ı	00BC	188
ı	00BD	189
ı	00BE	190
ı	00BF	191
ı	00C0	192
ı	00C1	193
ı	00C2	194
ı	00C3	195
ı	00C4	196
ı	00C5	197
ı	00C6	198
ı	00C7	199
ı	00C8	200
ı	00C9	201
ı	00CA	202
ı	00CB	203
ı	00CC	204
ı	00CD	205
ı	00CE	206
ı	00CF	207
ı	00D0	208
ı	00D1	209
ı	00D2	210
ı	00D3	211

TABLE 2, CONTINUED

Ō	00D4	212
Ŏ	00D5	213
Ű	00D6	214
×	00D7	215
Ø	00D8	216
Ù	00D9	217
Ú	00DA	218
Û	00DB	219
Ü	00DC	220
Ý	00DD	221
Þ	00DE	222
ß	00DF	223
à	00E0	224
á	00E1	225
â	00E2	226
ã	00E3	227
ä	00E4	228
å	00E5	229
æ	00E6	230
ç	00E7	231
è	00E8	232
é	00E9	233
ê	00EA	234
ë	00EB	235

ì	00EC	236
í	00ED	237
î	00EE	238
ï	00EF	239
ð	00F0	240
ñ	00F1	241
ò	00F2	242
ó	00F3	243
ô	00F4	244
õ	00F5	245
ö	00F6	246
÷	00F7	247
ø	00F8	248
ù	00F9	249
ú	00FA	250
û	00FB	251
ü	00FC	252
ý	00FD	253
þ	00FE	254
ÿ	00FF	255
ı	0131	305
Œ	0152	338
œ	0153	339
Š	0160	352

đ	0161	353
Ź	0178	376
ƒ	0192	402
ˆ	02C6	710
ˇ	02C7	711
˘	02C9	713
˙	02D8	728
˚	02D9	729
°	02DA	730
˛	02DB	731
˜	02DC	732
¨	02DD	733
π	03C0	960
—	2013	8211
—	2014	8212
˙	2018	8216
˙	2019	8217
˙	201A	8218
˙	201C	8220
˙	201D	8221
˙	201E	8222
†	2020	8224
‡	2021	8225
•	2022	8226

TABLE 2, CONTINUED

...	2026	8230
‰	2030	8240
◀	2039	8249
▶	203A	8250
€	20AC	8364
™	2122	8482
Ω	2126	8486
∂	2202	8706
Δ	2206	8710
∏	220F	8719
∑	2211	8721
/	2215	8725
.	2219	8729
√	221A	8730
∞	221E	8734
∫	222B	8747
≈	2248	8776
≠	2260	8800
≲	2264	8804
≳	2265	8805
⊞	25CA	9674

Cutter Maintenance

If you have the Color & Cut system, you may need this information.

The instructions in this appendix tell you:

- How to remove and replace your printer's cutting blade.
- How to adjust the depth of the cuts on your labels.
- How to clean the cutting blade.

About the Cutting Mechanism

Your plotter cutter consists of a stylus blade in a holder, mounted on a track in your printer. The stylus is moved mechanically across the tape in the design you designate.

The stylus consists of the cutting blade and the apparatus that holds the blade in place. It is contained in a holder that fits into the tracking mechanism in your printer. Figure B-2 on page B-4 provides a close-up view of the stylus holder.

To produce a cut out, the printer moves the stylus using the tracking mechanism across the tape, cutting the tape in the design you specified. The printer delivers the cut out label with the backing in place. All you have to do is strip the cut out from the backing.

You may need to adjust the depth of the blade within the stylus from time to time, and you may need to replace or clean the stylus holder as well. The sections that follow describe these procedures.

Removing the Stylus Holder

Follow these instructions to remove the stylus for adjusting, cleaning, or replacing.

- Step 1:** Turn the power off, then open the printer.
- Step 2:** Move the stylus holder mechanism to the center of the track, to make it easier to work with.
- Step 3:** To disengage the stylus holder, turn it counterclockwise to unscrew it, as shown in Figure B-1.




Figure B-1. Removing the stylus holder.

- Step 4:** Pull straight up to remove the stylus holder from the tracking mechanism.

Adjusting the Cut Depth

You may need to adjust the stylus blade on your cutter when:

- The cuts on your cut out labels are either too deep or too shallow.
- You install tape supplies of varying thickness.

The stylus holder has an adjustment dial you use to change the depth at which the stylus blade cuts the tape.

Step 1: Turn the power off, and open the printer. Follow the instructions in the **Removing the Stylus Holder** section above to remove the stylus holder, shown here:




Figure B-2. The stylus holder.

The stylus blade protrudes very slightly from the stylus nose. The stylus glides across the tape when cutting your label.

Step 2: Hold the stylus holder as shown here (Figure B-3) to make the adjustment.




Figure B-3. Adjusting the Stylus Depth change the diagram.

Step 3: Start by turning the adjustment dial slowly.

- Turn the dial clockwise to increase the cutting depth.
- Turn the dial counter-clockwise to decrease the cutting depth.

Step 4: Test the stylus before re-installing it:

1. Take a sample piece of the installed tape, and place it flat on a hard surface

2. Holding the stylus holder perpendicular to the surface, glide the stylus nose lightly across the tape. need diagram with new stylus holder




Figure B-4. Testing cutting depth.

Note: Apply slight pressure. Make sure the stylus holder is positioned straight vertically.

3. Check the tape to see if the cut is correct. The cut should go through the tape, but leave the backing paper unscored.

Step 5: Make any adjustments required to the stylus depth, then test again.

Step 6: Reinstall the stylus holder. Seat it in the mechanism, then turn it clockwise until it stops.

Replacing the Stylus Blade

At some point, especially after prolonged use with specialty tapes, you may have to replace the stylus blade.

- Step 1:** Turn the power off, and open the printer. Follow the instructions in **Removing the Stylus Holder** on page B-3.
- Step 2:** Holding the stylus holder in both hands as shown below, keep the nose end of the mechanism stable and turn the other end counterclockwise, loosening it until the two parts separate. new diagram




Figure B-5. Detaching the stylus.

Step 3: Carefully pull on the blade to remove it, as shown here: new diagram




Figure B-6. Removing the blade.

CAUTION: Be careful to grasp the blade on the shank, and not on the cutting edge.

Step 4: Insert the new blade.

Step 5: Reconnect the two parts of the stylus holder:

Push the blade holder as far down as possible, then turn it clockwise, until you feel the threads engage. Turn until the stylus protrudes from the opening, as shown in Figure B-2 on page B-4.

Step 6: Adjust the blade depth. Follow the instructions in **Adjusting the Cut Depth** on page B-4.

Step 7: Reinstall the stylus holder. Seat it in the mechanism, then turn it counter-clockwise until it is securely seated.

Cleaning the Stylus

Clean the stylus with Isopropyl alcohol and a cotton-tip swab. These are the same materials you use to clean the print head on your printer, described in **Cleaning your system** on page 2-13. (You may already have purchased a cleaning kit with your printer.)

- Step 1:** Turn the power off, and open the printer. Remove the stylus as described in Steps 1 and 2 in **Removing the Stylus Holder** on page B-3.
- Step 2:** Apply alcohol to the cotton swab, and wipe the stylus blade as shown here:




Figure B-7. Cleaning the stylus blade.

- Step 3:** Reconnect the two parts of the stylus holder:
Push the blade holder as far down as possible, then turn it clockwise, until you feel the threads engage. Turn until the stylus protrudes from the opening, as shown in Figure B-2 on page B-4
- Step 4:** Adjust the blade depth. Follow the instructions in **Adjusting the Cut Depth** on page B-4.
- Step 5:** Reinstall the stylus holder. Seat it in the mechanism, then turn it clockwise until it's securely seated.

Error Messages

Error conditions may appear during printing that require some action before you can continue. This section outlines changes to the error messaging functions to improve operator success in responding to error conditions:

Topics include

- **Error Messages**

Error Messages

Note: When an error message appears, it remains on the screen until you correct the error condition.

The table below shows the error code reported by the system firmware, the condition that generated that error code, the error message, the user action required to clear the error message, and any additional information.

When a print job is canceled because of an error condition, the printer attempts to eject and cut off the unfinished print job (where doing so will not harm the printer). In instances where that is not possible, the error message provides additional instructions for removing the partial output and returning the printer to a usable condition.

TABLE 1. Error Messages

Code	User Action
15	Close printer cover.
16	Close printer cover, and advance and shear tape.
17	Close printer cover.
18	None
19	Remove partial output, reload tape, then advance and shear.
48	Install tape with valid memory cell.
49	Install tape.
50	Install tape with valid memory cell.
51	Install tape with valid memory cell.
52	Install tape with valid memory cell.
53	Reinstall tape or install new tape.
54	Clear tape jam.

Code	User Action
55	Reload tape correctly.
56	Clean sensor and reload tape.
57	Replace ribbon.
58	Replace ribbon.
59	Replace ribbon.
60	
61	Remove ribbon.
62	Install wider ribbon.
63	Install ribbon and close cover or, press Continue with Current Ribbon button.
64	Install ribbon with valid memory cell.
65	Install ribbon with valid memory cell.
66	Install ribbon with valid memory cell.
67	Install ribbon with valid memory cell.
68	Install ribbon with valid memory cell.
80	Clear jam in shear cutter path.
81	Clear jam in tape path.
82	None. Service required
83	None. Service required

Code	User Action
84	Replace ribbon.
85	Clean sensor (part of tape guides).
87	Clear tape jam.
88	Clear tape jam.
89	None. Service required
90	None
91	None
92	None
93	None

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>